

FILE INFORMATION

DATE: 08/26/19

MODEL NUMBER:
MI-S037B-101 (MANUAL)

PRINTER SPECIFICATIONS

FILE NAME:
MI-S037B-101_Manual_082619.ai
SCALE: 100%
SIZE: Trim: W 221mm x H 164mm
PAPER STOCK: 80g Art Paper
INKS: 1/1
Grayscale
PRESS WORK / NOTES: Trim to size, score, fold,
& glue in specified areas.

Trim

Score

DO NOT print Comments or Dielines.
Physical sample according to specs must be approved
by MERKURY before proceeding to production.

CONTACT

MERKURY CHINA: Perry
perry@merkuryinnovations.com.cn

COMMENTS (Internal reference only)

File created by Ahri

- Please include this manual in all packaging
for MI-S037B
- Grayscale
- Double sided printing

Troubleshooting

No power	Recharge your PUMPED using the included micro USB cable. Try using a different cable.
Music is not playing over Bluetooth	Make sure your Bluetooth® device has A2DP profile. Check if both devices are paired and connected over Bluetooth®. Restart the speaker to reconnect your Bluetooth® device.
Bluetooth device will not reconnect with the speaker	Navigate to your Bluetooth® settings menu on your Bluetooth® device, tap “MERKURY S037B” and select “Forget.” Now follow the steps to pair your device again.

Specs

Speaker Specifications: Output Power: Dual 2.5W Frequency Response: 20Hz to 20KHz Dimensions (WxHxD): 31in x 8.26in x 2.7in	Power Information: Input: DC 5V Battery Capacity: 1200mAH Music playing time: Up to 3 Hours* Charging time: 3-4 hours
Additional Connection Sources: Power Source: Built-in rechargeable battery or via USB cable	Bluetooth® Information: Bluetooth® Specification: V5.0 Operating Distance: 30 Ft. System Requirements: Bluetooth®-capable device

*Depends on individual use and may be slightly more or less than the time specified.

Technical Support:
If you are experiencing problems, do not attempt to fix the product by yourself or return it to the store you bought it from. Please refer to the user manual or just contact our helpful support team:


Merkury Innovations
45 Broadway, 3rd Floor
New York, New York 10006
www.merkuryinnovations.com
support@merkuryinnovations.com

This device complies with Part 15 of the FCC Rules. Operation is subject to the two following conditions:
1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

©2019 Merkury Innovations, LLC.
To explore our full selection of products, visit us at: www.merkuryinnovations.com

Bluetooth is a registered trademark of Bluetooth SIG, Inc. The illustrated product and specifications may differ slightly from those supplied. All other trademarks and trade names are those of their respective owners.

Made in China



PUMPED
User's Manual for HPS-131

- Package Includes:**
- PUMPED Bluetooth® Speaker
 - Micro USB Cable
 - 3.5mm Aux Cable
 - User Manual

Charge

- Plug the micro USB cable into the micro USB port on the back of the speaker, and connect the other end of the cable with any compatible charger or wall outlet.
- When charging, the small LED indicator will glow solid red. When fully charged, the LED indicator will turn off.
- Charging time is approximately 3-4 hours.

Turn On & Off

- Press and hold power button on top of the speaker to turn device ON and OFF

Pair & Connect

- Make sure the speaker is turned off and your device's Bluetooth® setting is activated.
 - Turn the speaker on; after a few seconds it will automatically enter into pairing mode & the LED will flash.
 - On your Bluetooth®-enabled device, navigate to the Bluetooth® settings menu, turn on the Bluetooth® feature, and search for new devices.
 - Wait a few seconds & select “MERKURY S037B” The speaker will emit a tone when successfully paired.
- NOTE:** If your device's Bluetooth® version is below version 2.1, you may need to enter the password “0000.”


Play

- Connect your device to the speaker via Bluetooth® (see “Pair & Connect”).
- Open your favorite music app and press play.
- Change the track and volume, or control them from the controls on the speaker.
- Press the “M” button once to play/pause music.
- Press the “+” or “-” button once to raise/lower the volume on the speaker. Press & hold to skip to the next/previous track.
- All audio, including music, games, videos, and notifications will be routed through the speaker.


Reconnect to Bluetooth®

- You only need to pair your Bluetooth® device with the speaker once.
- With your previously paired device's Bluetooth® turned on & in range, power on the speaker.
- The speaker will automatically reconnect to the last Bluetooth® device it was connected to.
- If you have a previously paired device that does not auto-reconnect, navigate to the Bluetooth® settings menu on your device, turn on the Bluetooth® feature, and select “MERKURY S037B” from your list of paired Bluetooth® devices.

Control



Ports



This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

- Reorient the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.