

01 Customer Service

www.tagry.studio

If you have any problems with your earbuds, please do not hesitate to contact us to solve your problem.

www.tagry.studio

02 Packing List

Charging Case \*1

Earbuds (L&R) \*1

Type-C Charging Cable \*1

User Manual \*1

Note:

Before using earbuds, please remove the protective films from the charging contacts.

03 Product Overview

Charging Contact

Microphone

LED Indicator of Earbud

Touch Control Area

Charging Pin

Type-C Charging Port

Charging Status of Earbuds(L/R)

Power Display of Charging Case

02

04 Product Parameters

Model No.: S64

Bluetooth Version: V5.4

Support Profile:A2DP/AVRCP/HSP/HFP

FCC ID: 2AMBA-S64 IC: 27838-S64

Charging Cord Type: USB-C Charging Cable

Imput: 5V 1A

Capacity for Charging Case: 500mAh, 3.7V, 1.85Wh

Capacity for Earbuds: 60mAh, 3.7V, 0.222Wh

Weight: 0.18 lb

Size: 4.3\*1.2\*2.1 in

03

05 First -Use

1. Please remove the protective film before use, otherwise the headphone will not be able to charge.

2. Please use put both earbuds into charging case and use usb-c cable to charge for earbuds about 2.5Hrs.

Remove Me

Input: DC 5V

03

06 How to Wear

Step 1:

Take out the earbuds

Step 2:

Place the earhook over your ear

Step 3:

Rotote it backward, and adjust to the optimal position for a secure and comfortable fit.

04

07 How to Charge?

Charging the Earbuds

Place both earbuds in the charging case. Then close the lid, while charging, the LED indicator of earbuds will be red. (When the earbuds are fully charged, the red light will turn off)

05

Input: DC 5V

08 Power On and Power Off

Power on

Auto power on

Once open the charging case, it will automatically power on and enter pairing mode, the LED indicator of earbuds will be on blue light for 1s.

Manual power on

When earbuds are out of charging case. Long press the touch area for 2s, then the LED indicator of earbud will be on blue light for 1s.

Note: in this situation, each earbud need to be manual power on separately.

06

L/R Earbuds

Power off

Auto power off

Put both earbuds into charging case and close the case, earbuds will auto power off.

Manual Power Off

Long press the touch control area of either earbud for 5s, earbuds will power off, the LED indicator of earbuds will be on red light for 1s.

Note: this way is just for earbuds are disconnected with your device.

07

Power Off

09 Pair and reset

How to pair

Stereo Mode

1. Open the charging case, earbud will power on automatically and they will connect with each other, then enter pairing mode.

2. Turn on your device bluetooth to search and select "S64" to connect.

You will hear a promote"power on" and the light on earbuds will be blue for 1s.

Note: If in the disconnected statement, the earbuds will enter pairing mode automatically, the led indicator for main earbud flash red and blue alternately, the sub earbud flash blue slowly. Once paired successfully, the led indicator for main earbud flash blue for 2s and off.

Single Earbud Mode

1. Take one earbud out from charging case and close the case.

08

10 Touch Control

Music Assistant

Play/Pause:

Double clicks L/R earbud.

Either Earbud Controls

Previous Track:

Triple clicks L earbud

Volume -:

Long press L earbud

Next Track:

Triple clicks R earbud.

Volume +:

Long press R earbud

10

11 Battery Warning

Using the wrong battery can cause fire and other hazards (for example, in the case of somelithium battery types).

1. Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of battery, that can result in an explosion.

2. Do not leaving a battery in an extremely high temperature surrounding environment thatcan result in an explosion or the leakage of flammable liquid or gas.

3. A battery subjected to extremely low air pressure that may result in an explosion or theleakage of flammable liquid or gas.

12 Storage and Maintenance

1. If the earbuds have been unused for more than 3 months, we recommend that you charge them.

2. Please use chargers that are FCC (Federal Communications).

3. Do not disassemble earbuds.

4. Adult supervision is required for children aged 6 and under.

5. Do not expose earbuds to high or low temperature, do not use the earbuds in thunderstorm storm. Avoid falling or violent impact of the device. Keep the device away from fire, do not put.

12

13 FCC Cauton

Changes or modifications not expressly approved by the party responsible for compliance may void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device,pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference with radio communications. However, there is a guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference with radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to attempt to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

--- Increase separation between equipment and receiver.

--- Connect the equipment to an outlet on a circuit different from that to the receiver is connected.

--- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

13

14 FAQ

Q: How can i do when the earbuds can't be charged?

A: Please check if the charging case are out of battery. If yes, please use USB-C cable to charge it. It will take about 2.5Hrs for fully charging.

If not about the battery, please check the earbuds as below details:

1. Put both earbuds into charging case to check if the LED indicator for earbuds are on. If not, please check whether there are dirty in the charging pins of earbuds and the charging case. Use a fine cotton swab dipped in a small amount of alcohol, wipe the charging pins of the earbuds and case.

2. Whether the earbuds can be turned on normally.

3. Ensure that you are using a standard adapter and the provided Type-C data cable for charging.

15

16

S64说明书  
尺寸:72.5\*111.3mm  
材质:108g铜版纸  
对折方式:风琴折