

User Guide

FlatMesh 3G Gateway

FM3G-HSPA
FM3G-HSPA-T
FM3G-HSPA-A



0.03

Contents

Warnings	ii
1 Overview	1
1.1 The FlatMesh System	1
1.2 FlatMesh 3G Gateway	1
1.3 Product Specifications	2
1.3.1 Physical Specifications	2
1.3.2 FlatMesh Radio Specifications	2
1.3.3 Cellular Radio Specifications	3
1.3.4 Internal Battery (Standard)	3
1.3.5 Internal Battery (-T Version)	3
1.3.6 Power Input	4
2 Installation	5
2.1 Mounting	5
2.1.1 Wall Bracket	5
2.1.2 Pole Mounting	6
2.2 Power	6
2.3 Antennae	6
3 Access Port	8
3.1 Active Node Count	8
3.2 USB Port	8
4 Maintenance	9
5 Support	10
A Export Restrictions	11
B Software Licenses	12
B.1 FreeRTOS	12
B.2 Newlib	15
B.3 GCC Runtime Library	21

Warnings



Warning

Protection provided by the equipment may be impaired if used in a manner contrary to this user manual.



Warning

Keep a minimum distance of 20cm between the 2G/3G antenna and the human body during normal operation.



Warning

Do not attach any unapproved power source. If in doubt, contact the equipment supplier.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device must accept any interference, and
2. This device must accept any interference received including interference that may cause undesired operation

Changes or modifications not expressly approved by Senceive Limited could void the user's authority to operate the equipment.

This equipment must be professionally installed. Only the supplied antennas are to be used with the equipment.



This product must not be disposed of in the normal waste stream. It contains a battery pack and electronic components and so should be recycled appropriately.

In accordance with the WEEE guidelines, customers in the European Union may return the product free of charge for recycling at the end of its life. Contact your supplier for details.

DRAFT

Chapter 1

Overview

1.1 The FlatMesh System

A FlatMesh network consists of a number of nodes connecting to one gateway device. In some situations circumstances multiple networks may be required on a single site, for example a site which exceeds the number supported by a single Gateway, or a site where there are a set of separate measurement zones.

The FlatMesh 3G Gateway is a fully integrated unit which provides all the functionality required to operate a FlatMesh wireless sensor network in a remote location. This document describes the functionality of the gateway only.

1.2 FlatMesh 3G Gateway

The gateway is capable of communicating with nodes over the FlatMesh network, operating on the 2.4GHz ISM band. It will buffer samples collected from sensor-enabled nodes and transmits data over the cellular network. The gateway supports both traditional 2G networks (GPRS) and 3G networks (UMTS/HSPA+).

This device has an internal Lithium Ion battery, which will last around 3 weeks on one charge. Your gateway will be provided with either a power supply, solar panel or booster pack to keep the internal battery charged.

1.3 Product Specifications

1.3.1 Physical Specifications

Dimensions excluding antennas	218 x 68 x 126 mm
Dimensions including antennas	390 x 68 x 126 mm
Total Mass	1.1 kg (approx.)
Housing Material	Die cast aluminium body ASA polymer lid rated to UL94HB Die cast aluminium lid (optional)
International Protection Marking	IP67
Mounting Options	Pole mount integrated with enclosure Wall mount bracket available separately
Operating Temperature Range	-30°C to +75°C

1.3.2 FlatMesh Radio Specifications

Communication Type	Proprietary FlatMesh v3 Mesh Networking Protocols IEEE 802.15.4 compliant
Frequency Band	2400 - 2485 MHz ISM Band
Maximum Transmit Power	6.2dBm (EN 300 328 v1.8.1)
Maximum Antenna Gain	4dBi
Range	Up to 300m depending on the environment Consult with Senceive for your application
Maximum Network Size	Typically up to 100 nodes Consult with Senceive to determine the optimal system configuration
RF Module	Senceive FM3Gateway
FCC ID	2AMFBFM3G

1.3.3 Cellular Radio Specifications

Frequency Bands for GSM/GPRS/EDGE	850/900/1800/1900 MHz
Frequency Bands for UMTS/HSPA+	800/850/900/1900/2100 MHz
Output Power	Class 4 (+33dBm) for EGSM850 / EGSM900 Class 1 (+30dBm) for GSM1800 / GSM1900 Class E2 (+27dBm) for GSM 850/900 8-PSK Class E2 (+26dBm) for GSM 1800/1900 8-PSK Class 3 (+24dBm) for UMTS 800/850/900/1900/2100, WCDMA FDD Bdl, BdII, BdVIII, BdV, BdVI
Maximum Antenna Gain	+0.89 dBi
Supported SIM Cards	3V and 1.8V
RF Module	Gemalto PH8-P
FCC ID	QIPPH8-P

1.3.4 Internal Battery (Standard)

Battery Type	Lithium Ion, rechargeable
Nominal Voltage	3.6V
Nominal Capacity	8800mAh
Typical Runtime without charge	21 days
Charging Temperature Range	0°C to +40°C

1.3.5 Internal Battery (-T Version)

Battery Type	Lithium Ion, rechargeable
Nominal Voltage	3.6V
Nominal Capacity	8000mAh
Typical Runtime without charge	19 days
Charging Temperature Range	-30°C to +60°C

1.3.6 Power Input

Recommended Solar Panel Type	12V 20W
Target Voltage for MPPT	15.0V
Maximum Input Voltage	32.0V
Input Voltage for Charging	12.0V - 32.0V

DRAFT

Chapter 2

Installation

The gateway will be delivered to you pre-configured. Simply affix the gateway device to a structure within range of the rest of the network. It is recommended that the gateway be placed in the centre of the network with line of sight to at least two nodes to improve network reliability.

2.1 Mounting

There are two mounting options for the gateway - a clamp fixing for a pole, or a bracket which can be fixed to a wall or strapped to a pole.



Warning

The gateway has a total approximate mass of 1.1kg. Please ensure that the object you are fixing to can handle this load. Ensure that appropriate methods and materials are used when affixing equipment to a wall.

The gateway should be installed with the antennas uppermost. This is key to ensuring the best radio performance for both the Flat-Mesh network and for the cellular connection.

2.1.1 Wall Bracket

The tags at the top and bottom of the bracket may be used to affix the gateway to a wall with screws (not supplied.)

The slots in the middle of the bracket may be used in conjunction with hose clamps (sometimes known as Jubilee clips) to secure the gateway to a horizontal or vertical pole.



Figure 2.1: Wall Bracket

2.1.2 Pole Mounting

Use a 13mm A/F spanner to clamp the gateway to a vertical pole. The standard clamp will accommodate pole diameters of XXX - YYY millimetres.



Figure 2.2: Pole Clamp

2.2 Power

The gateway has an internal Lithium-Ion battery which when fully charged will allow the device to operate for 2-3 weeks. For continued operation, you will have been supplied with either a solar panel or mains power supply.

The three-pin power input connector can be found at the bottom side of the unit, to the left of the human interface port.

Engage the power connector and turn the collar to lock in place.



Figure 2.3: Power connector

2.3 Antennae

There are two distinct antennae which must be connected to the correct N-type socket on the device. The antenna/socket pairs are labelled *2.4GHz* and *2G/3G*.

Check

It is very easy to accidentally cross-thread the antenna connection. Be sure to align the connectors properly before screwing together.



Figure 2.4: Antennas fitted to enclosure

DRAFT

Chapter 3

Access Port

The access port is located on the bottom of the gateway next to the power connector. Unscrew the clear plastic cover (by hand if possible to avoid damage.) There is a Micro USB socket, pushbutton and three indicators which can be used to give a basic indication of the function of the network.

When finished with the Access Port, replace the cover:

- Screw the cap into the port until the gasket touches the enclosure
- Tighten the cap an additional 45° (or $\frac{1}{8}$ of a turn)

3.1 Active Node Count

The pushbutton and indicators may be used to show the number of nodes currently active on the network. Press the button briefly, and the blue indicator will illuminate. Then count the number of orange and red flashes. The number of nodes active on the network is given by $OrangeFlashes \times 10 + RedFlashes \times 1$.

3.2 USB Port

The gateway provides a Micro USB B socket for attachment to a Host device, which can either be a personal computer or a tablet. Contact your supplier for a software package to use with this connection.

Chapter 4

Maintenance

The product should not require any maintenance after installation.

If the need to clean the product should arise, use only a damp cloth and mild detergent. Do not use any solvents as this may damage the enclosure.



Warning

Only service personnel authorised by the manufacturer may open the enclosure.

No user serviceable parts are located inside.

Chapter 5

Support

For assistance and support, contact your supplier or the manufacturer:

Senceive Limited

Phone: +44 (0) 207 731 8269

Email: support@senceive.com

Web: <http://www.senceive.com>

Appendix A

Export Restrictions

DRAFT

Appendix B

Software Licenses

The firmware used in this product is partly bound to the following licenses. To obtain the source code for the components which are bound to these licenses, please contact the manufacturer:

Senceive Limited

Phone: +44 (0) 207 731 8269

Email: support@senceive.com

Web: <http://www.senceive.com>

B.1 FreeRTOS

The FreeRTOS.org source code is licensed by the *modified* GNU General Public License (GPL), text provided below. A special exception to the GPL is included to allow you to distribute a combined work that includes FreeRTOS without being obliged to provide the source code for any proprietary components. See the licensing section of <http://www.FreeRTOS.org> for full details. The exception text is also included at the bottom of this file.

The FreeRTOS download also includes demo application source code, some of which is provided by third parties AND IS LICENSED SEPARATELY FROM FREERTOS.

For the avoidance of any doubt refer to the comment included at the top of each source and header file for license and copyright information.

This is a list of files for which Real Time Engineers Ltd are not the copyright owner and are NOT COVERED BY THE GPL.

1) Various header files provided by silicon manufacturers and tool vendors that define processor specific memory addresses and utility macros. Permission has been granted by the various copyright holders for these files to be included in the FreeRTOS download. Users must ensure license conditions are adhered to for any use other than compilation of the FreeRTOS demo applications.

2) The uIP TCP/IP stack the copyright of which is held by Adam Dunkels. Users must ensure the open source license conditions stated at the top of each uIP source file is understood and adhered to.

3) The lwIP TCP/IP stack the copyright of which is held by the Swedish Institute of Computer Science. Users must ensure the open source license conditions stated at the top of each lwIP source file is understood and adhered to.

4) Various peripheral driver source files and binaries provided by silicon manufacturers and tool vendors. Permission has been granted by the various copyright holders for these files to be included in the FreeRTOS download. Users must ensure license conditions are adhered to for any use other than compilation of the FreeRTOS demo applications.

5) The files contained within FreeRTOS\Demo\WizNET_DEMO_TERN_186\tern_code, which are slightly modified versions of code provided by and copyright to Tern Inc.

Errors and omissions should be reported to Richard Barry, contact details for whom can be obtained from <http://www.FreeRTOS.org>.

The GPL license text follows.

A special exception to the GPL is included to allow you to distribute a combined work that includes FreeRTOS without being obliged to provide the source code for any proprietary components. See the licensing section of <http://www.FreeRTOS.org> for full details. The exception text is also included at the bottom of this file.

GNU GENERAL PUBLIC LICENSE Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc. 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software—to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your

rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHTHOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the program's name and a brief idea of what it does.> Copyright (C) <year> <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License** as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type 'show w'. This is free software, and you are welcome to redistribute it under certain conditions; type 'show c' for details.

The hypothetical commands 'show w' and 'show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than 'show w' and 'show c'; they could even be mouseclicks or menu items—whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names: