





Package List




EN	DE
1. Mpow Bluetooth speaker	1. Mpow Bluetooth Lautsprecher
2. Charging cable	2. Ladekabel
3. 3.5mm audio cable	3. 3.5 mm Audiokabel
4. User manual	4. Benutzerhandbuch
FR	ES
1. Mpow haut-parleur Bluetooth	1. Mpow Altavoz bluetooth
2. Câble de charge	2. Cable de carga
3. Câble audio 3.5 mm	3. Cable de audio de 3.5mm
4. Manuel utilisateur	4. Manual de usuario
IT	JP
1. Mpow Altoparlante bluetooth	1. スピーカー
2. Câble de carga	2. 充電ケーブル
3. Câble de audio de 3.5mm	3. オーディオケーブル
4. Manuel de usuario	4. 取扱説明書

Specification





EN				
Pairing Name	Bluetooth Version	Signal Distance	Compatible Protocol	Input
Soundhot R6	V4.2	100 (R30m)	A2DP/AVRCP/HFP/HSP	SV=1A
DE				
Gerätemame	Bluetooth-Version	Signaldistanz	Kompatible Protokoll	Eingang
Soundhot R6	V4.2	100 (R30m)	A2DP/AVRCP/HFP/HSP	SV=1A
FR				
Nom	Version Bluetooth	Portée Du Signal	Contrat D'assistance	Contribution
Soundhot R6	V4.2	100 (R30m)	A2DP/AVRCP/HFP/HSP	SV=1A
ES				
Nombre De Dispositivo	Versión De Bluetooth	Distancia De La Señal	Protocolos Compatibles	Entrada
Soundhot R6	V4.2	100 (R30m)	A2DP/AVRCP/HFP/HSP	SV=1A
IT				
Nome Di Abbinamento	Versione Bluetooth	Distanza Segnale	Protocollo Di Compatibilità	Ingresso
Soundhot R6	V4.2	100 (R30m)	A2DP/AVRCP/HFP/HSP	SV=1A
JP				
デバイス名	Bluetoothバージョン	動作距離	対応プロトコル	入力
Soundhot R6	V4.2	100 (R30m)	A2DP/AVRCP/HFP/HSP	SV=1A

Diagram




EN	DE	FR
1. Power button	1. Power Taste	1. Bouton d'alimentation
2. Bluetooth / TWS Button	2. Bluetooth / TWS Taste	2. Bouton Bluetooth / TWS
3. Pause / Play	3. Pause / Wiedergabe	3. Pause / Activer
4. Volume - / Previous track	4. Lautstärke - / Vorheriger Titel	4. Volume moins / Piste précédente
5. Volume + / Next track	5. Lautstärke + / Nächster Titel	5. Volume plus / Piste suivante
6. Bass up	6. Bass up	6. la basse
7. Power indicator light	7. Power Led	7. Voyant d'alimentation
8. Bluetooth indicator light	8. Bluetooth-LED	8. Voyant Bluetooth
9. Microphone	9. Microfon	9. Microphone
10. Micro-USB charging port	10. Micro-USB Ladeanschluss	10. Port de charge Micro-usb
11. Aux-in Port	11. AUX-IN-Anschluss	11. Interface d'entrée audio Aux-in

ES	IT	JP
1. botón de encendido	1. Pulsante di accensione	1. 電源ボタン
2. Botón Bluetooth / TWS	2. Tasto Bluetooth / TWS	2. Bluetooth / TWS機能ボタン
3. Pausa / Reproducción	3. Metti in pausa / Riproduci	3.一時停止 / 再生ボタン
4. Volumen - / Canción anterior	4. Volume - / brano precedente	4. 音量 - / 前の曲
5. Volumen + / Siguiente canción	5. Volume + / brano successivo	5. 音量 + / 次の曲
6. Basso hasta	6. Bass up	6. バス
7. Luz indicadora de potencia	7. Spia di alimentazione	7. 電源インジケータ
8. Luz indicadora de Bluetooth	8. Indicatore luminoso Bluetooth	8. Bluetoothインジケータ
9. Microfono	9. Microphone	9. マイク
10. Puerto de carga micro-USB	10. Porta di ricarica micro-USB	10. micro-USB充電ポート
11. Interfaz de entrada de audio Aux-in	11. Porta Aux-in	11. aux入力ジャック




Tws Connection (True Wireless Stereo)

Step 1



Step 2



EN
Step 1: Double click the **3** of Speaker A to connect two Soundhot R6 speakers and enter into true wireless stereo sound mode.
Step 2: Connect Speaker A to your cellphone via Bluetooth. You are now able to connect 2 Soundhot R6 speakers via a single device for double volume.

DE
Schritt 1: Doppelklicken Sie **3** am Lautsprecher A auf um zwei Soundhot R6-Lautsprecher anzuschließen und in den echten kabellosen Stereo-Klangmodus zu wechseln.
Schritt 2: Verbinden Sie Lautsprecher A über Bluetooth mit Ihrem Telefon. Dann können Sie jetzt 2 Soundhot R6-Lautsprecher über ein einzelnes Gerät für doppelte Lautstärke anschließen.

FR
Étape 1 : Double-cliquez sur **3** de l'un des haut-parleurs pour connecter les deux soundhot R6 afin de former une stéréo gauche et droite.
Étape 2 : Connectez le haut-parleur A à votre téléphone portable par Bluetooth; vous pouvez maintenant connecter deux haut-parleurs Soundhot R6 à l'aide d'un seul appareil pour un double volume.


ES
Paso 1: Haga doble clic en **3** el altavoz A para conectar dos altavoces Soundhot R6 y entrar en el modo de sonido estéreo inalámbrico verdadero.
Paso 2: Conecte el altavoz A a su móvil a través de Bluetooth. Ahora puede conectar 2 altavoces Soundhot R6 a través de un solo dispositivo para doble volumen.

IT
Passo 1: Fare doppio clic sul **3** di Altoparlante A per collegare due altoparlanti Soundhot R6 ed entra alla modalità audio stereo wireless reale.
Passo 2: Collegare l'altoparlante A al cellulare tramite Bluetooth. Ora gli due altoparlanti possono riprodurre il suono del telefono contemporaneamente per il doppio volume.

JP
第1、二つのスピーカーの電源を入れます。一つのスピーカーの **3** ボタンを2回押します。
第2、スマホなど端末で一つのスピーカーとBluetooth接続します。この時、二つのスピーカーが自動的にペアリングして、TWSモードになります。

Switch Between 2 Bluetooth Devices

Step 1



Step 2



FCC Statement

Operation is subject to the following two conditions:
(1) This device may not cause harmful interference; and
(2) This device must accept any interference received, including interference that may cause undesired operation.
(3) This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Note:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

www.xmpow.com | support@xmpow.com
MPOW TECHNOLOGY CO., LTD
Copyright © MPOW Inc. All rights reserved.