



MODEL : BH437A

The diagram illustrates the components of the AirPods Pro (2nd generation) charging case and earbuds. It includes the following labels and their corresponding parts:

- LED light**: Points to the status light on the inside of the charging case lid.
- Type-C charging port**: Points to the USB-C port on the bottom of the charging case.
- MFB (Touch Control)**: Points to the touch sensor on the stem of the left earbud.
- LED light**: Points to the status light on the stem of the right earbud.
- Magnetic charging connectors**: Points to the contact points on the back of the right earbud.
- L/R logo**: Points to the 'L' logo on the back of the right earbud.
- Talking mic**: Points to the microphone on the back of the right earbud.

Mode 1

The diagram shows the device in its closed, open position, and then in its closed position with the LED light on. A red arrow points from the closed device to the open device. A red dashed line connects the LED light to the device. A red arrow points down to a button labeled "ON".

Mode 2

The diagram shows the device in its closed position with the LED light on, and then in its open position with the LED light on. A red arrow points from the closed device to the open device. A red dashed line connects the LED light to the device. A red arrow points down to a button labeled "ON".

pulsante MFB per 5 secondi sull'auricolare R/L per spegnerli.

Note: The earbud will reconnect to the paired device by priority. If you want to pair to the second smartphone, please disconnect Bluetooth on the paired smartphone.

IT: Estrarre gli auricolari, entrano automaticamente nella modalità di associazione quando le luce bianca e rosso iniziano a lampeggiare alternativamente, poi selezionare "Mpow M30"

Nota: l'auricolare si riconnetterà al dispositivo accoppiato per priorità. Se si desidera associare il secondo smartphone, disabilitare Bluetooth sullo smartphone associato.

Diagram illustrating the correct and incorrect ways to charge the earbuds:

- Correct Charging Method:** The charging case is connected to a power source (labeled "Output: DC 5V") via a USB cable. The case is shown open, revealing the earbuds inside.
- Incorrect Charging Method:** The earbuds are shown being connected directly to a power source, which is marked with a red "X" indicating it is incorrect.

www.xmpow.com | support@xmpow.com
MPOW TECHNOLOGY CO., LTD
 Copyright © MPOW Inc. All rights reserved.