




Item # 1013 136 345
Model # 91564

USE AND CARE GUIDE

1000 LUMEN RECHARGEABLE UTILITY LIGHT
WITH BLUETOOTH SPEAKER

Thank you. We appreciate the trust and confidence you have placed in Husky through the purchase of this lantern. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Husky!



Rating: INPUT 5V 2A MAX

Questions, problems, missing parts? Before returning to the store, call Husky Customer Service
8 a.m. – 7 p.m., EST, Monday-Friday
9 a.m. – 6 p.m., EST, Saturday

1-888-43-HUSKY
HUSKYTOOLS.COM

DISTRIBUTED BY:
HOME DEPOT
2455 PACES FERRY ROAD,
ATLANTA, GA 30339

Safety Information

Use caution and good judgment when operating your rechargeable utility light. Failure to adhere to the safety warnings and guidelines in this manual could result in body injury or property damage. Save this manual for future reference.



WARNING: Read and follow all warnings and instructions in this manual to avoid personal injury or property damage.



WARNING: To prevent damage to eyesight, never look into light when the light is on. Do not shine light into someone else's face.

- Never place the utility light face down when the light is on or is still hot from recent use. Doing so could burn/ignite surfaces such as seats, carpeting, and so forth, and cause major property damage. Always turn the utility light off when not in use.
- Always unplug the USB cable from the power source when not in use.
- To prevent serious damage to eyesight, never look into the light or shine into someone else's face.
- DO NOT touch the lens of the utility light when light is on or if it was recently on. The lens will be hot and could cause serious burns.
- DO NOT place the utility light in water. Keep all components dry and out of water at all times.
- DO NOT allow children to handle or operate this utility light.
- DO NOT use this product for anything other than its intended use.
- DO NOT charge or operate in close proximity of combustible or flammable materials.
- DO NOT charge battery in airtight enclosures.
- DO NOT attempt to charge or operate this utility light if USB, battery, bulb, or any part of the utility light is damaged or corroded.
- Only use charging devices that are provided with the LED utility light or its replacements.
- DO NOT disassemble or tamper with the battery.
- DO NOT dispose of the battery in fire as this may result in explosion.


Warranty

- This product is lifetime guaranteed to be free of defects in materials and workmanship from the date of purchase. If this product is defective, call 1-888-43-HUSKY or visit www.huskytools.com.
- Guarantee does not include normal wear and tear, USB cable, or rechargeable battery.

Pre-Operation

PACKAGE CONTENTS

Part	Description	Quantity
A	1000 Lumen Rechargeable Utility Light with Bluetooth Speaker	1
B	Type-C USB Charging Cable with Type-A Adapter	1



Operation

OPERATING THE UTILITY LIGHT



WARNING: Read and follow all safety warnings and instructions in the user manual before operating the utility light.



IMPORTANT: The Battery is ready to use when purchased. A fully charged battery will provide approximately 3 hours of continuous light in high mode. Do not allow the battery to discharge completely. When battery indicator is red flashing, it indicates low battery. Turn the utility light OFF and recharge the battery as soon as possible.

- Press the utility light power ON/OFF button to switch among high light, medium light, low light, red, red flashing and off.
- Memory Mode will activate after a mode has been left on for 10 seconds.


MODE CAPACITY


HIGH MEDIUM LOW


RED RED FLASHING OFF


BATTERY INDICATOR


100% to 75% 75% to 50% 50% to 25% 25% to 0%



OPERATING THE BLUETOOTH SPEAKER

Product Information	Specifications	Product Information	Specifications
Input	DC 5 V 2 A MAX	Bluetooth	5.4 Version
Battery	2600mAh, 9.62Wh	Charging Time	1.5 Hours
Bluetooth work distance	10 m	Run Time at high light	3 Hours



Hold for 2S to skip to next song.
Press to increase the volume

Hold for 2S to activate/inactivate the bluetooth via "Husky Bluetooth".
Indicator flash blue while pairing and solid blue once paired successfully.
Press to play or pause music.

Hold for 2S to skip to the previous song.
Press to decrease the volume.

Press to turn on/off interconnect function.


☐ Select a speaker to pair your device, and press the link button as a main speaker to connect with other speakers. The LED light be solid blue.

☐ Then turn on the bluetooth and press link button of the other speakers to automatically connect with main speaker. It will sound a prompt tone. The link button LED light will flash blue once connect with main speaker.
NOTE: The main speaker (Solid blue) can control all speakers.


☐ The bluetooth will automatically turn off when the bluetooth is not paired within 10 minutes or no further operation within 10 minutes after paired.


CHARGING THE RECHARGEABLE BATTERY

Step 1.




Step 2.





The LED indicator will turn red while charging.



The LED indicator will turn green when the battery is fully charged.

Care and Maintenance

- Always keep the battery fully charged when not in use. This will prolong the overall life of the battery.
- Do not subject the unit to excessive force, shock, dust, or extreme temperature.
- Do not tamper with the external and internal components of the unit.
- Clean your unit with a dry cloth. Solvent or detergent should never be used.
- Avoid leaving your unit in direct sunlight or in hot, humid, or dusty places.
- Keep your unit away from heating appliances and sources of electrical noise such as fluorescent lamps or motors.
- Only use a type-C USB cable to charge this product.

Troubleshooting

Problem	Possible Cause	Solution
The light is dim.	The light is not fully charged.	Make sure the light is fully charged.
	The light is in low mode.	Check mode setting.
The battery charging LED indicator does not turn on.	The USB charging cable is not plugged into the charging port properly.	Make sure the USB charging cable is well connected.
Cannot connect to the bluetooth.	The connection distance is more than 10m.	Make sure the distance is within 10m (33ft).
	Bluetooth is not activated.	Make sure bluetooth activated both speaker and your device.
Cannot innerconnect with other speakers.	Buletooth is not activated.	Make sure bluetooth is activated for each speaker.
	The connection distance is more than 10m.	Make sure the distance is within 10m (33ft).
	Every device was connected with Phone before.	Connect all lights first before connect to the phone bluetooth, or clean the phone bluetooth before to connect to one light, then other lights connect to the first light.

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement.
- The device can be used in portable exposure condition without restriction.