

1.Overview

1.1 Features

1.2 Specifications

1.3 Accessories

2.Device appearance

3.Wiring Diagram

4.LED indications

Green LED(GSM indicator)

Red LED (Power indicator)

Blue LED(GPS indicator)

5.Hardware Operation

(1)SIM Card installation

After receiving this command, the device will reboot after 20 seconds

8.13 SOS

8.14 Wi-Fi hotspot

9.Platform & APP

9.1 Login service platform

9.2 Download APP





After receiving this command, the device will reboot after 20 seconds

2. Via platform

2. Via SMS

8.8 Oil cut-off

8.9 Restoring Oil

8.10 Over Speed Alarm

8.11 Restore to factory setting

8.12 Reboot device

6.Device Installation

7.Wiring

8.Operations & Functions

8.1 SOS number

8.2 APN setting

8.3 Server setting

8.4 Center number

8.5 Upload positioning data regularly

8.6 Arming time setting

8.7 Wire cut-off alarm

8.8 Oil cut-off

8.9 Restoring Oil

8.10 Over Speed Alarm

8.11 Restore to factory setting

8.12 Reboot device

Maintenance Record

CE Caution:

FCC RF Exposure Information and Statement

FCC Warning

10. Warning

11. Troubleshooting

Warranty instructions and service

12. Troubleshooting

4G Vehicle GPS Tracker

User Manual

(Version 1.0)

One side of the device is marked "THIS SIDE TOWARDS SKY". place the unit upside down will result in connection issues.

Avoid placing the device somewhere that metal will be covering it up.