



Internal Photographs

EUT - Open View



EUT – PCB View

Antenna Location



EUT – PCB View

