

EHE-PU25BK headphone user manual

No.	Function	Status	Operation	Prompt Tone	Indicator Light
1	Power On	Powered Off	Press & hold ON/OFF button for 1 second	power on	Blue light stays on for 1s → Blue/red lights flash
2	Powered Off	Power On	Press & hold ON/OFF button for 2 seconds	power off	Red light flashes twice
3	Enter Pairing Mode	Powered Off	Press & hold ON/OFF button for 2s	pairing	Blue/red lights flash alternately
4	Phone Connected	Standby	\	connected	Blue light stays on
5	Phone Disconnected	Standby	\	disconnected	Blue/red lights flash
6	Auto Reconnect	Powered Off	Press & hold ON/OFF button for 2s	connected	Blue light stays on
7	Out-of-Range Disconnect	Connected/Standby	Automatic	disconnected	Blue/red lights flash alternately
8	In-Range Reconnect	Disconnected (within 5m)	Return to effective range	connected	Blue light stays on
9	Redial Last Number	Standby/Playback	Double-click ON/OFF button	/	Blue light flashes every 3s
10	Force Disconnect	Connected	Press & hold V+/V- buttons for 3s	disconnected	Blue/red lights flash alternately
11	Incoming Call	During Call	/	Default phone	Blue light flashes every 3s
12	During Call	During Call	/	/	Blue light flashes every 3s
13	Answer Call	Incoming Call	Single-click ON/OFF button	/	/
14	End Call	During Call	Single-click ON/OFF button	"Beep"	/
15	Reject Call	Incoming Call	Press & hold ON/OFF button for 2s	/	/
16	Play/Pause Music	Standby/Playback	Single-click ON/OFF button	/	The blue light stays on when the music pauses The blue light lights up every 3 seconds while music is playing
17	Next Track	Standby/Playback	Press & hold V+ button for 2s		
18	Previous Track	Standby/Playback	Press & hold V- button for 2s		
19	Volume Up	Standby/Playback	Single-click V+ button	"Beep-beep" (max volume)	
20	Volume Down	Standby/Playback	Single-click V- button	"Beep-beep" (min volume)	
21	Low Battery Alert	Standby, call, music	Battery ≤3.4V; Automatic shutdown	"Battery Low" every 20s	Red light flashes every 3s (Blue light off)
22	Auto Shutdown (Low Battery)	Standby, call, music	Battery ≤3.4V; Automatic shutdown	/	/
23	Charging pilot	Charging			Red light stays on
24	Fully Charged	Charging			Blue light stays on
25	Shutdown While Charging	Connected	Auto shutdown when charging starts	/	
26	Wired Mode Shutdown	Connected	Plug in audio cable	/	
27	Auto Shutdown (Idle)		No connection for 5 minutes	power off	
28	ANC On (Noise Cancelling)	Bluetooth On	Lightly press the ANC button to enter transparency mode, and then lightly press the ANC button to turn it off	ANC ON	Green light stays on
29	ANC Off	ANC On (Bluetooth)	Press ANC button once	ANC OFF	Green light off
30	Transparent Mode	Bluetooth On	Press ANC button once	Transparent mode	Green light stays on

31	Activate Siri	Standby/Playback	Press the ON/OFF button three times	/	The blue light lights up every 3 seconds

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC INSTRUCTIONS FOR A CLASS B DIGITAL DEVICE OR PERIPHERAL

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.