

项目：Haylou X1S	
品名：英文说明书	
料号：	
版本：A	

更新日志：

图档识别



图档比例：1：1

技术要求

1. 尺寸：55x80mm
2. 材质：70g书写纸
3. 印刷：专色印刷
4. 工艺：风琴折
5. 公差：±1mm
6. 备注：

注：所有材料必须符合ROHS规定。

资料确认

品牌：	电子：
市场：	品质：
软件：	包装：



东莞市猎声电子科技有限公司
Dongguan Liesheng Electronic Co., Ltd.

	Overview	How to Wear	How to Charge For first time use, please remove the isolation film on the charging contacts of both earbuds. Then fully charge the charging case and earbuds. Plug charging cable to charge the earbuds and the charging case at the same time. When the charging case is not fully charged, the LED flashes red quickly. After fully charged, the LED lights up white for a long time.	How to Pair Automatic connection: Take the earbuds out, they will complete TWS re-connection within 5s and enter the pairing state; or they will enter monaural pairing state after 5s. Open device Bluetooth and search for "X1S", then click it to connect. Put the earbuds back into the charging case and repeat the above operation if the connection fails. After the first connection, the earbuds can be automatically connected to the last paired device when powering on (Bluetooth needs to be turned on).
			Power-on Take the earbuds out from the charging case, they will automatically power on. Power-off 1. Put the earbuds back into the charging case. If the charging case has power, the earbud will automatically power off. If the charging case has no power, the earbud will maintain the current state. 2. The earbuds power off outside the charging case: they will automatically power off if not connected to the device within 3 minutes.	When pairing, the green light of the charging case continuously flashes.

Functions - Double on any MFB: In Music mode, Play/Pause music - Triple click on the right MFB: In Music mode, Skip track forward - Triple click on the left MFB: In Music mode, Skip track backward - Press and hold 2s on any MFB: In paired mode, Turn on/off gaming mode - Double on any MFB: Call time / For incoming call, Answer / Hang up a call - Press and hold 2s on any MFB: Call time, Reject a call	Restore Factory Settings 1. Make sure the charging case has power, put the earbuds into the charging case, and press the button under the box for 6s. The earbuds will restore factory settings when there is a prompt tone. 2. After resetting, put the earbuds into the charging case and close the lid, then open the lid and take them out again. 3. Clear phone pairing record and follow the pairing steps to complete Bluetooth connection. Audio only Outputs from Single Earbud It's unusual indeed, please refer to the following operation steps if the situation occurs. 1. Put the earbuds back into the charging case, and then take them out again to connect. 2. Refer to the reset steps to reconnect the Bluetooth device. Other Charging Problems 1. When the charging case is out of power, the earbuds cannot be charged and keep the original connecting status. 2. The LED flashes solid white when the charging case is fully charged.	Package Overview Earbuds, charging case, Charging cable, user manual. Earbud model: X1S Earbud name: True Wireless Earbuds Basic Parameters(earbuds) Operation range: 10m (open space with no obstacle) Battery capacity: 30mAh(single earbud) Charging time: approx. 2h Playing time: approx. 5h Standby time: approx. 60h Input parameter: 5V ≈ 50mA Battery type: Li-ion Bluetooth version: V5.3 Basic Parameters(charging case) Input parameter: 5V ≈ 500mA Output parameter: 5V ≈ 100mA Charging time: approx. 1.5h Battery type: Li-ion Daily maintenance Please do not shower with earbuds. Do not wear them in rainy day. Do not leave them in washing machine or other extreme situations. Clean them with dry cloth.	Caveats Warning 1. Do not disassemble, repair or modify the product for any reason, as this may cause fire or even completely destroy the product. 2. Do not expose the product to environments where the temperature is too low or too high (below 0°C or above 45°C). 3. Keep the indicators away from the eyes of children and animals while using the earphones. 4. Do not use this product during thunderstorms. Thunderstorms may cause the product to malfunction and increase the risk of electric shocks. 5. Do not wipe and clean the earphones or their case with alcohol or other volatile liquids. 6. Avoid any contact with liquids. Note 1. Please read this user manual carefully before using the product and please properly store it. 2. When using for the first time, please fully charge this product. 3. Please charge the product, in case it has not been used over two weeks. 4. Please use certificated charger. 5. Do not wear earphones for a long term to protect your hearing. 6. Do not wear earphones in any situations with potential risks as wearing them may reduce your perception to the outside world.	FCC Statement: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) the device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter. Radiation Exposure Statement The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.	FCC ID: 2AMQ6-X1S Manufacturer: Dongguan Liesheng Electronic Co., Ltd. Address: Room 401-410, Building 1, No. 86 Hongtu Road, Nancheng District, Dongguan City, Guangdong, China
--	--	---	---	--	--