

说明书：751-110000-000  
80g 双胶纸 / 四色双面印 / 折页 / 成品尺寸：64\*60mm

400-MAWBT204BK\_GMAWBT204BK\_manual\_表面\_特色 1 色 (PANTONE 320C)+BK

Wireless Handy Mouse

Manual/取扱説明書/使用说明书

Wireless

Bluetooth

400-MAWBT204BK | GMAWBT204BK

Manual

FCC ID: 2AMSUGMAWBT204BK

DD: D088503

Ver 2.0

Receiver FCC ID: 2AMSUGMAWBT204BKRC  
Receiver Model: GMAWBT204BK-RC

1. Opening

Thank you for purchasing this Wireless Handy Mouse.

2. Caution

- The company is not liable for any damages, such as live motion defects, data loss, etc., caused by using this product or software.
- This product is not guaranteed to be compatible all devices supporting Bluetooth.
- This product is intended for use in general workplaces and homes. The company does not assume responsibility in the event of damages caused by using in any other places.
- Refrain from using in environments where medical instruments and systems directly or indirectly related to human life are required, and where a high level of safety and responsibility is required.
- Refrain from using directly or indirectly with equipment and computer systems in which a high level of safety and responsibility is required.
- Do not use this product on airplanes as it may interfere with the airplane communication system.
- Please consult your doctor before using this product if you use a pacemaker or other medical device.

3. Warnings Regarding Health

Operating the mouse, trackball, and keyboard for long periods of time can lead to pain or numbness in hands, arms, neck, shoulders, etc. Serious damage may be incurred if such use is repeated. If you feel pain or numbness while operating the mouse or keyboard, stop using it immediately and consult a doctor if necessary. Take regular breaks from daily computer work to avoid strain on hands, arms, neck, shoulders, etc.

4. Specifications

<Bluetooth specifications>

Interface Bluetooth 5.0 Class2 | Profile HOGPHID over GATT Profile

Frequency Range 2.402~2.480GHz

<2.4GHz wireless specifications>

Wireless System 2.4GHz RF radio wave system \*The ID between the mouse and the receiver is fixed.

<Common specifications>

Resolution 2000 DPI | Battery capacity 500mAh

Continuous operating time: approx. 15 hours.

Continuous standby time: approx. 200 hours. Usable days: approx. 62 days.

\*Based on 8 hours of computer work per day, with 5% mouse operation.

\*When fully charged

The data are the internal test results of the company, and the actual usage time shall be subject to the product received.

\*Note that battery performance will gradually deteriorate over time.

Communication Range Wooden desk (nonmagnetic material) / approx. radius 10m, Steel desk (magnetic material) / approx. radius 2m

Battery Performance

Left button, Right button, Up button, Down button, Play/Pause button, Previous button, Next button, Volume + button, Volume - button

Size・Weight

Mouse: W57.8×D114.3×H56.3mm; approx. 48g

Receiver: W18.4×D19.4×H6.1mm; approx. 2g

5. Compatible Models

Windows (DOS/V) PC / tablet, Apple Mac series / iPad / iPhone / Chrome OS PC / Android smartphones and tablets \*Models that support Bluetooth5.0 HOGP or have a USB A port.

6. Compatible OS

Windows 11~10, macOS 14~13~12, Chrome OS, Android 13~14, iOS 14~17, iPadOS 14~17

7. Name of Parts

1 Left button

2 Up button

3 Right button

4 Cursor stick

5 Down button

6 Wheel

7 Charging port

8 Power/Connection switch button

9 Notification LED

10 Volume + button

11 Previous button

12 Next button

13 Play/Pause button

14 Volume - button

15 Receiver storage cover

16 Receiver

17 Type-C charging cable

<Inside the cover>

15

16

17

8. Charging Method

1. Connect the mouse with the included charging cable. Connect the cable as shown in the figure. When connected, the notification LED will blink.

2. When the notification LED turns off, charging is complete. Unplug the charging cable.

\*Charging time is about 3 hours.

\*When the remaining battery charge is low, the notification LED will flash rapidly.

■ Sleep Mode

If the mouse is not operated for a certain period of time even when the power switch is ON, the mouse will enter the sleep mode. The mouse will recover from the sleep mode by clicking the mouse. The operation may become unstable immediately after recovery.

9. Connection with Mouse

<How to connect to Bluetooth devices>

1. Turn on the power of the connected device and boot the OS completely.

2. Add the Bluetooth device from the settings screen on the connection side.

3. Switch the mouse's power/connection switch to BT.

4. Press and hold the left and right buttons of the mouse at the same time. The notification LED will blink faster and the mouse will enter pairing mode.

5. \*SANWA MAWBT204\* will be displayed on the pairing screen of the connected device, so complete the connection.

● About the next connection

When the power/connection switch of the mouse is set to BT, the connection is made automatically.

<How to connect to 2.4GHz wireless devices>

1. Turn on the power of the connected device and boot the OS completely.

2. Remove the receiver storage cover on the back of the mouse and take out the receiver.

3. Connect the receiver to the USB A port of the connected device.

4. Switch the mouse's power/connection switch to 2.4G. The notification LED will flash green slowly.

5. The connection will be completed automatically.

10. How to use

<Mouse operation>

The left button for normal clicking, and the right button for right clicking.

Press the up button to page up and the down button to page down.

Tilt the cursor stick to move the cursor.

Press and hold the left button for about 3 seconds to activate the drag & drop mode.

Left-click to cancel the drag & drop mode.

<Usage with PowerPoint and Keynote>

Press the up button once: Page up (to the previous slide)

Long press the up button: Activate/Cancel full screen

Press the down button once: Page down (to the next slide)

Long press the down button: Blackout/Cancel blackout

<Using with media player>

Various operations can be performed with the media operation buttons.

\*May not be used depending on your environment.

11. Troubleshooting

Q: How do I change DPI settings?

A: For more control, adjust settings on your computer.

Mac:

1. Open "System Preferences," then "Mouse."

2. Adjust "Tracking Speed." Optionally, disable "Pointer Acceleration" under "Advanced."

Windows:

1. Open Control Panel, then search for "Mouse."

2. Adjust the "Speed" slider under "Pointer Options."

12. Warranty Term

1 year

13. Inquiries

EN: support@sanwa.com

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

1. はじめに

この度は、ワイヤレス/ハンディマウスをお買い上げいただき、誠にありがとうございます。

2. 注意

- 本製品およびソフトウェアを使用したことによって生じた動作障害やデータ損失などの損害については、弊社は一切の責任を負いかねます。
- 本製品はBluetooth対応のすべての機器との接続動作を保証したものではありません。
- 本製品は一般的な職場や家庭での使用を目的としています。本書に記載されている以外での使用にて損害が発生した場合には、弊社は一切の責任を負いません。
- 医療機器や人命に直接的または間接的に関わるシステム、高い安全性や信頼性が求められる環境下で使用しないでください。
- 高い安全性や信頼性が要求される機器や電磁システムなどとの直接的または間接的に関わるシステムでは使用しないでください。
- 飛行機の通信システムを妨害する恐れがありますので、飛行機で本製品を使用しないでください。
- ペースメーカーなどの医療機器を使用している方は医師に相談の上ご使用ください。

3. 健康に関する注意

マウスやキーボードを長時間操作すると、手や腕や首、肩などに負担が掛かり痛みや痺れを感じることがあります。そうなった場合は直ちに操作を中止し、場合によっては医師に相談してください。また日常のパソコン操作では定期的に休憩を取り、手や腕や首、肩などに負担が掛からないように心がけてください。

4. 仕様

<Bluetooth仕様>

インターフェース Bluetooth5.0 Class2 | プロファイル HOGPHID over GATT Profile

周波数範囲 2.402~2.480GHz

<2.4GHzワイヤレス仕様>

ワイヤレス方式 2.4GHz RF電波方式※マウスとレシーバー間のIDは固定です。

共通仕様

分解能 2000count/inch | 電池容量 500mAh

連続動作時間(約)75時間

連続待機時間(約)2000時間、使用可能日数(約)62日

\*1日8時間(1/3コン)を使用し、マウス操作も5%程度行う場合。(満充電時)

\*自然放電等を考慮しない。弊社計算値であり保証値ではありません。

\*使用開始により、徐々に性能が低下します。予めご了承ください。

最大範囲(送信機性能/受信機性能)10m、ステーション(受信機性能/送信機性能)2m

通信用電圧

左ボタン、右ボタン、上ボタン、下ボタン、再生一時停止ボタン、前ボタン、次ボタン、音量+ボタン、音量-ボタン

マウス(W57.8×D114.3×H56.3mm・約48g)

レシーバー(W18.4×D19.4×H6.1mm・約2g)

5. 対応機種

Windows搭載(DOS/V)パソコン、タブレット、Apple Macシリーズ・iPad・iPhone、Chrome OS搭載パソコン、Android搭載スマートフォン、タブレット

\*Bluetooth5.0 HOGPに対応、またはUSBポート(Aコネクタ)を持つ機種。

6. 対応OS

Windows 11~10, macOS 14~13~12, Chrome OS, Android 13~14, iOS 14~17, iPadOS 14~17

7. 各部の名称

1 左ボタン

2 上ボタン

3 右ボタン

4 カーソルスティック

5 下ボタン

6 ホール

7 充電ポート

8 電源・接続切替スイッチ

9 お知らせLED

10 音量+ボタン

11 前ボタン

12 次ボタン

13 再生一時停止ボタン

14 音量-ボタン

15 レシーバー収納カバー

16 レシーバー

17 USB-C 充電ケーブル

<カバー内側>

15

16

17

8. 充電方法

1. マウスに付属の充電ケーブルを接続し充電します。

下図のようにケーブルを接続してください。接続すると、お知らせLEDが点滅します。

2. お知らせLEDが消灯したら充電は完了です。充電ケーブルを抜いてください。

\*充電時間は約3時間です。

\*電池残量が少なくなると充電お知らせLEDが速く点滅します。

■スリープモード

電源スイッチがONの場合でも一定時間マウスを操作しないとマウスがスリープモードに移行します。スリープモードはいずれかのボタンを押すことで解除されます。復帰後は動作が不安定になる場合があります。

9. 接続方法

<Bluetooth機器との接続方法>

1.接続機器の電源をONにして、OSを完全に起動します。

2.接続側の設定画面からBluetooth機器の追加操作を行います。

3.マウスの電源・接続切替スイッチをBTに切替えます。

お知らせLEDがゆっくり青色点滅します。

4.マウスの左ボタンと右ボタンを同時に長押しします。

お知らせLEDの点滅が速くなり、ペアリングモードに移行します。

5.接続機器のペアリング画面に「SANWA MAWBT204」と表示されますので、接続を完了させます。

●次回からの接続について

マウスの電源・接続切替スイッチをBTにすると自動的に接続されます。

<2.4GHzワイヤレス機器との接続方法>

1.接続機器の電源をONにして、OSを完全に起動します。

2.マウス背面のレシーバー収納カバーを取出して、レシーバーを取出します。

3.レシーバーを接続機器のUSB Aポートに接続します。

4.マウスの電源・接続切替スイッチを押して2.4Gに切替えます。お知らせLEDがゆっくり緑色点滅します。

5.自動的に接続が完了します。

10. 使用方法

<マウス操作>

・左ボタンで通常クリック、右ボタンで右クリックできます。

・上ボタンでページアップ、下ボタンでページダウンできます。

・カーソルスティックを傾けるとカーソルが移動します。

・左ボタン約3秒長押ししてドラッグ&ドロップモードが起動します。

・左クリックでドラッグ&ドロップモードが解除されます。

<PowerPoint、Keynoteでの使用>

上ボタン1回押し: ページアップ(前のスライドへ)

上ボタン長押し: フルスクリーン起動/解除

下ボタン1回押し: ページダウン(次のスライドへ)

下ボタン長押し: ブラックアウト/ブラックアウト解除

<メディアプレーヤーでの使用>

メディア操作ボタンで各種操作できます。

\*ご使用の環境により使えない場合があります。

11. 「故障かな...」と思ったら

Q: DPI設定を変更するにはどうすればいいですか？

A: コンピューターの設定を調整します。

Mac:

1. 「システム環境設定」を開き、「マウス」を選択する。

2. 「調整」>「追従速度」、如有必要、点击「高級」>「詳細」で「ポインターの加速」をオフにする。

Windows:

1. コントロールパネルを開き、検索ボックスに「マウス」と入力する。

2. 「ポインター」のオプション」タブで「速度」スライダーを調整する。

12. 保証書

サンワサプライ株式会社

型番: 400-MAWBT204BK | シリアルナンバー:

お客様・お名前・ご住所・TEL

販売店名・住所・TEL

担当者名

保証期間 1年 | お買い上げ年月日 年 月 日

サンワサプライ株式会社

〒700-0825 岡山県山崎区西園1-10-1 TEL:086-223-6680 FAX:086-235-2361

8. 充電方法

1. 用附帯のType-C充電电线直接连接进行充电。

如配所示连接充电线。连接后，指示LED将闪烁。

2. 当指示LED灯灭时，充电完成。请拔除充电线。

\*充电时间约为3小时。

\*电池剩余电量不足时，指示LED将快速闪烁。

■休眠模式

即使电源开关处于开启状态，若一段时间未操作鼠标，鼠标将进入休眠模式。通过点击鼠标，可恢复至工作状态。恢复初期光标可能有些延迟。

9. 接続方法

<蓝牙设备连接方法>

1. 打开待连接设备的电源，并完全启动操作系统。

2. 在待配对端的设置页面添加蓝牙设备。

3. 将鼠标的电源・设备切换键切换至BT。

指示LED缓慢闪烁蓝灯。

指示LED快速闪烁。

进入蓝牙配对模式。

5. 将配对的设备上会显示蓝牙名称「SANWA MAWBT204」。

请按照设备上的操作方法完成配对。

●关于下次连接

当鼠标的电源・设备切换键切换至BT时，就会自动连接。

<2.4GHz无线设备连接方法>

1. 打开连接设备的电源，并完全启动操作系统。

2. 取下鼠标背面的接收器收纳盒，取出接收器。

3. 将接收器连接到设备侧面的USB A端口。

4. 将鼠标的电源・设备切换键切换至2.4G。

指示LED缓慢闪烁绿灯。

5. 连接自动完成。

10. 使用方法

<鼠标操作>

鼠标左键为普通单击，右键为右键单击。

鼠标向上翻页键为向上翻页，向下翻页键为向下翻页。

倾斜光标键可移动光标。

长按左键约3秒，可启动拖放模式。

左键单击可取消拖放模式。

<在PowerPoint和Keynote中使用>

按1次向上翻页键: 向上翻页 (返回上一幻灯片)

长按向上翻页键: 全屏模式启动/取消

按1次向下翻页键: 向下翻页 (进入下一幻灯片)

长按向下翻页键: 进入黑屏/取消黑屏

<在多媒体播放器中使用>

多媒体操作按键可以执行多种操作。

\*根据使用环境，也可能无法进行操作。

11. 故障诊断

Q: 如何更改 DPI 设置？

A: 调整电脑设置。

Mac:

1. 打开“系统偏好设置”，选择“鼠标”。

2. 调整“跟踪速度”。如有需要，点击“高级”并关闭“指针加速”功能。

Windows:

1. 打开控制面板，在搜索框中输入“鼠标”。

2. 在“鼠标选项”标签下，调整“速度”滑块。

12. 保修期限

1 年

13. 产品咨询

CN: support-cn@sanwa.com

SANWA®