

图纸名称：遥控桌面三脚架说明书

物料编号：3T-P016

成型尺寸：85x120mm

展开尺寸：240x340mm

材质：100g双胶纸双面印刷/折页

正面

备注：折痕虚线不印刷



SIRUI, Capturing Your Imagination!

INSTRUCTIONS

Remote Control Tripod 3T-R

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2AATD3-TF-R

Package Includes


Please check carefully whether all the following items are included in the package before using. If any are missing, please contact customer service or your agent.



Remote Control Tripod



USB Receiver



type-C USB Cable



Instructions

Buttons



1/4" 20 Mounting Screw



QR Plate



Ball



Friction Control Knob



Battery Level and Charging Indicator



Focus/Photo Button



ON/OFF Button



Charging Port



Non-Slip Silicone Sleeve



Bluetooth Connection Indicator



TW: Zoom Button




Movie Button




C1 Button

USB Receiver




USB Receiver

Detachable Remote Control




Remote Control

Focus and photo buttons are combined into one. Tap to focus and press to take a photo.



Focus/Photo Button

The vertical notch on the left makes 90° vertical shooting possible. 25° tilt is available in any direction.



Vertical Shooting

Installation or Removal of the QR Plate

1.Press hard the fixed block and the active plate to the middle until the clamp is released, then take out the QR plate. Let go of your fingers after the QR plate is removed, then the clamp will spring back to its original position.



Clamp

2.Press hard the fixed block and the active plate to the middle until the clamp is released, then install the QR plate. Let go of your fingers after the QR plate is installed, then the clamp will spring back to its original position.



QR Plate Clamp

背面

备注：折痕虚线不印刷




影像随心 思锐随行

使用说明


遥控桌面三脚架 3T-R

产品清单


使用本产品前, 请仔细检查产品包装内是否含以下所有物品, 若有缺失, 请联系客服或您的代理商。



遥控桌面三脚架



接收器



USB type-C 充电线



说明书

按键说明



UNC 1/4" 20相机螺丝



快装板



球体



球体阻力调节旋钮



电量及充电指示



对焦/拍照按钮



开/关机按钮



充电接口



硅胶防滑套



蓝牙连接指示灯



TW:变焦推杆按钮




录像按钮




C1:自定义按钮

接收器




接收器

遥控器可拆卸




遥控器

对焦/拍照按钮为双向开关, 轻按对焦, 重按拍照。



对焦/拍照按钮

球体可以单方向90度竖拍, 其它方向任意使用角度25度



竖拍

快装板取出或者安装

1.取出快装板时用食指和大拇指同时用力向中间用力按压, 直到锁紧块松开可以取出快装板。在取出快装板后再松开, 此时锁紧块会自然复位。



锁紧块

2.安装快装板时用食指和大拇指同时用力向中间用力按压, 直到锁紧块松开可以放入快装板。在放入快装板后松开手, 此时锁紧块会自然复位锁住快装板。



快装板 锁紧块

制图：谢亮

审核：

批准：