


Bluetooth Headset

USER MANUAL



Please read this guide carefully before use and keep it for future use

CHARGING BOX : PACKING LIST

CHARGING BOX

earphone quantity digital display

Type-C Charging Interface

EARPHONE

Volume+ Previous Song

Volume- Next Song

Switch/answer/play/pause button

multi-function button

Mic

Indicator light

Receiver

Charging Contact

Type-C Charging Cable

The package includes real wireless earphone and charging box, charging cable, and instruction manual

BASIC PARAMETERS

Bluetooth version: V5.2 + EDR
Support protocol: A2DP/AVRCP/HSP/HFP
Transmission distance: within 10m range
Earphone battery capacity: 100mAh
Charging box battery capacity: 600mAh
Earphone working hours: 10H
Charging box time: can charge the earphone about 2 times
Standby time: 100H
Charging time: 2H
Charging interface: Type-C


EARPHONE BUTTON OPERATION

Power on: 1. In the shutdown state, press and hold the MFB key for about 2 seconds
2. Take out the headset from the charging bin and the headset will start automatically
Shutdown: 1 Press and hold the multifunction key for about 4 seconds
2. Put the headset into the charging bin
Answer/end a call: click the multi-function button
Play music/pause: click the multi-function button
Reject the call: long press the multi-function button for about 2 seconds
Redial: double-click the multi-function button quickly
Voice dialing: long press the multi-function button for about 2 seconds to turn on voice dialing
Previous song: Long press the volume button + about 2 seconds
Next song: Long press the volume button-about 2 seconds
Prompt tone switching: Three hit multifunction key
Reset: In the power off state, press and hold the MFB button for 8 seconds until the red and blue lights are always on for 1S
Game mode: in the connected state, press the MFB button three times to enter the game low delay mode
Music mode: in the game mode, press the MFB button three times to exit the game low delay mode

CHARGING INSTRUCTIONS


Headphone charging:

Put the headset into the charging compartment:
1. During charging, the red light of the headset is always on and the display screen of the charging bin is always on;
2. After being fully charged, the earphone lights out and the display screen goes out.



Charging in the charging box:

- When Type-C charges the charging cabin, the display screen flashes slowly during charging, and when fully charged, the display screen displays 100.



Low power alarm of charging box:

- When the display screen displays the value of 10, it will prompt that the power of the charging bin is not, and the display screen will flash slowly



TWS HEADSET TEAM

TWS headset s team (without charging cabin):

By default, you will enter the TWS headset team after startup. After successful pairing, the red and blue lights of the main ear flash alternately, and the lights of the auxiliary ear are not on.

TWS headset team (with charging cabin):

Take out the left and right earphones in the charging cabin and form a team automatically. After successful pairing, the red and blue lights of the main ear flash alternately, and the lights of the auxiliary ear are not on.

TWS headset Regrouping:

When the left and right headphones are turned off, long press the MFB key for 8 seconds (restore the factory setting) until the red and blue lights are always on. Turn on the left and right headphones again to form a team. After the automatic pairing is successful, use the mobile phone to search for the pairing name.

Headset pairing



1. Press and hold the multifunction button for about 4 seconds, at this time, the indicator lights flash red and blue, the headset goes into pairing.



Compatible with Bluetooth on the headset or other products.

2. Turn on your phone bluetooth function,search for the model name of headphones, then click it will automatic ally connect.

DISCONNECT THE HEADSET FROM THE PHONE

To disconnect the headset from the mobile phone (for example, connect the mobile phone to other Bluetooth devices), use any of the following methods:

- Turn off the headset
- Use the phone's Bluetooth function to disconnect the headset from the phone

EARPHONE WEAR

According to the specific position of the earphone wearing, please adjust the ear-hook to make you comfortable.

QUESTIONS

•Hear the sound of [Kaha]?

Since the protocol distance of bluetooth is in an open area, it can reach 10M in barricade-free condition. Human body is also the biggest interference obstacle for bluetooth headset. We suggest that you put the headset on the same side of the phone to achieve the best use effect.

•There is no sound from the headset?

Make sure that the headset is turned on and fully charged.

•Can't connect the mobile phone and earphone?

1. Please make sure the headset is connected to the mobile phone.
2. Please make sure that the Bluetooth device of the mobile phone is enabled.
3. Please make sure that the headset is within 10 meters of the mobile phone, and there are no obstacles, such as walls or other electronic devices

•If the above steps fail to solve the problem, please try the following methods:

A. Recharge the headset.
B. Reboot the phone.
C. Turn on the Bluetooth function of the mobile phone and delete the previous pairing history!
D. Reconnect the Bluetooth headset to the mobile phone!

⚠ PRECAUTIONS

(1) Do not put the headset on the safety air bag in the car, because when the safety air bag is out, it may cause serious injury
(2) Do not allow children to play with this headset, as the small parts may suffocate the children.
(3) In hospitals, blasting sites, or potentially explosive environments, users may be required to turn off electronic equipment and radio equipment. Please pay attention to the relevant instructions when entering the specified space.
(4) Please turn off the earphones before boarding the plane. The earphones cannot be used in the plane.
(5) In order to better protect your hearing, please do not volume up too much.
(6) Do not try to make any modification or disassembly of this headset.
(7) Do not use this product in damp or rain.
(8) Do not clean the headset when it is charging. Separate the headset and charger before cleaning.

⚠ NOTE

There is a danger of explosion if the battery is incorrectly replaced
Only use the same type or equivalent type of battery to replace
A warning that the battery (battery pack or combination battery) must not be exposed to the environment such as sunlight, fire or similar overheating.

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

PRODUCT QUALITY WARRANTY CARD

*This warranty card must be provided when receiving the service, please keep it properly!

Model	
Commodity origin	
User name	
Sales location	
Sale date	
Seller's name	
Seller's contact number	
Repair Record	

Copyright © 2024 All Rights Reserved