


DS11-24 说明书
尺寸: 100mm x 150mm
80g书写纸, 黑白印刷, 折页, 双面印
料号:

USER MANUAL

Model: VENTOTWO

BOOKSHELF SPEAKER



IMPORTANT
Please read this manual carefully before operating the SPEAKER, keep this user manual for further reference.

Important Safety Instructions



1. Read these Instructions.
2. Keep these Instructions.
3. Heed all Warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus including amplifiers that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Unplug this apparatus during lightning storms or when unused for long periods of time.
13. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Special note: When placing your unit on a lacquered or natural finish, protect your furniture with a cloth or other protective material.

Additional Warnings:
The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on apparatus.
L'appareil ne doit pas être exposé aux écoulements ou aux éclaboussures et aucun objet ne contenant de liquide, tel qu'un vase, ne doit être placé sur l'objet.

Caution marking is located at the rear or bottom of the apparatus.
Attention marquage est situé sur le panneau arrière ou inférieur de l'unité.
The marking information is located at the rear or bottom of apparatus. Le marquage est situé sur le panneau arrière ou inférieur de l'unité.

FCC Warnings

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



This symbol indicates that this product incorporates double insulation between hazardous mains voltage and user accessible parts.

1What's in the box

Make sure you read all the safety information before you use this product.



SPEAKER main unit



Power adapter



AUX audio cable




USB cable



User Manual

2Overview



LED indicator

1. Press to switch the unit on/off.

2. Select the input modes (BT, AUX, USB, PC).

3. Volume Control

DC IN

SPK OUT

USB

AUX

3.5 Stereo Input

Left Channel Output

USB (for USB driver play music / PC Decoding)


* Figures and illustrations in this User Manual are provided for reference only and may differ from actual product appearance.

3SPEAKER LED Indicator

The LED indicator on the sound bar gives you information about the status of the SPEAKER.


USB	Purple light	BT	Blue light
AUX	Red light	PC	Purple light


4Connect the SPEAKER



5Using your soundbar

5aTurn On / Off





1. Connect the cable of the secondary computer to the SPKOUT hole of the main computer.

2. Plug in the power supply and press to turn it on (Short press to turn on, long press to turn off).


5bAUX

1. Choose line in cable (3.5mm to 3.5mm) connect the SPEAKER to your TV.

2. Turn on the speaker. Press the knob button on the speaker, then select the "AUX" red light input mode on the display screen.

3. Turn on the TV, press the **home** (or menu) on the TV remote, go to **TV setting**→**audio(sound)**→**TV speaker**→select **external speaker**(turn off TV speaker), save the **setting**. (For some TVs, please back to **audio(sound)**→select **analog output**→select the **"Variable"**, save the setting).

4. Play TV show to test the SPEAKER.



3.5mm to 3.5mm cable (not supplied)

5cBT


The BT connection

1. Press the speaker knob button, then select the blue light input mode "BT" on the display screen. At this time, the blue light will blink.

2. Turn on BT on the BT device. (see the device's manual for more information)

3. Select "DS11-24" from the device BT list, connect it. When your BT device is connected, the LED display will stop flash.

4. Play music from the BT device to test the SPEAKER.



BT Device

* You cannot connect more than one BT device at a time.

* If your device requests a password, enters the default "0000".


* Only work with the device which can output BT signal, it can not work with some devices can not output BT signal such as headphones.

5dUSB

1. Connect your USB drive to the USB port on the speaker.

2. Press the speaker knob button, then select the purple light shown on the display screen, which corresponds to the input mode "USB".

3. Play music to test.



USB Flash Driver

Kindly Note: only for USB flash drive to play MP3 music and update firmware, can not compatible with other usb devices.

6Specifications

Model	VENTOTWO
Power Supply	DC 18V
Peak Power	24W
Speaker	2pcs * 1.5" tweeter Driver+ 2pcs * 3" Driver+2pcs * 88x60 Passive
Volume Level	0-32
BT Version	5.4
Distortion	<0.5%
Product Weight	2.36kg
Product Dimension	110(L) x 130(D) x 165(H) mm*2pcs