S2 蓝牙音箱

S2 蓝牙音箱　　使用说明书

使 用 前 请 仔 细 阅 读

ENJOY THE MUSIC

重要安全信息

* 请仔细阅读说明书
* 请保留说明书
* 请注意所有警告
* 请将音箱放在一个稳固的位置，以防坠落造成音箱损害
* 请勿在靠近水源的地方使用音箱，也不要将音箱浸入任何液体中或液体滴落地方使用音箱
* 请勿将音箱放置或靠近裸露火焰源，如点亮的蜡烛等地方
* 请勿将音箱长期置于高温、高湿、曝晒、雨淋等环境中，否则将严重影响产品的正常使用寿命或导致产品故障等
* 请勿自行拆解、修理和改造产品
* 产品内置锂电池，勿随意丢弃或置于火中，以免引起危险
* 本机的充电电压为 5V，给本机充电时要用 5V 的充电器，如用高于 5V 的充电器给本机充电，会烧坏机器内部的芯片，造成机器不能正常使用

物品清单

请确认您所购买的产品包装箱上的型号，如与您欲购的型号不符请迅速与您购买商家联系.

S2 蓝牙音箱

- ☑ 电源线及AUX音频线各一条
- ☑ 说明书及保修卡一份
- ☑ 音箱一台
- ☑ FM收音机拉杆天线一根

使用说明





① “ ＋ ”音量加/加时间
② “ — ”音量减/减时间
③ “ ⏻ ”开关机/播放暂停/通话免提/时钟设置
④ “ M ”模式切换/收音模式/长按搜索电台
⑤ “ ⏮ ”上一曲/长按开关背光灯
⑥ “ ⏯ ”下一曲/长按调节背光灯的亮度(可调三个等级亮度)
⑦ 通话麦克风
⑧ LED 指示灯
⑨ “ USB ”U盘插口
⑩ “ DC ”充电插口
⑪ “TEMP ”温度检测口
⑫ “ AUX ”音频输入插口
⑬ “ TF ”内存卡卡槽
⑭ “ 8888 ”时间显示
⑮ “ ”24小时制
⑯ “ ”闹钟1
⑰ “ ”闹钟2
⑱ “ -88° ”温度
⑲ “ 188% ”电池电量
⑳ “ AM ”上午
㉑ “ PM ”下午
㉒ “ ”蓝牙模式显示
㉓ “ AUX ”音频输入显示
㉔ “ TF ”TF卡插入显示
㉕ “ FM ”收音机显示
㉖ “ USB ”U盘插入显示

注：⏮ ⏯ 组合键：同时长按这两个键可关闭整机电源（无时钟显示，闹钟也同时被关闭）

蓝牙音箱使用说明

本机工作模式说明：本机有两种工作模式，蓝牙音箱模式和闹钟设置模式

蓝牙音箱模式：长按电源键(⏻)开机，进入蓝牙音箱模式，此模式为蓝牙音箱使用模式 不能设置时间 / 闹钟

闹钟设置模式：长按电源键(⏻)关机，进入闹钟设置模式，可设置时间 / 闹钟 不能使用蓝牙音箱

一. 手机蓝牙的连接方法

1. 长按音箱电源键(⏻)开机，进入蓝牙模式
2. 打开手机蓝牙设置，进入搜索，看到显示 S2 后进行连接配对（手机音箱配对成功后，音箱蓝牙有记忆功能，当另一部手机使用时，请将已配对成功的手机蓝牙功能关闭，重新进行配对连接）
3. 电话免提：当手机有来电时，按音箱的免提键(⏻)，可直接用音箱与对方通话，通话结束，再按一下免提键(⏻)挂电话，来电时长按免提键(⏻)可拒接来电

二. AUX（外接音源输入）

本机具有将一切外接音源（如手机、ipad 平板电脑、MP3 播放器、磁带随身听、CD 机、收音机等）的声音输入到本机播放，用本机配备的 3.5 音频线一端插入本机的 AUX 插孔，另一端插入手机或电脑的耳机输出孔使用.

三. 插卡、U 盘

将有音乐文件的 TF 卡或 U 盘插入音箱，音箱会发出提示音后直接播放 TF 卡或 U 盘里的音乐文件

支持的音乐文件格式：MP3 WAV WMA

TF 卡支持的最大容量：32G

四. FM 收音机

按 M 键切换到收音(FM)模式，将本机配备的拉杆天线插入本机的 AUX 插孔，长按 M 键音箱会自动搜索电台，此时音箱上面的蓝灯快闪，搜索完电台后会自动保存电台，直接播放搜到的电台（注：收音效果跟使用环境和信号强度有关，信号强收音效果好，信号弱收音效果会差一些，收音效果差可将本机配的 3.5 音频线插入 AUX 孔内当收音天线使用）

五. 充电使用方法

1. 当音箱内置电池电量不足时，音箱会发出低电提示音后自动关机，此时将本机配备的 USB 充电线，一端插入本机的 DC 充电插孔，一端插入电脑的 USB 插孔或（ 5V 1A ）手机充电器的 USB 插孔，即可实现对音箱充电，音箱上面的红色灯亮表示正在充电，充满电后电量显示 100%。

注：本机的充电电压为 5V，给本机充电时要用 5V 的充电器，如用高于 5V 的充电器给本机充电，会烧坏机器内部的芯片，造成机器不能正常使用。

2 电池充电时间一般为 3 个小时左右，充满电后最大音量状态能连续播放 5–6 个小时，在默认音量状态能连续播放 8–12 个小时左右，待机时间为 80 小时。

六. 复位功能

当按音箱上的按键操作无效时，电池电量不足会出现这种现象，如音箱充满电出现这种现象，此时可对音箱进行复位操作：长按电源键 10 秒以上来进行复位操作，之后音箱就能正常工作了

七 . 使用平板电脑和笔记本电脑的操作方法：**用本机配备的 3.5 音频线一端插入本机的 AUX 外接音源输入 ）接口，另一端插入平板电脑和笔记本电脑的耳机输出孔连接使用**

八. 常见问题解决方法

1. 蓝牙多次连接配对不成功：(1) 重开机配对；(2) 周边蓝牙设备太多，造成搜索困难，关闭其它蓝牙设备
2. 声音过小或失真：(1) 电池电量不足；(2) 调节音量到合适大小
3. 蓝牙音乐播放出现断音：是否超出音箱有效连接距离，或音箱和手机间有障碍物

操作指南

1 时间设置：

蓝牙音箱在关机状态下，按压中间开机键“ ⏻ ”，显示屏变亮，再按压中间开机键“ ⏻ ”，显示屏时钟数字开始闪动，按加号键或减号键“ — / ＋”调制显示屏上闪动数字，调制固定时钟时间，再按压下一曲键“ ⏯ ”显示屏分钟数字开始闪动，按压加号键或减号键“ — / ＋”，调制显示屏上闪数字，调制固定分钟时间，完成后时间调制好。

如图所示：



2 12/24 小时制设置：时间设置好后，按压下一曲“ ⏯ ”，显示屏上 24 小时制或 PM/AM 开始闪动，按压加号键或减号键 “ — / ＋ ”，设 12/24 小时制。

如图所示：

3 闹铃设置：时间设置好后，按压下一曲“ ⏯ ”，显示屏上闹钟 1 开始闪动两跳置数字闪动，再按压加号键或减号键 “ — / ＋”，设置闹铃时间，设置闹铃时间后，按压下一曲“ ⏯ ”，显示屏上出现 “OFF” 闪动，表示 “关闭”，出现 “ON” 闪动，表示 “开启”，按压加号键或减号键 “ — / ＋”选择关闭或开启，选择好后，再按压下一曲“ ⏯ ”，显示屏上再次出现“LOOP”闪动，表示循环闹铃，显示屏上出现“ONE”闪动，表示不循环闹铃，按压加号键或减号键“ — / ＋”选择循环闹铃或不循环闹铃，设置完后，闹铃 1 结束。闹铃 2 设置同闹铃 1 一样。

如图所示：

补充说明：

1. 闹钟开关设置：OFF 为关闭闹钟，ON 为打开闹钟，闹钟打开后显示屏上有闹钟图标（ ⏰ ）显示，同时长按（ ⏮ ⏯ ）键关机也可关闭闹钟
2. 闹铃循环设置：ONE 为闹铃只响一次，LOOP 为重复响铃 10 分钟重复响一次，重复响 5 次）
3 闹钟铃声选择：本机有内置的 5 种铃声和 TF 卡选择，TF：如选择 TF 为闹钟铃声(机器要有 TF 卡插入，卡内要有音乐文件能正常播放)，当闹钟时间到机器会自动开机读 TF 卡播放，播放的顺序同正常读卡播放顺序，如设置了 TF 卡为闹钟铃声后又未插 TF 卡，闹钟时间到机器会默认铃声 1 为闹钟铃声
4. 闹钟闹铃响后，按任意按键可停止闹铃声

产品规格

产品型号：S2

输出功率：3W*2

蓝牙版本：Bluetooth 5.4

传输距离：≤10 米(传输距离因环境因素和手机蓝牙设备不同而有所不同)

音箱电源：3.7V 2000mAh

规格：DC5V ⎓ 2A

保修卡

感谢您购买本公司产品，请在购机时填写以下内容并妥善保存此卡，以便我们为您提供完善的售后服务，为保证您的合法权益和使用权，请仔细阅读保存条款 .

产品型号：_____　　用户姓名：_____

购买日期：_____　　联系电话：_____

WARRANTY CARD

Model No _____　　User Name _____

Purchasing Date _____　　Telephone No _____

S2 bluetooth speaker

S2 bluetooth speaker　　User Manual

Please read me before using

ENJOY THE MUSIC

SAFETY INFORMATION

* Please read and keep this Manual, and pay attention to the below warnings.
* Please put this speaker in a stable place, to avoid any damage caused by accident dropping.
* Please keep this speaker away from any liquid or fire.
* Please don't leave this speaker in high temperature, or high moist environment for long time.
* Please don't insolate this speaker
* The charging voltage is 5V. The speaker's internal chip will be burned out and couldn't work normally if using higher charger

PACKING LIST

Pls make sure the purchased item is with the correct Model No. If the item model number doesn't match with that of the package, pls try to contact the agents .

S2 bluetooth speaker

- ☑ 1 pcs speaker
- ☑ 1 pcs manual
- ☑ 1 pcs AUX cable and 1 pcs charging cable

OVERVIEW AND INSTRUCTION FOR USE





① “ ＋ ” Volume Up/Time Forward
② “ — ” Volume Down/Time Backward
③ “ ⏻ ” On/Off/Play/Pause/Hands Free Phone Call/Time and Alarm Setting
④ “ M ” Mode Switch/Long Press Search Radio when it's under FM mode
⑤ “ ⏮ ” Previous Song/Long Press for Back Ground Light On and Off
⑥ “ ⏯ ” Next Song/Long Press for Light Brightness Adjusting (3 brightness level available)
⑦ MIC
⑧ LED Led
⑨ “ USB ” USB disk socket
⑩ “ DC ” Charging slot
⑪ “TEMP ” Temperature detection
⑫ “ AUX ” Aux line in
⑬ “ TF ” TF card slot
⑭ “ 8888 ” Time
⑮ “ ” 24 Hours
⑯ “ ” Alarm 1
⑰ “ ” Alarm 2
⑱ “ -88° ” Temperature
⑲ “ 188% ” Battery
⑳ “ AM ” AM
㉑ “ PM ” PM
㉒ “ ” Bluetooth
㉓ “ AUX ” AUX
㉔ “ TF ” TF card
㉕ “ FM ” FM Radio
㉖ “ USB ” USB Disk

Note: ⏮ ⏯ Long press these two at same time can turn off the whole machine (include alarm clock)

Bluetooth Speaker Instruction:

Mode Instruction:

This speaker is with Bluetooth Speaker Mode and Alarm Setting Mode.

Bluetooth Speaker Mode: long press button to turn on, the speaker is in the Bluetooth Speaker Mode, at this status, Alarm can't be set.

Alarm Setting Mode: long press button again to turn off the speaker, at this status, the alarm and the time can be set, while Bluetooth speaker is not functional.

How to connect the mobile phone by Bluetooth?

1. Long press ⏻ for 3 seconds to turn the power ON, there will be a turn on prompt sound. Press **M**, the speaker will get into Bluetooth connection mode
2. Turn on the Bluetooth of mobile phone and search S2, and then match the speaker to mobile phone. There will be a prompt sound after connection succeeded, and the blue indicator light will stop flashing. Bluetooth paring time is about 1 minute. It will be different for different mobile phones as the Bluetooth version is different.
3. Note: There is a memory function for the Bluetooth speaker. Turn off the Bluetooth of the previous mobile phone before connecting to another one.
4. Short press button ⏻ to answer the phone call, long press button ⏻ to refuse the phone call. Press button ⏻ to finish the phone call, the speaker will be back to work
5. Long press ⏻ for 3 seconds to turn off the speaker. (When the bluetooth is not connected, the speaker will turn off automatically if it doesn't work and have got no operate instruction within 60 minutes.)

How to Line in by AUX (external audio input)?

This speaker can connect to all kinds of audio devices (such as mobile phones, pad, MP3 player, cassette player, CD player, radio, etc.). With 3.5mm AUX plug in the earphone jack of the audio device and the other end in the AUX slot of the speaker, there will be a prompt sound. Then it can play under AUX line in mode.

How to use Micro SD/TF Card?

Insert the Micro SD/TF Card into the TF slot of speaker, there will be a prompt sound, and then play the audio files in the card.

It supports following format file: MP3 WAV WMA

It support maximum 32GB TF card

FM Radio

Long press button **M** in the radio mode, it will search the radio automatically. Once finished it, press button ⏮ /⏯ to play the radio.

How to charge?

1.The Speaker will make a prompt sound and turn off automatically when the battery is low. Insert one end of the cable to the charging slot of speaker, the USB plug to the computer or the mobile charger (5V 1A). The front indicator light on red indicates it's charging, the power display on screen 100% indicates it's fully charged. **(The charging voltage is 5V. The speaker's internal chip will be burned out and couldn't work normally if using higher charger)**

2,It takes around 4 hours for fully charged, It could work about 5-6 hours at maximum volume, and 8-12 hours at default volume, The standby time is about 80 hours.

Reset Function:

When the buttons are out of control, the speaker may get into stuck. Please check if the battery ran out. If battery ran out, please charge it.

If the stuck happen while the battery is full, Pls long press the ⏻ button for 10 seconds. Then turn on the speaker.

Using for Tablet PC/Notebook:

Connect the speaker and Tablet PC/Notebook by using the 3.5mm AUX cable.

F&Q

1. It cannot be matched with the devices by Bluetooth: (1) turn off the speaker and mobile phone, and then turn on both, rematch. (2) Too many Bluetooth devices surround, turn off the other Bluetooth devices
2. Sound too small or distortion too much: (1) may be battery runs out. Please charge it. (2) Turn up the volume of the mobile phone.
3. Sound off and on: please check if the range between the speaker and the device is more than 10 meters. Or check if there are any barrier between the speaker and the device

OPERATION INSTRUCTION

Time setting

Long press “ ⏻ ” for 3 seconds to turn on, the speaker will turn into Time Mode, then press “ ⏻ ” again, the screen digital will start flashing; now can adjust the hour hand by pressing “ — / ＋ ”. After finish it, press “ ⏯ ” now can adjust the minute hand by pressing “ — / ＋ ”. At last press “ ⏻ ”, the whole step has been finished.



12 hours/24 hours setting

At first, press “ ⏻ ” twice, the screen digital will start flashing, Then press “ ⏯ ” for several times until the “ ” show up. Then press “ — / ＋ ” for choosing 24 hours/12 hours, At last press “ ⏻ ”, the whole step has been finished.

Alarm clock setting

At first, press “ ⏻ ” twice, the screen digital will start flashing, Then press “ ⏯ ” for several times until the “ ” show up, Now can set up first alarm clock, After finish it, press “ ⏯ ”, the “ ON/OFF ” will show up (this is for alarm status), Then press “ — / ＋ ” for choosing its status, Still press “ ⏯ ”, the “LOOP/ONE” will show up, press “ — / ＋ ” for choosing one. “ONE” indicates it will ring only once, “LOOP” indicates it will ring in loop (repeat 5 times every 10 minutes), Still press “ ⏯ ”, now can choose alarm rings by pressing “ — / ＋ ”, It has 5 choices, At last press “ ⏻ ”, the whole step has been finished. (Second alarm clock is same as first one)

Specification			
Model number:	S2	Power output:	3W*2
Bluetooth version:	5.4	Bluetooth range:	≤10 meter
Battery:	3.7V 2000mAh	Power input:	DC5V⎓2A

材质：128g双铜版纸　风琴折页　规格：70*135mm

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and
(2)This device must accept any interference received, including interference that may cause undesired operation.