TORRAS

USER MANUAL
取扱説明書

In order to bring you a better experience, please read this user manual carefully before using this product and keep it properly for future reference.

Specifications

Product Name	Power Bank
Product Model	P5010
USB-C Input	5.0V ⎓ 3.0A/9.0V ⎓ 2.0A/12.0V ⎓ 1.5A
USB-C Output	5.0V ⎓ 3.0A/9.0V ⎓ 2.0A/12.0V ⎓ 1.5A
Wireless Charging Output	15W MAX
USB-C+Wireless Charging Output	10W+5W MAX
Output Power	22.5W MAX
Lithium Battery Energy	10000mAh/3.87V/38.7Wh (2 cells in parallel)
Cell Capacity	10000mAh
Rated Capacity	9700mAh (3.7V ⎓ 7.2Wh)
Transfer Efficiency	≥85%
Charging Voltage Of Battery Charging	4.45V
Working Temperature	0°C~35°C / 32°F~95°F
Packaged List	Power Bank ×1; Charging Cable ×1; User Manual ×1

The parameters above are derived from the laboratory of TORRAS. The actual parameters would be different due to different testing scenes and other factors. The margin shown here is indicative only.

Overview



Use the Power Bank

1. Button operation

① Click the power button to turn it on and start the wireless charging/wired charging; double-click the power button to turn it off.

② Press the power button for 2 seconds to start the low-current mode for 2 hours (it will automatically turn off after 2 hours). Press and hold again for 2 seconds to turn off the low-current mode and enter the normal charging mode.



2. Magnetic wireless charging

(Do for iPhone series mobile phones that support magnetic wireless charging) Align the center of the back of your phone magnetically attract the mobile phone to the wireless charging area of the power bank, and the wireless charging mode is turned on. When the wireless charging is successful, the blue light, and the power indicator will display the current battery level.



3. Regular wireless charging

(Do for non-iPhone mobile phones that support wireless charging) Align the center of the back of your phone with the wireless charging area, and the charging symbol will display on the screen of your phone. The blue light indicator will be constantly on blue light, and the power indicator will display the current battery level.

Note:
When the wireless charging output is abnormal or a foreign object (FOD) is detected, the blue light of the wireless charging indicator will continue to flash 3 times/second, and it will reverse within 2 seconds after it is removed.

4. Wired charging

Use the USB-C charging cable provided with the product to connect the power bank and the charger, and then charge the phone/tablet and other devices. The blue light of the wireless charging indicator will be off, and the power indicator will display the current battery level.



Charge the Power Bank

Plug one end of the USB-C charging cable into the USB-C port of the power bank, and the other end into a suitable charger for charging the power bank. When charging, the power indicator light flashes and displays the remaining battery level; when fully charged, four power indicator lights are always on.



Notes:
01. When it is charging and fully charged, the wireless charging indicator light does not light up.
02. In order to guarantee the normal service life of the battery, please use and charge it at least once every three months.

Attentions

01. This wireless charger is not compatible with non-MagSafe iPhone 12 series.
02. For current sensitivity charger your device in the following situations: a. using a case with a magnetic / iron plate b. using a case with a foldable handle and bracket, c. using an unusually thick case (more than 3mm thick).
03. Do not place any foreign objects between your phone and the wireless charger(Do not be including metal plates on a car mount, credit cards, keys, coins, metal objects, or NFC cards
04. Wireless charging power is only accepted at 5V 1A (5W) or more
05. Wireless chargers make no sense to your device's current charger, but due to current wireless technology limitations, the charging speed is slower than wired chargers.
06. High temperatures can reduce charging speed and limit charging to protect your device and battery temperature. It is recommended to charge your device in environments with temperatures below 25°C/77°F.
07. Remove any protective cover of your device so the wireless charger will detect the charging speed. The further the device is from the center of the wireless charger, the slower the charging speed will be.
08. For optimal charging performance, align your smartphone with the coil in the center of the wireless charger. If the charging is interrupted, adjust the position of your device to be placed on. Ensure the smartphone is always centered on the wireless charger.

Important Safety Instructions

When using this product, basic precautions should always be followed, including the following:

01. Please store this product in a cool and dry place.
02. Do not expose this product in a high-temperature or humid environment.
03. Do not use the power bank after being immersed in water.
04. Use of a power supply or charger not recommended or sold by the product manufacturer may result in a risk of fire or injury to persons.
05. Do not disassemble the product. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of electric shock or fire.
06. For safety reasons, please do not drop the product. Do not use this product in high temperature or humid environments. Avoid exposure to water.
07. During charging, the product may generate heat. This is normal, please do not worry. If overheating occurs, please stop using it temporarily.
08. After fully charging, please unplug the charger plug in a timely manner to avoid damaging the battery due to prolonged charging.
09. In normal conditions, the battery performance will decline after 300 cycles.
10. Do not place the product in high temperatures or fire. Avoid exposing the product to environments with temperatures above 60°C, as this may result in overheating, fire or explosion.
11. If the power bank emits any unusual smell, overheats, changes color, or deforms, please stop using it immediately.
12. Do not use harmful chemicals or detergents to clean this product.
13. Misuse, dropping, or excessive vibration may cause product

Wonder. Explore. Forward.

SHENZHEN TORRAS TECHNOLOGY CO., LTD.
Address: RM1715, BLK C, Zhantao Technology BLDG, Minzhi Avenue, Minzhi ST, Longhua DIST, Shenzhen, China

© Shenzhen TORRAS Technology Co., Ltd. All Rights Reserved.

Email: support@torrasltd.com

Made in China

FC CE PD

FCC Warning
15.19 Labeling requirements.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
15.21 Information to user.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
15.105 Information to the user.
This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
FCC RF Radiation Exposure Statement:
1.This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2.This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.

Caution

This product is equipped with a built-in lithium battery, and please pay attention to the followings.

01. Please charge the product in time when the battery is low. If the product is not used for long periods of time, charge and discharge it once every three months to prevent battery damage.
02. Do not disassemble, hit, squeeze, or throw into fire. If severe swelling occurs, stop using it. Do not place in high temperature environments for the battery, such as sunshine, strip using it and seek professional maintenance.
03. If the wrong type of battery is used, there is a risk of explosion. So, etc.
04. Batteries or battery packs on assembled battery should not be exposed to high temperatures such as direct sunlight or fire.
05. Products containing built-in batteries should be separated from household waste when disposed of, and should be taken to an appropriate waste collection center for recycling and do not discard it casually.
06. When disposing of used batteries, keep batteries of different electrochemical systems separate from each other.
07. Do not use batteries for purposes that cause fire or smoke. Insulate the terminals with tape.

概要

モバイルバッテリーの使用方法

1. ボタン操作

① 電源ボタンを 1 回押すと電源がオンになり、ワイヤレス / 有線充電が始まります。電源を 2 回押すと電源がオフになります。

② 電源ボタンを 2 秒間押し続けると作モードが 2 時間起動します（2 時間後に自動的にオフになります）。2 回押し続けると、低電流モードを終了し、通常充電モードに入ります。

3. ワイヤレス充電

（マグネット充電が可能なモバイル（iPhone シリーズなど）に対応）モバイルバッテリーのワイヤレス充電エリアの中心に電話のバックカバーを合わせます。ワイヤレス充電モードに入ります。ワイヤレス充電エリアの中心からの距離が大きいほど、充電速度が遅くなります。

4. 有線充電

付属の USB-C 充電ケーブルを接続し、スマートフォンやタブレットなどの機器を充電します。有線充電中はワイヤレス充電インジケーターライトが消灯します。

モバイルバッテリーの充電方法

USB-C ポートに付属の充電ケーブルを挿入すると、モバイルバッテリーの充電が始まります。充電中はインジケーターライトが点滅し、バッテリー残量が表示されます。充電が完了すると、4 つのライトが一時点灯インジケーターライトが点灯します。

ご注意：
01. 充電中、満充電時、ワイヤレス充電インジケーターライトは点灯しません。
02. バッテリーを長時間ご使用されない場合、少なくとも 3 ヶ月に 1 回は充電を行ってください。

注意事項

01. 充電器のワイヤレス充電面は MagSafe 非対応のすべての iPhone 12 シリーズに適しません。
02. 次の場合の充電器ワイヤレス充電デバイスへの感応に敏感：a. 磁石 / 鉄板付きケースの使用時、b. 折りたたみブラケットとケースの使用時、c. 異常に厚いケース（厚さ 3mm 以上）の使用時。
03. メーター充電はバッテリーなしの場合でも、充電デバイス充電器を使用することで、より大きな充電速度が得られて充電効率が向上します。
04. 小型（1kg 以下）の充電台は安定性が悪いため、ケースやデバイスを使用しないようにしてください。小型（1.5kg 以下）で取り付けてください。充電デバイスの充電効率が低下します。
05. 出力が 5V ⎓ 1A (5W) 以下のデバイスは充電しないでください。
06. ワイヤレス充電は有線充電よりも充電速度が遅くなります。これは、ワイヤレス充電技術の制限によるものです。充電デバイスの温度が 0°C ～ 35°C の条件下でのご使用を推奨します。
07. 充電デバイスの保護カバーを取り外してください。充電デバイスの充電位置が中心から離れるほど、充電速度は遅くなります。
08. 充電効率を最適化するには、スマートフォンを充電デバイスの中心に合わせて置いてください。充電が中断された場合は、充電デバイスの位置を調整してください。

安全上のご注意

本製品を使用する際は、以下の注意事項を守ってください：

01. 本製品は涼しく乾燥した場所で保管してください。
02. 高温多湿な環境で使用しないでください。
03. 本製品を水に浸した後は使用しないでください。
04. メーカーが推奨していない電源アダプターを使用しないでください。感電や発火などの危険があります。
05. 本製品を分解しないでください。修理が必要な場合は、サービス担当者にご相談ください。誤った再組み立ては、感電や火災の危険があります。
06. 安全のため、本製品を落下させたり、高温や湿気の多い環境で使用しないでください。水に触れないようにしてください。
07. 充電中は、本製品が熱くなることがありますが、正常な動作ですので、ご安心ください。異常な過熱が発生した場合は、使用を中止してください。
08. 充電完了後、長時間の充電による劣化を防ぐため、速やかに充電器のプラグを抜いてください。
09. 通常の使用条件下では、300 回のサイクル後に容量が低下します。
10. 本製品を高温や火の近くに放置しないでください。60°C を超える環境での使用は、過熱、火災、爆発の原因となります。
11. 異臭、過熱、変色、変形が見られた場合は直ちに使用を中止してください。
12. 製品のクリーニングには、化学薬品やクリーナーを使用しないでください。
13. 誤使用や落下、過度な衝撃は故障の原因になります。
14. モバイルバッテリーの内蔵電池はリサイクル可能ですので、ゴミとして捨てないでください。
15. 分解や改造はしないでください。
16. 絶縁テープなどで端子部分を保護してください。
17. 異なる化学組成のバッテリーを混ぜて使用しないでください。
18. 廃棄する際は、適用国や地方の法律に従ってください。

警告

本製品は以下のような電波妨害を受ける、または他の電子機器に妨害を与える可能性があります。

01. バッテリー残量が少ないときに充電すると、過充電により故障してください。長期間使用しない場合でも、3 ヶ月に 1 回は充電を行ってください。
02. バッテリーを分解したり、衝撃を与えたり、火で投げ入れたりしないでください。バッテリーが膨張した場合は、使用を中止してください。直射日光などの高温環境に置いたり、バッテリーを取り外して、専門の修理サービスを受けてください。
03. 誤った種類のバッテリーを使用すると、爆発のリスクがあります。
04. 組み立てられたバッテリーパックやバッテリーを直射日光や火などの高温にさらさないでください。
05. 内蔵電池の本製品を廃棄する際は、適切なゴミ収集センターでリサイクルしてください。通常のゴミとして捨てないでください。
06. 使用済みバッテリーを廃棄する際は、異なる化学組成のバッテリーを分けてください。
07. 火災や煙の発生を伴う用途でバッテリーを使用しないでください。
08. 絶縁テープなどで端子部分を保護してください。

物料编码：		物料名称：图拉斯1 小云宝系列超薄移动电源说明书			
结构部分	材　质：铜版纸 200克本白双胶纸	单　位：mm	平面部分	印刷颜色：K	LOFFAN DESIGN
	成型尺寸：60*60mm（44P，双钉）	刀　线：———		表面处理：单黑+双面印刷，啤+折，风琴折	
	展开尺寸：	压　线：- - - - - - - -		平面设计：陈古鸿	
	结构设计：	针 刀 线：		平面修改：	
	日　期：	刀模相交：		日　期：2024.06.12	
	备　注：	切　线：		备　注：	

特别说明：所有物料需要符合富禾《有害物质限用管理程序》LH-WI-0004（环保要求）