

Y10001811--V1说明书(日语)-V1(20230725)


### 技术要求:

- 1.成型尺寸:125\*215mm, 风琴折;
- 2.材质:80g书纸,
- 3.印刷:单色 双面印刷 色彩准确,无套印不准等现象;
- 4.裁切整齐无毛边;
- 5.其他要求:产品需满足REACH法规及最新RoHS指令要求。

产品需满足欧可林《包装材料来料检验通用标准》。

- 6.公差:±1mm  
7.标注单位mm

English



# Ocliclean

## Product User Manual

**■ Important Safety Tips**

This product is recommended for use by persons over 15 years of age.  
The product can only be used with Ocliclean replacement heads. We will not be responsible for any consequences resulting from the use of non-recommended third-party brush heads.  
This product is for personal cleaning only and is not recommended for medical purposes.  
This product is for indoor use only. Avoid direct use on toothpaste under sunlight for a prolonged period of time. It is recommended to be placed in the dry well-ventilated place with normal temperature.  
Please keep the body dry before charging, dry it with a soft cloth and ensure the charging base with a dry cloth regularly to prevent the stain from building up.

**Brush head**  
When replacing the brush head, please pull out or insert vertically, and do not rotate left or right.  
It is recommended to change the brush head every two to three months.

**Attention:** should be paid for both the following conditions and of sensitive:  
Those who have recently undergone periodontal surgery or are undergoing treatments.  
Individuals with other symptoms of mouth including those with unstable dentures or have persistent heavy bleeding from the gums.  
Other individuals with sensitive and fragile oral tissues.  
The product is not recommended for use with the above group or consult a professional dentist before use.

This product is not suitable for people with disabilities, mental illness or lack of relevant experience and knowledge (including children (0-12 years old)), unless used under the supervision of their guardians.



**■ Scientific Grouping**

**Brush Activity Closer:** The Ocliclean Toothbrush replaces daily and easily closes loop management. It records the number of brushing every day (which are required to brush the teeth at least 10 times daily), brushing time (which is required for more than 2 minutes each time), brushing score (average 100 points per time)(Brush Activity Closer is a watch for oral care heads).

**Overpressure Reminder:** During the brushing process, if too much pressure is applied, it may harm the gums and oral surfaces. Therefore, when brushing, please use moderate pressure. If it is too close, the device will warn, and the toothbrush light will also display red.

**Excessive lateral brushing reminder:** During the brushing process, if the lateral brushing is too strong, it may cause gum bleeding or damage to the neck of the tooth. Therefore, when the toothbrush detects excessive or rapid lateral brushing, it will sound an alarm. Remember to brush the occlusal surface. The occlusal surface of molars is prone to caries, so you need to pay special attention to brushing this area. The toothbrush will sound an alarm during the brushing process to remind you to brush the occlusal surface.

**Zone reminder:** Brushing needs to cover all areas to effectively prevent dental problems. Therefore, during the brushing process, it should be able to remind you to change areas after completing previous dental areas.

Swipe the screen up and down      Press On/Off button to confirm the settings

**Low Battery Alert**  
When the battery percentage is below 10%, an alert will pop up on the display of your toothbrush from time to time to indicate that the battery is running low. Once you need to charge it again. When the battery is seriously low, your toothbrush will be off and the toothbrush motor will respond to alert you to charge the battery.

**In the toothbrush bottom or the charger is a sensor that the toothbrush is upright and clamped in the charging base. In normal charging, the toothbrush will show the charging sign and battery percentage and will fully charge for about 1.5 hours.**

**Important Charging Alert**  
As the electric toothbrush is provided with the fast-charging mechanism, it is recommended to connect and charge the toothbrush directly. Don't put the toothbrush on the charger when charging is not required or it is fully charged because leaving the fully-charged toothbrush in the charger for a long time may lead to premature depletion of the built-in battery. But affecting the usage experience.

**■ Recommended Tooth Brushing Method**




Move the toothbrush slowly at 45° angle between the teeth and gums and there is a need to move the brush up and down during this process.

Hold the toothbrush vertically, gently move slowly in a circular motion, and please do not apply excessive pressure.

Please grasp with clean water after brushing.

**■ User Guide**

**First-time use**  
Turn on the toothbrush, press the power button. The toothbrush will enter standby mode after turning on. The Bluetooth and Wi-Fi will remain on while the screen is off. After the screen turns off, Bluetooth and Wi-Fi will turn off automatically after 30 seconds of inactivity.

**App installation**  
Scan the QR code to download the "Ocliclean Care" app, then search for and connect to the toothbrush with the app. Note connecting to the toothbrush through "Bluetooth settings" in your phone's system settings will not work.

**App Connection**  
On the "Ocliclean" page of the app, click the top device picture to enter the "Device Information" page, then turn on "Automatic switch between morning/night mode" under "Function settings" to allow the toothbrush to switch between "Sunrise Scouting" and "Sunset Sunset" mode automatically.

**Brushing Plan Settings**  
After successfully linking the toothbrush to the app, fill in your identification information to receive recommended brushing plans that fit you most. Alternatively, customize your own exclusive brushing plan by clicking "Exclusive Mode" on the "Ocliclean" page of the app.

**Viewing Brushing Records on the App**  
The app can view Ocliclean toothbrush data during brushing if the toothbrush is connected to Wi-Fi and bound to the app. "Toothbrush data" data may take time to be saved and will be saved. The toothbrush can only be limited amount of brushing data (up to 7 days), but please connect the toothbrush to Wi-Fi and synchronize the data with the app when it's day.

**Brushing plan**  
Without any settings, the toothbrush will run in the "Unlimited clean mode" by default, where, strong alert will be given when the toothbrush runs for 2 minutes and will automatically stop running after 5 minutes of operation.

**Charging the toothbrush**  
Dry the toothbrush between before charging and then insert the USB-Cable on the charging base or in adapter. After that, you can determine the battery level with the battery percentage shown on the Ocliclean electric toothbrush. After fully-charged please remove the toothbrush from the charging base in time. After charging, please recharge it when the toothbrush alerts you. Its battery status.

**Automatic Wake-up**  
By default, the toothbrush will automatically wake up in the screen.  
If the screen is automatically wake up multiple times in a row without brushing, the next use will require pressing a button to wake it up, when the battery is low, lifting the toothbrush will not automatically wake up the screen.

**■ Specifications**

|                  |                                                 |
|------------------|-------------------------------------------------|
| Product Name     | Ocliclean Wi-Fi Smart Sonic Electric Toothbrush |
| Model            | W850                                            |
| Power            | IPX7                                            |
| Charger          | Wi-Fi Wireless Charging Base                    |
| Input            | 5v/2A                                           |
| Output (user)    | 40 days                                         |
| Battery Capacity | 1200 mAh                                        |
| Charging time    | 2 hours                                         |
| Standard         | GB4706-2020                                     |
| Bluetooth        | Bluetooth 4.2+Active                            |
| Weight           | 245g                                            |

\* Using default mode, it is calculated at 2 minutes/1me, 2 minutes/working condition.

**■ Precautions**

- Do NOT disassemble, stir, extrude or throw the device into a fire.
- Do NOT use the toothbrush if the battery is bulging or has expanded.
- Do NOT place in a high-temperature environment.
- Do NOT use the device if the battery has been subjected to immersion in water.

• **FCI WARNING**

This device complies with part B of the FCC Rules. Operation is subject to the following two conditions: (1) This device may cause interference, and (2) The device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class II digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into a different electrical outlet, one to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general IFN requirements for radio equipment. The device can be used in portable equipment condition without restriction.

**FCC ID: JAWED-V0100**

• **CE WARNING**

- The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given specific instructions.
- The appliance must be kept away from children.
- Signal wires (WARNING, CAUTION, EARTH) or appliance having a height as specified, (appliance table) of the test separating the surface of the appliance not be greater than 15 mm (6 inches) above the surface, or clamped materials either raised above or below a depth below the surface of not less 505 mm, unless:
- The appliance contains cutlives that are non-exposed

Shenzhen Vunding Information Technology Co., Ltd  
Manufacture Address: 250, Building 3, Donghai Business Center (Phase 3), No.18, Daohang Road, Baoan District, Shenzhen, Guangdong, China  
Website: vunding.com.cn

• When removing the battery, the product must be powered off.

After removing the battery, it should be safely disposed of.

Before performing personal follow the steps below to remove the battery from the product.

Before separating the product, the battery should be removed from the product according to the following steps:

1. First slide the charging port cover with a screw driver, then place the charging port along the edge of the bottom cover with tweezers.
2. Use a screwdriver to remove the battery from the bottom cover and remove the bottom cover.
3. Use a screwdriver to lift the battery from the bottom cover and remove the battery.
4. Use a screwdriver to lift the battery from the bottom of the battery, break open the battery, and remove the battery.

- the battery must be removed from the appliance before it is scrapped;
- the appliance must be disconnected from the supply mains when removing the battery;
- the battery is to be disposed of safely.

|                                                                                       |                                                                                           |                                                                                |                                                   |
|---------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------|---------------------------------------------------|
|  | EU Authorized Representative<br>Agency name: Merxian Ltd<br>Representative Agency: Tivoli | (European address: Tivoli g. s. r.l.s.,<br>L'Espresso 101<br>Via Lancia 164237 | Email: service@merxian.com<br>Phone: +39027702772 |
|---------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------|---------------------------------------------------|

**Made in China**

|                                                                                                                                                                                                                                                                                                                                                                       |                                   |  |  |  |                    |                 |            |  |  |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------|--|--|--|--------------------|-----------------|------------|--|--|
| <b>Warranty Certificate of Ocean Smart Electric Toothbrush</b><br>User Information<br>Name: _____ Contact number: _____ E-mail: _____ ZIP code: _____<br>Address: _____<br>Retailer Information<br>Retailer: _____ Contact number: _____ Address: _____<br>ZIP code: _____ Invoice No.: _____<br>Product Information<br>Product Type: _____ Manufacturing Site: _____ |                                   |  |  |  |                    |                 |            |  |  |
| <b>Warranty Card of Ocean Smart Sonic Electric Toothbrush</b>                                                                                                                                                                                                                                                                                                         |                                   |  |  |  |                    |                 |            |  |  |
| Delivery Date                                                                                                                                                                                                                                                                                                                                                         | Fault Description/Reason/Disposal |  |  |  | Equipment employed | Acceptance date | Serviceman |  |  |
|                                                                                                                                                                                                                                                                                                                                                                       |                                   |  |  |  |                    |                 |            |  |  |
|                                                                                                                                                                                                                                                                                                                                                                       |                                   |  |  |  |                    |                 |            |  |  |

| Name of parts  | Toxic and harmful substance or element |    |    |      |       |             | Environment Protection |
|----------------|----------------------------------------|----|----|------|-------|-------------|------------------------|
|                | Pb                                     | Hg | Cd | PBBs | PBDEs | 4Phthalates |                        |
| PCBA           | ○                                      | ○  | ○  | ○    | ○     | ○           | 10 years               |
| Plastic parts  | ○                                      | ○  | ○  | ○    | ○     | ○           |                        |
| Metal hardware | ○                                      | ○  | ○  | ○    | ○     | ○           | 5 years                |

| Name of parts   | Toxic and harmful substance or element |    |     |      |       |             | Environment Protection |
|-----------------|----------------------------------------|----|-----|------|-------|-------------|------------------------|
|                 | Pb                                     | Hg | Cd  | PBBs | PBDEs | 4Phthalates |                        |
| Vibrating motor | ○                                      | ○  | ○   | ○    | ○     | ○           | 10 years               |
| Accessories     | ○                                      | ○  | ○   | ○    | ○     | ○           |                        |
| Battery         | ○                                      | ○  | --- | ---  | ---   | ---         | 5 years                |

**Remarks**

○ This indicates that the content of toxic and hazardous substances in all homogeneous materials of this component is less than the limited quantity as specified in table 2.5 (Directive 2002/95/EC & EU 2006/66/EC)

× This indicates that the content of toxic and hazardous substances in at least one of the homogeneous materials of this component is more than the limited quantity as specified in table 2.5 (Directive 2002/95/EC & EU 2006/66/EC)

— Refer to battery directive 2006 / 59 / EC and amendment 2013 / 56 / EU

\* Except for very few materials, due to technical development reasons, most of the materials used are environmentally friendly. Please use this product with confidence during the environmental protection period.

[illegible][illegible][illegible]

**Instruction for E-label**

- Instruction to find the e-label in the FQA:
  1. Lift up the toothbrush, the screen will be automatically awake and lights up for 5S.
  2. Slip up and down to select any mode and hold for 5S. The firmware version will be displayed on the button.
  3. Slip up and down to switch to E-label screen and the E-label can be checked by user.

The certification logo will be displayed immediately in the screen of the device .  
 Before the device display the certification logo , the wireless transfer will not start.  
 After entering into the E-label screen, the user do not have the entrance to enter and change the identification logo as the contents of the E-label is encrypted .
- E-Label display as below figure:

The diagram illustrates the E-label display layout, which is divided into five main panels:

- Panel 1 (Top Left):** Contains the text "CMIIT ID: 2023DP11889" and a logo with the text "DS 218-230121".
- Panel 2 (Top Middle):** Contains various certification logos including CE, ENEC, UKCA, and others.
- Panel 3 (Top Right):** Contains the text "FCC ID : 2AN5D-V8100" and "FDA Registration Number : 3014246581".
- Panel 4 (Bottom Left):** Contains the text "IPX7" and a recycling symbol.
- Panel 5 (Bottom Right):** Contains the text "Model V8100", "FW V1.x.x.x", and "Made in China".