User Manual

Product Name: ceiling fan remote
Model:99122,99119

Manufacture: HEFEI HOVEYKING ELECTRONICS CO.,LTD.

1.Press “0” and “3” buttons simultaneously for 4 seconds to pair the remote with the ceiling fan.

2.Press the following buttons to control the ceiling fan:

==”3” button to be for high speed fan

==”2” button to be for middle speed fan

==”1” button to be for low speed fan

==”0” button to be for stopping the fan

==the button at the bottom to be for turning on/off the light

3.Press and hold the bottom/Light button to dim the light.

FCC Caution.

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.
-Increase the separation between theequipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.