


Parallax 4000 Wireless Power Bank w/ 2-in-1 Cable

Instruction Manual

7121-51



Features:

1. Wireless Charging Pad
2. Micro USB Input
3. USB Output
4. LED Indicators(six)
5. ON/OFF Button
6. Type-C Input

What's included:

- 1 x 4000 mAh wireless Power Bank
- 1 x 2-in-1 charging cable (see above diagram)
- 1 x Instruction Manual

Tech Specifications

- 4000 mAh/3.7V poly-li battery
- Input power: DC5V/2A
- Output power: DC5V/2.1A
- Wireless Output: DC 5V/1A

LED Indicators:

- ON/OFF Button: Press once to view the remaining power capacity.

Instructions:

1. Charging the power bank:

- a. Using 2-in-1 charging cable, insert the USB A port into a certified USB AC adapter or USB port of a computer, insert the 2-in-1 tip (the side with pins upwards) into power bank micro input. Then charge begins.
- b. When Charging the first four LED Indicators will flash BLUE, Once fully charged the four LED indicators will be remained BLUE.

2. Charging mobile phones and other electronic devices:

- a. Connect the 2-in-1 cable to your mobile phone/device. If Android device, the tip with pins upwards; If iOS device, the tip without pins upwards. Connect the other end of the power bank. The first four LED Indicators will illuminate BLUE when charging.
- b. When capacity is getting decreased during charging, the four LED indicators will gradually turn off accordingly.
- c. Remove the USB cable from your mobile device when it is fully charged.

3. Charging Mobile phones and other electronic devices with wireless output.

- a. Press ON/OFF Button once, BLUE four indicators should be on to show balance capacity, the remaining two LED indicators will flash RED and GREEN for three times, then Green indicator off right away, RED indicator would wait for 50 seconds to get off if no charging action. The first four BLUE LED indicators would be off after 60 seconds.
- b. When the last indicator displays RED, it means wireless charging mode. Place a phone compatible with wireless charging function on the wireless charging pad surface and it would charge automatically. The fifth LED indicator display GREEN.

SAFETY PRECAUTIONS:

WARNING—When using this product, basic precautions should always be followed, including the following:

1. Read all the instructions before using the product.
2. Charge the power bank fully before initial use. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.
3. To reduce the risk of injury, close supervision is necessary when the product is used near children.
4. Do not expose the device to moisture.
5. Do not use the device in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.
6. Do not use the device if damaged or modified.
7. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
8. Do not disassemble the device. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury.
9. Do not expose the device to fire or excessive temperature. Exposure to fire or temperatures above 212°F may cause explosion.
10. Have servicing performed by a qualified repair person using only identical replacement parts.
11. This will ensure that the safety of the product is maintained.
12. Do not overcharge Phone. Unit may get hot with excessive use. Remove Phone when it is fully charged. Never charge for more than 7 hours at a time.

13. Attachments on the back of your phone can impede the effectiveness of the wireless charger, and lead to overheating. Please remove attachments from the phone before charging on this device.

Note: In order to charge devices, use only the accessory cable or the cable included with your own device by the manufacturer.

FCC Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

- * Warning:
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.