



User Manual Wireless Mouse  E100	Product Function  A Left Button B Right Button C Scroll Wheel D DPI Switch Button E Low Battery Indicator Light F Power Switch
---	---

G

Battery Compartment

H

06.11.01.1132

E100深圳市融创致远 说明书60x95mm展开240x95mm 80克书写纸 黑色单面印刷 风琴折