


FRONT

Closed: 9 x 20cm | Open 27 cm x 20 cm

GTECH
Wireless
Karaoke
Microphone

ITEM 53864-DI



Enjoy the karaoke bar experience with family and friends anywhere you go with this portable Wireless Karaoke Microphone system. This unit connects to your mobile phone via Bluetooth and has an integrated dual Bluetooth speaker. Once the karaoke microphone is connected to your phone you can download any karaoke App or just stream a karaoke songs from any website. The music will play through the Karaoke microphone speakers and you can sing along with your select song. Control the music volume, your voice volume, treble, bass and echo effect all from the microphone just like a karaoke system. Get your Karaoke ON at home, in the office in the park or anywhere you feel like singing your heart out with this portable Wireless Karaoke microphone. Compatible with IOS and Android devices.

Charging the Karaoke Microphone

1. Connect the Micro USB cable (included) from one end to the microphone and the other end ot a USB power source. (Home Charger, Car Charger or USB port on your computer) Once the red light on the microphone turns on that means the unit is charging.
2. Charge the microphone for 2 hours for a full charge. The red light on the microphone will turn off when the internal battery is fully charged.

Note: When the battery is running low the unit will automatically turn off letting you know it's time to charge it.

Pairing the Wireless Karaoke Microphone to your Mobile Device

1. Hold down the power button for 5 second to turn on the microphone. Hold down the power button again for 5 seconds to turn off the unit.
2. To "pair" the microphone to your mobile device hold down the Power button for 5 seconds from the OFF position. The microphone will turn on an automatically enter into paring mode.

3. Turn on the Bluetooth function on your phone and search for "Karaoke Microphone". Once you select "Karaoke Microphone" on your device you will hear a beep on the microphone confirming it is paired. **Note:** if you mobile device asks you for a pairing password please enter 0000.
4. You are now ready to sing your heart out!
5. Use the controllers to customize your singing and music. The "Volume" controller will control how loud your voice comes through the microphone speakers. The music controller will control how loud the music you are streaming will come through the microphone speakers. Then adjust the Echo, Treble and Bass to your liking.

Recording from Microphone to your Mobile Device

1. Connect a Micro USB to 3.5mm cable audio cable from under the Square speaker box on the microphone to your mobile device.(Included)
2. Download any Karaoke recording APP and then follow the prompts in the App on how to record.

Note: The Bluetooth will automatically disconnect when audio cable plug in.

Specifications

Bluetooth Version V5.0
Transmission distance up to 10M
USB Flash Drive Input
Portable and easy to carry
Includes USB charging cable
Output voltage: 3.7V-4.2V
2 x 3W Speaker
Signal and noise ratio(SNR): 80db
Frequency Response: 20HZ-20KHZ
Battery: 1200mAh

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by C.J Global is use under license. Other Trademarks and trade names are those of their respective owners.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference, received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device,pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

GTECH is distributed by C.J Global Inc.
All rights reserved. 2010 Maple Ave Fair Lawn NJ 07410