







Wyze Sense Starter Kit QUICK START GUIDE	IN THE BOX Wyze Contact Sensor (battery pre-installed) x2 Wyze Motion Sensor (battery pre-installed) x1 Wyze Sensor Bridge x1 Quick Start Guide x1 Pin x1	Wyze Contact Sensor (WHCS1)  1 Reset button 2 Status Light	Wyze Motion Sensor (WHMS1)  1 Status Light 2 Reset button	Wyze Sensor Bridge (WHSB1)  1 Status Light 2 USB	SETUP 1 Insert the Sensor Bridge into the USB port of a Wyze Cam or Wyze Cam Pan. 	2 Log into your Wyze account and add a new device from the Home page. Follow the instructions in the Wyze app to finish setup.  3 Repeat Step 2 for each Contact and Motion Sensor.	 @WyzeCam
---	--	--	--	---	--	--	---

CONTACT SENSOR PLACEMENT  Ensure the two sections of the Contact Sensor are at most 2 cm apart when closed.	MOTION SENSOR PLACEMENT  Place Sensor approximately 6 feet high and ensure the Wyze Logo is in the top left corner.	STATUS LIGHT Bridge Solid yellow light The device is powered on, but not connected Flashing yellow/blue light The bridge is connecting Solid blue light The device is working properly Flashing blue light The device is ready to pair with a sensor	Sensors Red light Sensor triggered FCC Compliance Statement This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful	interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and	can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the	following measures: —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help.	NEED HELP? Resources & Support www.wyze.com/support Community www.wyze.com/forums
---	---	---	---	--	--	--	--