


取扱説明書

サウンドサーキュラー


外観



1	3.5mmオーディオ入力ポート	2	充電用Micro USB充電ポート
3	状態表示	4	ファンクションボタン
5	音量調節ボタン	6	電源スイッチ


Sound Circularの使用方法

① 電源オン/オフ



Sounder Circularは他の機器と約10分間接続されなかった場合、自動的に電源がオフになります

② スピーカーとBluetooth機器をペアリング




	青色ライトですばやく点滅	Bluetooth機器をペアリング
	青色ライトで点灯	接続に成功
	赤色ライトで点灯	充電必要

Sound Circularは電源をオンにしたとき、最後に接続した機器と自動接続をします（機器がオフの状態時）。それ以外の場合、ペアリングモードになります。

他の機器と接続したい場合、接続済みの機器との接続を切り、電源スイッチを二回押すと再度ペアリングモードになります。


ペアリングができない場合、ペアリングの履歴を一度削除し、お使いの機器とSound Circularの距離が90cm以内であることを確認した上で、再度ペアリングを行ってください。

③ AUX経由での接続



AUXモードにしたい場合、Bluetooth接続を切り、電源スイッチを二回押すとモードが切り替わります。
AUXモードにあるとき、音声の調整は接続機器側の再生機能を操作してください。

④ Sound Circular本体の充電



	赤色ライトで点灯		充電中
	ライト消灯		充電完了

初回ご使用前に、Sound Circularの電量はフル状態にあることを確認してください。

操作方法

	× 1	電話をする/切る
	>1s	着信を拒否
	× 1	再生/一時停止
	× 2	次の曲
		音量を大きく/小さくする

製品仕様

入力	5 V ≒ 2 A
再生可能時間 (音量や内容により異なる)	最大32時間
オーディオ出力	5 W × 2
インピーダンス	4 Ω
動作範囲	20 m / 66 ft
サイズ	132 x 132 x 36 mm / 5.2 x 5.2 x 1.4 in

充電時間 (電流により異なる)	4 hours
ドライバ	1.5" x 2
周波数応答	100Hz - 20 KHz
ブルートゥースバージョン	4.0
防水等級	IP 68
重さ	381g/ 13.4 oz

ご注意ください

1.屋外で使用する際は、周りの安全に十分に注意してご使用ください。屋外で使用する際は、周りの状況がわかるように音量を適度に調整してご使用ください。また、交通量の多い道路など安全に注意が必要な場所での使用は避けてください。

2.小さなお子様の手の届くところに保管しないでください。誤飲など思わぬ事故を招く場合があります。

3.本体は精密な電子機器のため衝撃や振動の加わる場所、強い磁力の発生する場所、静電気の発生する場所などでの使用・保管は避けてください

4.車載機器と電波干渉が起こる場合は使用しないでください。ご使用の車により、まれに車載機器との間で電波干渉が起こる場合があります。そのような場合は、本製品の使用を中止してください。

5.充電中は、本製品および充電用USBケーブルの周りに物を置かないでください。発熱、発火、火災、やけどの原因となります。

6.ご使用の際は、接続機器の取扱説明書の指示に従ってください

本製品は、パソコンや携帯電話などと無線通信による使用が可能です。接続先の機器により設定方法や注意事項が異なります。ご使用の際はこれらの機器の取扱説明書をよく読み、注意事項に従ってください。

7.定期的に充電してください

本製品を長期間使用しない場合でも、1ヶ月に1度を目安に充電してください。バッテリーが膨張したり、劣化の原因となります。

8.IP68防水性能付きですが、水深10mを超えないでください

取り扱い上の注意

1.万一、異常が発生したときは

本製品から異臭や煙が出たときは、ただちに使用を中止し、電源を切り、充電中の場合は、付属の充電用USBケーブルをUSB ACアダプターなどのUSB電源から抜いてください。その後は本製品をご使用にならず、販売店にご相談ください。

2.高温のまま放置しないでください

本製品は精密な電子機器です。高温、多湿の場所、長時間直射日光の当たる場所での使用・保管は避けてください。車の中には絶対に設置しないでください。本製品を高温の車内に長時間放置しておくこと、内部電池の破損・発火・故障の原因となり大変危険です。また、周辺の温度変化が激しいと内部結露によって誤動作する場合があります。

3.充電が終わったら、必ず充電用USBケーブルを取り外してください。また、必要な充電時間を終えて充電が完了しない場合も、いったん充電用USBケーブルを取り外してください。所定の充電時間を超えて充電した場合、内部電池が発熱・発火・破裂する危険性があります。また、電池寿命に影響を与える場合があります。

4.着信音量の設定には十分気をつけてください

携帯電話と接続して使用しているときに、着信音に驚いて事故の原因となったり、心臓に影響を与える恐れがあります。

5.分解しないでください

本書の指示に従って行う作業を随いては、自分で修理や改造・分解をしないでください。感電や火災、やけどの原因になります。

6.接続に使用するコードを傷つけないでください

火災や断線の原因となります。


7.病院内や航空機の中などでは使用しないでください

高度な安全を要求される場所では絶対に使用しないでください。特定医療機関や航空機の計器類などの誤動作の原因になります。



TELEC 本製品はモジュール単体で、電波法で定めるところの技術基準適合認証(技適)を取得済みです。


At a Glance



1	3.5mm AUX input	2	Micro USB charging port
3	Status indicator	4	Function key
5	Volume buttons	6	Power button


Using Your Sound Circular

① Turn on / off



Sound Circular will automatically turn off after 10 minutes if no device is connected.

② Pair with your device




	Rapidly flashing blue	Pairing mode
	Steady blue	Connected to a device
	Steady red	Low power

When turned on,Sound Circular will automatically connect to the last connected device if available.If not,Sound Circular will enter pairing mode.

To pair a different device,first disable Bluetooth on the connected device or press double click to re-enter pairing mode. Then repeat the pairing steps.


Having connection problems? Remove Sound Circular from your device's Bluetooth history, ensure it's less than 3 feet away then try pairing again

③ Connect via AUX



when turn to AUX mode,need to cut off bluetooth connection just double click to repair mode
when using AUX mode, control audio playback via the connected device

④ Charge your Sound Circular



	Steady red		Charging
	Steady white		Fully charged

Use the included USB cable to charge your Sound Circular and make sure it is fully charged before first use.

Controls

	× 1	Answer / end call
	>1s	Reject call
	× 1	Play / pause
	× 2	Skip forward
		Volume up / down

Specifications

Input	5 V ≒ 2 A
Play time (varies by volume level and content)	Up to 32 hours
Audio output	5 W × 2
Impedance	4 Ω
Range	20 m / 66 ft
Size	132 x 132 x 36 mm / 5.2 x 5.2 x 1.4 in

Charging time (varies by electric current)	4 hours
Driver (full range)	1.5" x 2
Frequency response	100Hz - 20 KHz
Bluetooth version	4.0
Waterproof rating	IP 68
Weight	381g/ 13.4 oz

Safety Instructions

1. Avoid dropping.
2. Do not disassemble.
3. Avoid extreme temperatures.
4. Use original or certified cables.
5. do not submerge in water under 10 meters
6. Do not use any corrosive cleaner/oil to clean.
7. Do not use the device outdoors during thunderstorms.

Notice

This product complies with the radio interference requirements of the European Community.

This product is designed and manufactured with high quality materials and components, which can be recycled and reused.

This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.

Fcc Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning:Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio / TV technician for help.

RF Warning Statement

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Owner's Manual

Sound Circular