


 CRE-NORDIC DANISH DESIGN Bluetooth Speaker with LED Light and Champagne Cooler Model: LUX 1 Operating manual Version 1.1 2019	Introduction Dear Customer, Thank you for purchasing our Cre-Nordic LUX 1. This product complies with the statutory national and European requirements. To maintain this status and to ensure safe operation, you as the user must observe these operating instructions!  These operating instructions are part of this product. They contain important notes on commissioning and handling. Also consider this if you pass on the product to any third party. Therefore, retain these operating instructions for reference! All company names and product names are trademarks of their respective owners. All rights reserved. 1.Intended use This LUX 1 is intended to be used as a lifestyle product. The product serves as a multifunctional speaker and light. Its top chamber can be used for chilling champagne or used as a planter. Any use, other than described above, can damage the product. Additionally, this is connected to dangers, such as short circuit, fire, electric shock, etc. No part of this product must be modified or converted! Read these operating instructions completely and attentively; they contain a lot of important information on setup, function and operation. Always observe the safety information! 2.Box contents - Bluetooth speaker and LED light - Operating Manual - USB cable - Wooden Support Stands - Silicone stands with Screws	3.Safety information The warranty/guarantee will expire if damage is incurred resulting from non-compliance with these operating instructions. We do not assume any liability for consequential damage! Nor do we assume any liability for damage to property or personal injury caused by improper use or failure to observe the safety information. In such cases the guarantee/warranty will expire! The following safety information is intended not only for the protection of your health but also for the protection of the device. Please read the following items carefully: The unauthorized conversion and/or modification of the product is inadmissible for safety and approval reasons. The product is only suitable for dry areas. Do not expose it to for long periods of time to direct sunlight, heat, cold, dampness or wetness; otherwise, it may cause damage to the product. There is danger of fire or potentially fatal electric shock. If this is the case, first power down the respective socket (e.g. switch off circuit breaker) and then pull the power adaptor from the socket. Disconnect all cables from the device. Do not operate the product anymore afterwards. Do not place any open sources of fire, such as burning candles, on the device. Handle the product with care. It can be damaged by impact, blows or when dropped even from a low height. Note: The handle and wood parts are not water proofed and need to be kept dry at all times. This product is not a toy and not suitable for children . Children cannot judge the dangers involved when handling electrical devices. Do not leave packing material unattended. It may become a dangerous toy for children. Also observe the safety and operating instructions of any other devices that you connect to the speaker.	4.Product overview  Keys function & Bottom A1 On/Off switch A2 USB charging port Charging B1 USB cable Assembly Parts C1 Wooden Support Stands C2 Silicone Support Fee C3 Screws LED indicator D1 Charging LED D2 Mode LED
5.Setup mono speaker (single-unit) connection Step 1: Before first use, turn off the Bluetooth function of any other Bluetooth devices near the speaker. Step 2: Press the On/Off key for about 3 seconds on the unit. You will hear a start-up sound and the blue LED indicator light will flash. Step 3: Short press the On/OFF key ONCE. Step 4: Now turn on your "Bluetooth" on your mobile phone and search for LUX 1 on discoverable devices in your Bluetooth menu and pair with the unit. The blue indicator light on the unit will then turn off. You can now play your favorite music. 6.Setup stereo speaker connection Step 1: Before first use, turn off the Bluetooth function of any other Bluetooth devices near the speakers. Step 2: If you have purchased two (2) LUX 1 products and wish to pair them, press the On/Off switch for about 3 seconds on the first unit and repeat for the second unit. There will be a start-up tone and the blue LED indicator light will flash on both units.	Step 3: Double press the On/Off button on one of the units. (This unit is now set as the LEFT channel speaker) Let the second unit automatically connect to the LEFT channel speaker. You will hear a "beep" tone once the connection between the second unit and the LEFT channel speaker is successfully made, the second unit's blue light indicator at the bottom will then turn off. (This unit is now set as the RIGHT channel speaker) The LEFT channel speaker unit's blue LED indicator will still be flashing. Step 4: Now turn on the "Bluetooth" on your mobile phone and search for LUX 1 in discoverable devices in your bluetooth menu and pair with the unit. The Blue light indicator on the LEFT channel speaker will then turn off. You can now play your favorite music. 7.Pairing to new phone Step 1: While the product is on and connected to a device, press the On/Off key once on any of your LUX 1 products. Once the connection hassuccessfully been disconnected from the phone, a tone can be heard, and the unit's blue LED indicator will start flashing. Step 2: You can now turn on the "Bluetooth" on your mobile phone and search for LUX 1 in discoverable devices in your Bluetooth menu and pair with the unit. The blue LED indicator light on the LEFT channel speaker unit will then turn off. 8.Changing from Stereo speaker to a Mono speaker Press the On/Off key TWICE on any of your LUX 1 products that are already connected. The connection between the units will now be disconnected and once successful, a tone can be heard, and the blue LED indicator can be seen flashing on both your LUX 1 products.	9.Charging Remove the silicone part on the side of your LUX 1 product and insert the USB-C jack into the USB port. If you are using the product for the first time, it is recommended to leave the USB jack plugged-in for a minimum of 12 hours, in order to charge the internal battery fully. General Notes: For an optimal experience, keep your mobile device within 10m to the LEFT channel speaker unit. Position your 2 units in the same room or outdoor area within 3-5m of each other, free from obstructions. The performance of your LUX 1 products may vary based on device, distance and other environmental factors. 10.Maintenance and cleaning Servicing or repair must only be carried out by a specialist or specialist workshop. The product contains no parts that require servicing by you. Therefore, never open the product (except for the procedures described in these operating instructions). A dry, soft and clean cloth is sufficient for cleaning the outside.  Never use any aggressive cleaning agents, alcohol or other chemical solutions that would damage the casing (discoloration). 11.Disposal a) Product Electronic devices are recyclable waste and must not be disposed of in the household waste! At the end of its service life, dispose of the product according to the relevant statutory regulations. Remove any inserted batteries/rechargeable batteries and dispose of them separately from the product.	b) Batteries and Rechargeable Batteries  You as the end user are required by law (Battery Ordinance) to return all used batteries/rechargeable batteries. Disposing of them in household waste is prohibited! Batteries/rechargeable batteries that contain any hazardous substances are labeled with the adjacent icon to indicate that disposal in domestic waste is forbidden. The descriptions for the respective heavy metals are: Cd=cadmium, Hg=mercury, Pb=lead (the names are indicated on the battery/rechargeable battery e.g. below the rubbish bin symbol shown on the left). You may return used batteries/rechargeable batteries free of charge at the official collection points in your community, in our stores, or wherever batteries/rechargeable batteries are sold. You thus fulfill your statutory obligations and contribute to the protection of the environment. FCC Warning This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any inte rference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interferenceto radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

成品尺寸：90X90MM 封面157G双铜版纸过哑胶 内页105G铜版纸 2颗骑马钉装订