



Getting started



FCC This device complies with part 15 of FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Caution Any changes or modifications not expressly approved by SenseAnywhere could void the user's authority to operate this equipment.

The SenseAnywhere system



1

Create account and redeem credits




saclient.com/redeem

or



2

Install and register AccessPoint



Management > Register device





Help > Getting Started




3

Register sensor




Management > Register device





4

Install sensor



> 0°C
during installation



concrete



walls



glass



metal



wood

5

Monitor data and insights

