# TAGRY

TAGRY H08
Active Noise Cancelling Wireless Headphones

# User Manual

## Content

Packing List and Specifications....01
Product Description....02
Pre-Use and Maintenance....03
How to Wear?....04
Power on/off....04
Pairing with Your Device....05
Connect to a New Device....05
Button Controls....06
ANC Mode....07
Reset....07
Wired Listening Mode....08
Charging....08
Battery Warning....09
FCC Caution, ISED Warning & CE Caution....09~10
Troubleshooting....11~12

## Customer Service

Please kindly scan the QR code to activate lifetime warranty of your headphone within 15 days.

www.tagry.pro

## Packing List

Headphones *1



Type C Charging Cable *1



3.5mm AUX Audio Cable *1

User Manual



Headphone Pouch *1

## Specification

| | |
|---|---|
| Model No. | H08 |
| Product Name | Headset |
| Speaker Size | Φ40.0mm |
| Maximum Working Range | 10m/33ft |
| Capacity | 3.7V 850mAh, 3.15Wh |
| Input | Input:5V ⎓ 1.6A |
| Playtime (With ANC mode off) | 100H |
| Playtime (With ANC mode on) | 70H |
| Charging Time | 1H |
| FCC ID | 2ANYH-H08 |
| Support Device | Smart Phone, PC, Laptop, Smart Watch, Tablet, etc |

## Product Description





## Pre-Use

Please check the following components for integrity before first use:

1. Check if the headphones have power: Press and hold the power button on the headphones and see if the LED indicator lights up. If there is no power, please use the provided Type C charging cable to charge the headphones.
2. Check if each headphone headband is adjustable and if the headphone stands are adjustable.
3. Check if there are any missing parts of the product.

If you encounter any of the above issues, please contact us immediately, and we will assist you in resolving them.

## Maintenance

1. Please charge your headphones regularly to ensure you have enough battery for listening to music each time.



2. Please clean the ear pads and headband of your headphones regularly. You can use a cotton cloth dipped in alcohol to wipe the ear pads and headband.



3. Please use a pointed cotton swab to clean the 3.5mm audio jack and USB-C port regularly to ensure wired listening and headphone charging are not affected.



Clean the 3.5mm audio jack and usb-c port

4. When you are not using the headphones, please fold them and store them in the provided storage bag.



## How to Wear

Please follow the diagram below to adjust the headphones to a comfortable position.



## Power on/off

### Power on

Press and hold the "Power on/off" button for 2s to enable the headphones, you will hear a "power on"prompt from the headphone, and the indicator light will flash blue for 1s.



### Power off

Press "Power on/off" Button for 5s to power off the headphones, you will hear a prompt "power off" from headphone, and the indicator light will flash red for 1s.



⚠ **Notice:**

1. Headphones can not power off when you are in phone call.
2. If the headphones are turned on, not paired with any device, they will automatically power off after more than 3 minutes, but the ANC function will not be turned off if you initially enabled the ANc function.
3. When the headset is turned off, you can still press and hold the "ANC" button to enable active noise cancellation without enabling bluetooth function.

## Pairing with Your Device

### 1. First time pairing with your device

a. Just press "⏻" to turn on headphones, then wear headphones and enable the bluetooth of your device.
b. Search and choose "H08" on bluetooth menu, then you will hear a prompt "Connected"

### 2. Next time pairing

For device second time pairing, just enable bluetooth of your device and turn on the headphones, they will connected automatically.

## Connect to a New Device

▶ Step 1: Unpair earbuds "H08" from the Bluetooth-Enabled device that's connected. Earbuds will disconnect from the device. The led indicator light on headphones will flash blue and red alternately.

▶ Step 2: Activate Bluetooth on your new device, search and choose "H08" on new device to connect.



① Disconnect H08 with 1st device



② Connected H08 with new device

## Button Controls



**Power on**
Press and hold for 2s

**Power off**
Press and hold for 5s

**ANC on**
Press and hold for 2s

**ANC off**
Press and hold for 2s

### Music Control

**Play/Pause**
Once click

**Volume +**
Once click

**Next Track**
Double click

**Enable Voice assistance**
Double click

**Volume -**
Once click

**Previous Track**
Double click

### Phone Call Control

**Answer Call**
Once click

**End Call**
Once click

**Reject Call**
Press and hold for 2s

## ANC Mode

### Headphones Turned Off

You can enable **Active Noise Cancelling** function when headphones are in power off status.

**Method:** Just press "**ANC**" button for 2s, no need to power on headphones.



### Headphones Turned On

When headphones powered on, of course, you can press "**ANC**" button for 2s to activate ANC function.



## Reset

### Method for Reset:

Press and hold the "V+" and "V-" keys simultaneously for 5 seconds when headphones is power on Then, headphones will be reset, and enter pairing mode, the led indicator light will flash red and blue alternately.



### When Headphones Should be Reset

① You can not find the device where the headphones connected to.
② Headphones disconnect with your device frequently.
③ Headphones have no sound even connected with device and the volume of device and headphones has been adjust to maxmium.

## Wired Listening Mode

### When headphones is powered off

Just insert the 3.5mm AUX audio cable we provided from your phone a other player which has 3.5mm audio jack.

### When headphones is powered on

When headphones is power on or headphones is connected with your device via bluetooth.Once insert the 3.5mm AUX audio cable we provided, the headphones will turn off automatically.

Then headphones will change to wired listening mode, it is powered by the device which play music or video now.



⚠ **Notice:** ANC mode can not be enabled when headphones in wired listening mode.

## Charging

Please plug the provided USB-C charging cable (included) into the headphones and connect it to a charger (not included) to charge the headphones.

Please use a 10W and above charger to charge the headphones to experience faster charging.



⚠ **Notice:**

1. When you charge the headphones, even if they are turned on, they will automatically power off once charging begins. While charging, the indicator light will flash red for 2 seconds, from bright to dim, in a repeating cycle. Once the headphones are fully charged, the indicator light will remain blue.
2. Battery Low: When the battery life is less than 30 minutes, you will hear "Low battery please charge", prompted every 5min, prompted 4 times, the fifth prompted "power off" and the headphones power off !

## Battery Warning

Using the wrong battery can cause fire and other hazards (for example, in the case of some lithium battery types).

1. Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
2. Do not leaving a battery in an extremely high temperature surrounding environment that can resuilt in an explosion or the leakage of flammable liquid or gas.
3. A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

## FCC Caution

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions,may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

— Reorient or relocate the receiving antenna.
— Increase the separation between the equipment and receiver.
— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
— Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## ISED Warning

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:
(1) this device may not cause interference, and
(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
(1) l'appareil ne doit pas produire de brouillage, et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device is compliance with RF exposure guidelines, users can obtain Canadian information on RF exposure and compliance.

Le présent appareil est conforme Après examen de ce matériel aux conformité ou aux limites d'intensité de champ RF, les utilisateurs peuvent sur l'exposition aux radiofréquences et la conformité and compliance d'acquérir les informations correspondantes.

## Caution

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

⎓ The symbol indicates DC voltage

RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE).
This means that this product must be handled pursuant to European
directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.
This product can be used across EU member states.
The device is low power device, it can meet the requirement of the RF exposure.

NOTES:

1. High Sound Pressure
2. Hearing Damage Risk
3. Do not listen at high volume levels for long periods.

## Troubleshooting

### Q Headphones cut in/out when it connects with my phone via bluetooth.

A We kindly ask you to try the following troubleshooting steps as they have often proven helpful:

① Reduce the distance between your headphones and your audio device.

② Reset the headphones: Follow these steps to reset your headphones:

Step 1: Delete the pairing history from your Bluetooth device.

Step 2: Press the button on the "V+" "V- "5s simultaneously until the LED indicator flashes red and blue three times. Your headphoens are now successfully reset.

③ Reset your Bluetooth connection: Turn off Bluetooth on your device (phone/tablet/etc.) for at least 10 seconds and then turn it back on. Please note, quickly turning Bluetooth off and on will not reset the connection.

④ Close unused apps: Try closing any other apps you are not using on your device.

⑤ Test the headphones: Listen to downloaded music or videos to test the headphones.

⑥ Try another device: Please try using the headphones with another device (phone/tablet/etc.) to see if the issue persists.

### Q What should I do if the ANC function doesn't work even though I have pressed "ANC" button for 2s?

A ① Please make sure that the headphones are not plugged into any AUX cable, because once the headphones are plugged into the audio cable to listen to a song through a device, the ANC noise cancellation function will be automatically disabled.

② If you are sure that the headset is not plugged into any AUX audio cable, please reset your headset and press the ANC button again for 2s to enable the ANC function.

③ If above methods do not work, please contact us for help.

### Q Headphones can not connected with my phone.

A First, please make sure your headphones is power on,then follow steps below.

① Disable and re-enable the Bluetooth function.
② Remove the headphones pairing name from the Bluetooth list on your device.
③ Clear the pairing list on your device. Connect again.

If above method do not work, please reset your headphones and reconnect with your device.

V1.1 20240829

CE RoHS
Made in China

H08说明书
尺寸:160.5*180.5mm
材质:108g双铜纸
装订方式:骑马钉