


4in

ergonomic wireless mouse



included

- Ergonomic wireless mouse
- USB-A 2.4Ghz receiver
- USB-A to USB-C charging cable

product requirements

- Compatible devices

charging the mouse

- A full charge requires approximately 3 hours and can provide up to 50 hours of use when fully charged.
 - Plug the USB-C end of the charging cable into the mouse and plug the opposite end into a USB-A power supply of at least DC 5V 300mA.
- WARNING:** please use UL compliant power supply.
- The LED indicator will turn solid red while the mouse is charging, when charging is complete the LED indicator will turn off.

Note: You can use the mouse while it is charging.

connection method

2.4Ghz wireless connection mode:

- Fully charge the mouse with the provided USB cable before use
- Switch the power switch to 2.4G.
- The mouse and receiver will automatically pair, the indicator light will flash green and then fade when pairing is successful.

Bluetooth connection mode:

- Switch the power switch to BT, the indicator light will flash blue.
- Use the Bluetooth settings on your device to pair with "heyday mouse". The indicator will

fade when pairing is successful.

Note: When the mouse is powered on it will automatically re-pair in the previously used settings.

adjusting DPI

- Mouse sensitivity can be quickly adjusted by pressing the DPI button, cycling through 800 > 1200 > 1600 levels. A higher DPI value results in faster cursor movement. The corresponding indicator light for your current mode (Blue for BT/ Green for 2.4G) will flash to confirm the setting:
800 DPI: The indicator light flashes once.
1200 DPI: The indicator light flashes twice.
1600 DPI: The indicator light flashes three times.

troubleshooting

- If the mouse is not connecting, make sure the receiver is properly plugged into the computer or make sure wireless pairing is enabled on your device and that it has successfully paired.
- If the mouse is not responding, check if your battery is low. If it is recharge the mouse.
- If the connection keeps dropping, move closer to the device or reduce interference from other wireless devices.
- Having trouble with your device? Be sure you're running the latest software on your devices. You can do this by doing a software update in the settings of your device.

need some help?

Can't get it to pair? Just have a question?



call us at: 1-833-TGT-Tech or: 1-833-848-8324

safety

- Do not use near any water source.
- Do not modify or repair this device.
- Do not use chemical detergents to clean your device, use a soft dry cloth.

heyday

Wireless Mouse Model: BEM502 FCC ID: 2A023-BEM502; Receiver Model: BEM501R FCC ID: 2A023-BEM501R Working distance: 8-10m
Input 5v ~300mA Made in Vietnam
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Target Corp. Mpls. MN, 55403 Phone: 612-304-6073

For qualified repair specialists requesting repair information and parts please contact the original manufacturer at customersupport@getmyfindyours.com

front

back

5.3in