


4in

full size wireless keyboard



included

- Full size keyboard
- USB-A 2.4Ghz receiver
- 2PC AAA Battery

product requirements

- Compatible devices

indicators

- Num lock indicator:
flashing green - 2.4Ghz wireless connecting
flashing blue - Bluetooth 1 pairing
flashing red - Bluetooth 2 pairing or low battery
- Caps lock indicator:
Solid Red - Caps Lock

keyboard multimedia keys (Works with most Windows operating system computers)

- Fn Key + F1 - Media Player
- Fn Key + F2 - Volume -
- Fn Key + F3 - Volume +
- Fn Key + F4 - Mute
- Fn Key + F5 - Previous Track
- Fn Key + F6 - Next Track
- Fn Key + F7 - Play/Pause
- Fn Key + F8 - Stop
- Fn Key + F9 - Home
- Fn Key + F10 - Mailbox
- Fn Key + F11 - My Computer
- Fn Key + F12 - Collect

connection method

2.4Ghz wireless connection mode:

- Remove the battery cover on the back of the keyboard and install 2 AAA batteries, align the "+" and "-" symbols.
- Plug the receiver into your device.
- Hold the FN+3 key. When the Num lock indicator flashes green, the keyboard is in

connecting mode.

- The keyboard and receiver will automatically connect. The indicator will fade when pairing is successful.
TIP: To use the media keys hold FN and press the secondary function (play/pause, volume up/down, etc.) you'd like to use.

Bluetooth connection mode:

To 1 device

- Remove the battery cover on the back of the keyboard and install 2 AAA batteries, align the "+" and "-" symbols.
- To enter pairing hold FN+1, the Num lock indicator will flash blue.
- Use the Bluetooth settings on your device to pair with "Keyboard". The indicator will fade when pairing is successful.

To 2 devices

- After connecting the first device using the above method, hold FN+2 to enter pairing again, and the Num lock indicator will flash red.
 - Use your second device to pair with "Keyboard". The indicator will fade when pairing is successful.
 - Press FN+1 or FN+2 to switch between the two devices.
- NOTE:** The keyboard will automatically pair the same way the next time it is powered on. The keyboard will automatically enter sleep mode after 30 seconds of inactivity.

troubleshooting

- If the keyboard is not connecting make sure the receiver is properly plugged into the computer or make sure wireless pairing is enabled on your device and pairing is successful.
- If the keyboard is not responding check if the battery is low. If it is, please replace the battery.
- If you're still having connectivity issues, move closer to the device or reduce interference from other wireless devices by moving them away from the keyboard.
- Having trouble with your device? Be sure you're running the latest software on your devices. You can do this by doing a 'software update' in the settings of your device.

need some help?

Can't get it to pair? Just have a question?



call us at: 1-833-TGT-Tech or: 1-833-848-8324

safety

- Do not use near any water source.
 - Do not modify or repair this device.
 - Do not use chemical detergents to clean your device, use a soft dry cloth.
 - When the AAA battery is dead, remove it promptly to prevent battery leakage from corroding the product.
- WARNING:** The battery (battery or batteries or battery pack) shall not be exposed to excessive heat such as sunshine, fire or the like.

heyday

Keyboard Model: BGK01 FCC ID: 2A025-BGK01; Receiver Model: BGK01R FCC ID: 2A025-BGK01R Working distance: 8-10m Made in China
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Target Corp. Mpls. MN, 55403 Phone: 612-304-6075

For qualified repair specialists requesting repair information and parts please contact the original manufacturer at customersupport@gemsfindyours.com

6.6in

front

back