


4in

full size wireless keyboard



included

- Full size wireless keyboard with tablet holder
- USB-A 2.4Ghz receiver
- 2PC AAA batteries

product requirements

- Compatible devices

indicators

- Battery indicator:
Flashing red: low battery
- Num Lock indicator:
Flashing green - Bluetooth 1 pairing
Fade: Bluetooth paired successfully
Solid green - Num Lock
- Caps Lock indicator:
Flashing green - Bluetooth 2 pairing
Fade: Bluetooth paired successfully
Solid green - Caps Lock
- Scroll Lock indicator:
Flashing green - 2.4Ghz wireless connecting
Fade - 2.4Ghz connection successful
Solid green- Scroll Lock
- Combination indicators:
Fn Lock ON - Scroll Lock, Caps Lock and Num Lock indicators flash green 3 times simultaneously
Fn Lock OFF - Scroll Lock, Caps Lock and Num Lock indicators stay lit green for 2 seconds

keyboard multimedia keys (Works with most Windows operating systems)

- Fn Key + F1 - Brightness -
- Fn Key + F2 - Brightness +
- Fn Key + F3 - Desktop
- Fn Key + F4 - Search
- Fn Key + F5 - Show Window
- Fn Key + F6 - Previous Track
- Fn Key + F7 - Play/Pause
- Fn Key + F8 - Next Track
- Fn Key + F9 - Mute
- Fn Key + F10 - Volume -
- Fn Key + F11 - Volume +
- Fn Key + F12 - Screen Lock
- Fn Key + Esc - Fn Lock ON/OFF

connection method

2.4Ghz wireless connection mode:

- Remove the battery cover on the back of the keyboard and install 2 AAA batteries, align the "+" and "-" symbols
- Flip the power button to the ON position
- Plug the receiver into your device

front

- Press 2.4G on the right numeric keypad, the Scroll Lock indicator will flash red
- The keyboard and receiver will automatically connect. The indicator will fade when connecting is successful
tip: To use the media keys hold FN and press the secondary function (play/pause, volume up/down, etc.) you'd like to use
note: Ensure Fn Lock is off for proper functionality
- **Bluetooth connection mode:**
pair with device 1 (channel 1)
• Remove the battery cover on the back of the keyboard and install 2 AAA batteries, align the "+" and "-" symbols
- Flip the power button to the ON position
- To enter pairing Press #1 on the right numeric keypad, the Num Lock indicator will flash green
- Use the Bluetooth settings on your device to pair with "Heyday KB". The indicator will fade when pairing is successful
- pair with device 2 (channel 2)
• Press #2 on the right numeric keypad to enter pairing again, and the Caps Lock indicator will flash green
- Use your second device to pair with "Heyday KB". The indicator will fade when pairing is successful
- **switching devices**
• Press FN+ #1 or FN+ #2 to switch between the two devices
note: The keyboard will automatically pair the same way the next time it is powered on
The keyboard will automatically enter sleep mode after 30 minutes of inactivity
tip: Hold 3 seconds to enter Bluetooth pairing mode for new device, disconnects prior device and re-pairs new one.

system mode switching guide

In 2.4Ghz connection:

Use the Fn combinations below to manually switch system modes:

- Fn Key + Q - Mac Mode
- Fn Key + W - Windows Mode
- Fn Key + E - Android Mode
- Fn Key + R - iOS Mode

In Bluetooth connection:

The keyboard will automatically match the system of your connected device, no manual mode changes needed

troubleshooting

- If the keyboard is not connecting make sure the receiver is properly plugged into the computer or make sure wireless pairing is enabled on your device and pairing is successful
- If the keyboard is not responding check if the battery is low. If it is, please replace the batteries
- If you're still having connectivity issues, move closer to the device or reduce interference from other wireless devices by moving them away from the keyboard
- Having trouble with your device? Be sure you're running the latest software on your devices. You can do this by doing a 'software update' in the settings of your device

need some help?

Can't get it to connect? Just have a question?



call us at: 1-833-TGT-Tech or: 1-833-848-8324

safety

- Do not use near any water source
- Do not modify or repair this device
- Do not use chemical detergents to clean your device, use a soft dry cloth
- When the AAA battery is dead, remove it promptly to prevent battery leakage from corroding the product
- Do not mix old and new batteries and Do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cad, ni-mh, etc.) batteries
WARNING: The battery (battery or batteries or battery pack) shall not be exposed to excessive heat such as sunshine, fire or the like

hegday

Keyboard Model: BGK04 FCC ID: 2A023-BGK04; Receiver Model: BGK04R FCC ID: 2A023-BGK04R Working distance: 8-10m

Made in China

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Target Corp. Mpls. MN, 55405 Phone: 612-304-6073

For qualified repair specialists requesting repair information and parts please contact the original manufacturer at customersupport@gemsfindyours.com

back