

BLUETOOTH SPEAKER

5B597BT



INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY AND
RETAIN FOR FUTURE USE

Getting Started

- Remove the product from the box.
- Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

Package Contents

- Dual True Wireless Bluetooth Speaker
- USB rechargeable cable
- 3.5mm AUX cable
- Instruction Manual


Key Features

- Set of 2 Wooden Wireless Speaker
- Built-in rechargeable battery
- Stream music
- Micro cable included for recharge

SAFETY INSTRUCTIONS

- Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.
- Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Do not use the unit with wet hands.
- Do not put objects into any of the openings.
- Keep the unit free from dust, lint etc.
- Do not use this unit for anything other than its intended use.
- Keep the unit out of reach of children.
- This appliance is not a toy.
- Do not use the handset at excessive levels as damage to hearing may occur.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat place, such as sunshine, fire or the like.

Description of Parts



1	Speaker
2	ON/OFF Switch
3	LED Indicator
4	Charging Port
5	AUX-input

INSTRUCTIONS FOR USE

Charging the speaker

The device has built-in rechargeable battery. When the battery is drained, device would turn OFF automatically. You would have to recharge the battery.

Plug the Micro USB end of the included USB cable into the charging port. Plug the other end into a USB port on your computer or other devices made for USB charging. The Red LED Light illuminates indicating that the device is being charged.

It takes 3-4 hours to fully charge the device. Once the device is fully charged, Red LED Light would turn OFF.

Turning ON/OFF the Speaker –

Slide the ON/OFF switch to ON position to turn on the speaker, or OFF position to turn off the speaker.

Pairing Speaker using Bluetooth Technology:

- Turn on the speaker.
- You would hear an indication tone and Blue LED will flash rapidly. The speaker is now in pairing mode.
(Note: Speaker will automatically pair with previously paired devices)
- Turn on the Bluetooth on your Mobile Phone, Tablet or Computer.
- It will search for various devices.
- The pairing name of our Bluetooth Speaker is “SL DUAL SPEAKER”, pair it with this device.
- If required, enter the password ‘0000’ to confirm to finalize pairing.
- Once paired successfully, you would hear another indication tone and the Blue LED will stay on.
- If you fail to pair it within the time frame or you want to pair it with a new device please follows the steps outlined above.

Select your favorite song at the Bluetooth device and music would now stream through Bluetooth speaker.

Play music using “Aux-In” Jack

- Turn ON the device.
- Insert the 3.5 mm Aux in cable (provided) to the Aux-in jack of the speaker. And, the other end of the cable to the audio device (such as computer / tablet / MP3 etc.).
- Select your favourite song at the source device and play.

(Note: When you insert 3.5 mm Aux in cable into the Aux-in jack of the speaker, the speaker will turn off its Bluetooth mode automatically. All the functions like play, pause, volume increase/decrease, next/previous track can be controlled only through source devices, while playing music in Bluetooth or Auxiliary mode.

Specifications –

Bluetooth® Version: 2.1+EDR
Wireless Distance: 33 feet
Speaker power: 2x5W
Dimension: 5-1/8” (L) x 3-1/2” (D) x 6-11/16” (H) per speaker
Weight: 31.3 oz per set
Power Input: DC 5V
Charging time: 3-4 hours
Play time: up to 1.5 hr (max volume)
Built-In Rechargeable Battery: 3.7V 800mAh
(Note: Battery life & charging time may vary based on usage & types of devices used.)

Troubleshooting

Problem	Possible Cause	Solution
Low sound level	Source (Tablet, Mobile Phone, Laptop, etc.) volume too low.	Adjust source volume.
	Battery dead	Charge Battery.
Sound distorted	Battery nearly dead	Charge Battery.
No sound at all.	Source (Tablet, Mobile Phone, Laptop.) turned off.	Turn the source on.
	Speaker turned off.	Turn the speaker on.
	Volume turned down source.	Adjust volume source.
	Media paused on source.	Play media from source.

Care and maintenance

Clean the unit with a soft, damp cloth. Never use chemicals or hard abrasives.
Keep this unit away from wet or damp surroundings.

FCC Instructions

Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Limited Warranty

This manufacturer’s product warranty extends to the original consumer purchaser of the product. Neither the retailer nor any other company involved in the sale or promotion of this product is a co-warrantor of this manufacturer warranty.

WARRANTY DURATION: All materials and workmanship are warranted to the original consumer purchaser for a period of ninety (90) days from the original purchase date.

WARRANTY COVERAGE: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty doesn’t cover the following which may be supplied with this product, including but not limited to; LCD Screens, glass parts, lenses, bulbs etc. This warranty is effective only if the product is purchased and operated in USA and Canada, and does not extend to any units which have been used in violation of written instructions furnished by manufacturer or to units which have been altered or modified or, to damaged products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

WARRANTY DISCLAIMERS: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for manufacturer any other liability in connection with the sale of our products. There shall be no claims for defects or failure under any theory of tort, contractor commercial law including but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract. Under no circumstances will Manufacturer’s / Distributor’s maximum liability exceed the retail value of the product.

WARRANTY PERFORMANCE: During the above 90 day warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at manufacturer’s option). The repaired or replacement product will be in warranty for the balance of the 90 day warranty period and an additional one-month period. No charge will be applicable for such repair or replacement.

SERVICE AND REPAIR: If service is required for this product, you should first contact Midwest Trading Group Customer Service at info@mtradinggroup.com or by calling 1 (866) 815-4714, Monday to Friday 10am to 6pm EST.

NOTE: Manufacturer cannot assume responsibility for loss or damage during incoming shipment. As a precautionary measure, carefully package the product for shipment, and insure it with the carrier. Be sure to enclose the following details with the product: your full name, return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.