

Remote control operation instructions:

There are two keys on the remote control, as shown in Figure 1.

1. ▲ key: When the stairs are moved up the ladder, press the ▲ key
2. ▼ key: When you make the stairs down the ladder, press the ▼ key

Remote Control Specifications:

1. Operating frequency: 433.92MHZ
2. Operating voltage: DC12V

Matters needing attention: When the remote control distance becomes shorter, please change the battery

You can use the ▲ or ▼ key on the remote control to operate the stair lift to the desired position



Figure 1.

FCC Compliance Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.