




N

C=80 M=75 Y=70 K=45

英文

Overview

Microphone

Micro USB Charging Port

Indicator Light

Power / Multi-function Button
Ear Tip

Turn On / Off and Charge

Status	LED Indicator
Charging	Solid Red LED
Fully Charged	Solid Blue LED
Turn On (Earbud needs to be unplugged)	Press and hold the power button until the blue LED flashes
Turn Off (Earbud needs to be unplugged)	Press and hold the power button until the red LED flashes

Connect SonaBuds ES

Connect to Your Phone (Stereo Mode)

NOTE : Both earbuds come pre-paired with each other
Turn on both of your earbuds, then turn on Bluetooth on your phone and select "Dashbon SonaBuds ES", the alternating blue / red LED flash will go away, and you are done!

Connect to Your Phone (Mono Mode)

A. RESET
Charge your earbuds. While your earbuds are being charged, press and hold the power button on one of the earbuds for about 6 seconds to reset. You will see the purple LED flashing once and the reset action is complete. Repeat the same action on the other earbud to reset.

B. Connect the 1st Earbud to the 1st Phone
While the earbuds are off, press and hold the power button for about 4 seconds to enter pairing mode (you will see alternating blue / red LEDs flash). Turn on the Bluetooth on your phone and select "Dashbon SonaBuds ES" to connect with this earbud.

Connect the 2nd Earbud to the 2nd Phone
If you have another phone, then pick up the second earbud and repeat Step B to complete the process.

Connect SonaBuds ES to Multiple Bluetooth Devices

Step 1 : Turn off Bluetooth on your first device.
Step 2 : Turn on the Primary Earbud to Pair.
The primary earbud is the left channel (listen to the voice prompt when turning on the earbuds). While the primary earbud is off, press and hold the power button for about 4 seconds to enter pairing mode (you will see alternating blue / red LEDs flash). Turn on Bluetooth on your device and select "Dashbon SonaBuds ES" to connect with this earbud.
Repeat these steps to pair with another Bluetooth device.

Listen to Music

Command	Click Action
Play / Pause	Single Click Power Button
Skip to the Next Song	Double Click Power Button

Calls and Voice Command (Controls via Primary Earbud Only)

Command	Click Action
Answer or End a Call	Single Click Power Button
Activate Siri or Google Now	Press and Hold Button for 2 seconds

Simple 3-Step Process : Reset, Pair, and Connect

RESET
Charge your earbuds. While your earbuds are being charged, press and hold the button on one of the earbuds for about 6 seconds to reset. You will see the purple LED flashing once and the reset action is complete. Repeat the same action on the other earbud to reset.

PAIR
While the earbuds are off, press and hold the power buttons of two earbuds for about 4 seconds to enter pairing mode (you will see alternating blue / red LEDs flash). The left and right earbuds will pair with each other within 10 seconds.

CONNECT
After left and right earbuds are paired successfully, turn on Bluetooth on your phone and select "Dashbon SonaBuds ES", the alternating blue / red LED flash will go away, and you are done!

NOTE : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions :

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.