



8+

IMPORTANT SAFETY PRECAUTIONS

1. READ ALL INSTRUCTIONS BEFORE USING YOUR HEADSET.
2. Do not use your headset near water. Clean using a dry or slightly moist cloth.
3. Do not place your headset on any wet surfaces.
4. Do not allow children or the infirm to play with your headset without adult supervision.
5. Do not expose your headset to excessive heat, flames or fire.
6. Always press all buttons or switches carefully. Do not mishandle your headset.
7. Do not use in extremely dry environments, as this can lead to static discharge during usage.
8. Do not expose your headset to temperatures above 40°C. Keep out of direct sunlight.
9. Do not attempt to repair this product yourself. Contact a qualified service center if your headset is in need of service.
10. Do not drop, puncture or expose your headset to excessive trauma.
11. Your headset is not intended for commercial use.
12. Unplug this device when not in use for long periods of time or during lightning storms.
13. Do not place near objects that generate a strong magnetic field.



- The device is equipped with an integrated lithium ion battery. The battery cannot be replaced.
- Do not attempt to remove the battery from the device.
- Do not dispose of in fire or expose to excessive heat.
- Do not crush, puncture, incinerate, or short circuit external contacts.
- Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.

- Nerf Wireless Headset with Communication Mic
- Micro USB Charging Cable
- User's Manual with Warranty Information



Bluetooth Range: Up to 33 Feet (10 Meters)
Charging Input: DC 5V
Battery Type: Lithium Ion Battery
Charge Time: Approximately 2 Hours
Play Time: Approximately 4 Hours*

*Applicable at 50% of maximum volume. Results will be lower when volume is higher.



●●●● (red) = Charging
○ (off) = Charging Complete



A hand is shown touching the 'Bluetooth' toggle switch on a smartphone screen. The toggle is currently in the 'ON' position, indicated by a blue bar and the word 'ON' in bold. Below the toggle, the text 'GAMI3056B connected' is visible.

PAIRED
Blue Flashing LED

3. The LED indicator light turn blue and flash when paired to your phone/computer.



⏮ V+

--Press to go to the next song in a playlist.



- Press to play or pause a song.
- Press to answer or end a phone call.
- Press and hold to reject an incoming call.



--Press to go to the last song in a playlist.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty
Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:
Call 1-877-397-8200 in the U.S. or visit our website at
www.sakar.com.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaired.



©2021 Sakar International
195 Carter Drive
Edison, NJ 08817
SUPPORT: 877 397 8200
www.sakar.com

USER'S MANUAL

ITEM: GAM83056B-BLUE

254mm

152.4mm