Important Safety Precautions

When using your Vivitar Bluetooth Neckbuds, basic safety precautions should always be followed, including the following:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR NECKBUDS.
2. Do not use your neckbuds near water. Clean using a dry or slightly moist cloth.
3. Do not place your neckbuds on any wet surfaces.
4. Do not allow children or the infirm to play with your neckbuds without adult supervision.
5. Do not expose your neckbuds to excessive heat, flames or fire.
6. Always press all buttons carefully. Do not manhandle your neckbuds.
7. Do not use in extremely dry environments, as this can lead to static discharge during usage.
8. Do not expose your neckbuds to temperatures above 40°C. Keep out of direct sunlight.
9. Do not attempt to repair this product yourself. Contact a qualified service center if your neckbuds are in need of service.
10. Do not drop, puncture or expose your neckbuds to excessive trauma.
11. Your neckbuds are not intended for commercial use.
12. Do not place near objects that generate a strong magnetic field.
13. Use only the supplied charging cables. Unplug this device when not in use for long periods of time or during lightning storms.

⚠ CAUTION

-The device is equipped with an integrated lithium battery. The battery cannot be replaced. Do not attempt to remove the battery from the device.
-Do not dispose of in fire or expose to excessive heat.
-Do not crush, puncture, incinerate, or short circuit external contacts.
-Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.

Introduction

Thank you for purchasing your Vivitar Bluetooth Neckbuds, item VOB40072BT. You can use your neckbuds with most smartphones and Bluetooth devices to stream music wirelessly and enjoy hands-free calling. In order to get the best results, please read this manual first before using your neckbuds.

Package Contents

-Vivitar VOB40072BT Bluetooth Neckbuds
-USB Charging Cable
-User's Manual with Warranty Information

Specifications

Bluetooth Specification: JLS.0
Bluetooth Range: Up to 33 feet (10 meters)
Power Supply: DC 5V
Battery Type: 3.7V, 150mAh Lithium Ion Battery
Charge Time: Approximately 2 Hours
Play Time: Approximately 4 hours*

*Applicable at 50% of maximum volume. Results will be lower when volume is higher.

A Quick Look at Your Device

Charging Your Neckbuds

1. The USB charging cable has a Micro USB plug and a standard USB plug

2. Insert the USB charging cable's Micro USB plug into the charging port on your neckbuds.

3. Insert the USB charging cable's standard USB plug into the USB port of a computer or suitable USB charging adapter.



4. The LED Indicator Light turns red while the neckbuds is charging then turns blue once charging is complete.

NOTES:

- Charging can take approximately 2 hours to complete when the battery is fully drained.
- Remove the charging cable once charging is complete.
- Overcharging could reduce the life of the battery.
- A charged battery will lose its capacity if it is not used on a regular basis.

Important: To avoid a complete discharge of the battery, charge your neckbuds at least once every six months.

Bluetooth Pairing



1. Press and hold the power button to power on your neckbuds.

2. The LED indicator light will alternately flash red and blue to indicate that your neckbuds are in pairing mode.



3. Go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on. Connect to the device listed as "VOB40072BT"

4. The LED indicator light will turn blue and flash slowly to indicate that your headphones are paired with your phone.

Using Your Neckbuds



1. Press and hold the power button to power on your neckbuds. If they have been previously paired to your Bluetooth device, they will automatically reconnect each time they are powered on.

2. Press the Play/Pause Button to play a track. Press it again to pause a track.

3. Press the + Button to advance to the next track in a playlist. Press the - Button to return to the previous track in a playlist.

4. Press and hold the + Button to increase the volume. Press and hold the - Button to decrease the volume.

5. Press the Answer button to answer an incoming call or end a call.

6. Press and hold the Answer button to reject an incoming call.

Maintenance and Care

-Before using your neckbuds, examine the ear cups to make sure that they are clean. Similarly, inspect any ports on your neckbuds to make sure that they are clear of dust and debris before charging.

-Use a soft cloth or paper towel to clean your neckbuds. Do not allow moisture to get inside the ear cups. Never use any harsh chemicals or detergents for cleaning. Make sure your neckbuds are dry before using.

-When your neckbuds are not in use, they should be stored in a cool, dry place.

-Never tug or yank on the USB cable while it is connected to your neckbuds. Connect and disconnect cables as carefully as possible.

-Never expose your neckbuds to high temperatures, extreme cold, high humidity or excessive moisture or water.

-Please recycle or dispose of your neckbuds properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your neckbuds for further information.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

Vivitar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty
Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:
Call 1-800-592-9541 in the U.S. or visit our website at www.vivitar.com.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaired.

Vivitar One Year Warranty (continued)

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION -ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR INT. BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies. This product is manufactured, distributed and sold by SAKAR International, Inc. All other trademarks are the property of the respective owner, who has not sponsored, endorsed or approved this product.

.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sakar International is under license. Other trademarks and trade names are those of their respective owners.