



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

PrimeAudio®

SAFE SOUND!


WIRELESS HEADPHONES



INSTRUCTION MANUAL

Product Diagram

HEADPHONES BOTTOM



INSTRUCTION MANUAL

ENGLISH

SAFE SOUND! Bluetooth® Wireless Headphones

FEATURES

- Limited volume of 80 decibels provides safe listening fun for ages 3 and up!
- Works with most Bluetooth®-enabled smartphones and devices
- Stream audio wirelessly via Bluetooth technology in high quality from up to 33 ft. away!
- Built-in mic enables hands-free phone calls!
- Integrated rechargeable battery provides hours of playing time wherever you go!

SPECIFICATIONS

- Power: Internal Li-Ion Rechargeable Battery
- Supply Voltage: DC 3.7V (not included)
- Sensitivity: 80dB
- Bluetooth Version: Bluetooth v3.0
- Driver Unit: 40 mm
- Impedance: 32 ohms
- Wireless Capability: Up to 33 ft range
- Frequency Response: 20Hz – 20KHz

CHARGING THE BATTERY

The internal battery must be fully charged before first use of the wireless headphones. To charge, use the included USB charge cable:

1. Insert the smaller micro-USB end of the cable into the CHARGE INPUT on the headphones unit.
2. Insert the larger USB end of the cable into the USB port of a computer OR into a compatible USB DC 3.7V wall charger (not included) to charge through a standard wall outlet. The indicator lights up red during charging and will automatically turn off when complete. Unplug from the power source when charging is complete.

NOTE: When battery power is low the LED may blink red and/or there may be an alerting sound, even while music is playing. Fully charge the battery as advised above to resume normal operation.

WIRELESS HEADPHONES OPERATION

Wireless playback via Bluetooth:

1. Make sure the battery is charged as explained above.
 2. Press and hold the POWER/PLAY BUTTON until the indicator light flashes blue – this means the Bluetooth function is active and ready to connect to your smartphone/Bluetooth audio device. NOTE: If you do not connect the headphones with a Bluetooth device after 5 minutes of being turned on, they will turn off automatically. Restart this step to try to connect again.
 3. Activate Bluetooth function on your audio device – it should automatically recognize the headphones unit and allow you to select it using the name "iWorld". If required, enter the password "0000" to complete the wireless connection. When the headphones are connected, the indicator light will flash blue and you are now set to enjoy wireless audio from within a 33ft range of the audio device.
 4. Before playback, first adjust the volume of your audio device to medium level as a safe starting point.
 5. To play audio, click the POWER/PLAY BUTTON once.
 6. To pause audio, click the POWER/PLAY BUTTON once.
 7. To increase the volume, press and hold >>>. To decrease the volume, press and hold <<<. The headphones make a chime sound when they reach maximum volume. You may then adjust the volume on your audio device to make it even louder or softer as you please.
 8. To go to the next song, click >>> once. To go to the previous song, click <<< once.
 9. To answer an incoming call, click the POWER/PLAY BUTTON once.
 10. To hang up a phone call, click the POWER/PLAY BUTTON once.
 11. To disconnect and shut off the headphones, press and hold the POWER/PLAY BUTTON until the indicator light goes out.
- NOTE: Low headphones power and/or low audio device power may cause poor operation and/or no Bluetooth connection.

Playback via audio cable without battery power and Bluetooth connection:

When the battery is not charged, these headphones can still play music from devices without Bluetooth technology using the included 3.5 mm audio cable.

1. Connect your audio device by inserting one end of the included 3.5 mm cable through its 3.5 mm headphone jack and the other end into the audio input jack on the headphones.
2. Activate your audio device and use it to control playback and volume.

CAUTION

- This is not a toy. Please keep away from small children.
- Please keep the unit away from water and heat.
- Do not overcharge the battery.

TECHNICAL SUPPORT

Please do not attempt to fix the product yourself. If you are experiencing any problems with the product please do not return it to the store you bought it from. You can contact our technical support representatives and they will assist you with any questions you may have. For assistance operating your product, please consult the User's Manual or feel free to contact iWorld technical support:

iWorld LLC
65 West 36th St., 11th Floor
New York, NY 10018, USA

www.iworldnyc.com
email: support@iworldnyc.com
Please keep instructions for further reference.

© 2018 iWorld Global Trading LLC
The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by iWorld is under license. All other trademarks and tradenames are those of their respective owners. Actual product may differ slightly from image shown. MADE IN CHINA