

Technical drawing of a mechanical part, likely a shaft or rod, showing two dimensions:

- A dimension of 98.30 mm, indicated by a horizontal line with vertical end caps.
- A dimension of 294.90 mm, indicated by a horizontal line with vertical end caps.

98.30 mm



CLOCK RADIO WITH BLUETOOTH
Model: 3940032

Model: 3940032

INSTRUCTION MANUAL




WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

CAUTION: TO PREVENT ELECTRIC SHOCK DO NOT USE THIS (POLARIZED) PLUG WITH AN EXTENSION CORD, RECEPTACLE, OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.

Please read this before operating your unit.

1. :To turn unit on/off
2. **FM** :To select FM/
3. **TIME**: Setting the clock
4. **ALARM**: Setting the alarm time
5. **SLEEP**: To fall asleep with the radio
6. **SNOOZE**: Interval alarm repetition
▶▶: Interval alarm repetition
7. — **Volume down**
8. **+ Volume up**
9. **HR**: Hour setting
|◀◀:Skip/Tuning down
10. **MIN**: Minute setting
▶▶:Skip/Tuning up
11. **PM** indicator
12. **ALARM** indicator
13. indicator
14. **FM** radio indicator
15. **USB** charger for cell phone
16. **AC** outlet for charging
17. Battery compartment
18. AC Power Cord
19. FM wire antenna



POWER SUPPLY

AC: 120V ~ 60 Hz (UL)

DC: 2x1.5V, battery type AAA size (not provided)

For optimal performance, alkaline batteries are recommended. These batteries must be replaced every six months.

1. Insert the plug of power cord into a standard wall outlet.
 2. Install the batteries in their compartment. Use only the size and type of batteries specified. Respect the polarity indicated in the compartment. Improper polarity can cause damage to the device. Do not attempt to recharge the batteries, they can catch fire or explode. The batteries need to be replaced when: The volume decreases, or sound is distorted during operation.
- CAUTION:** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

TURNING ON/OFF THE UNIT

In standby mode, press button once to turn on the unit. Press again to turn off the unit.

SETTING THE TIME

1. Press and hold Time set button, in the mean time, press HOUR or MINUTE to set the time.

LISTENING TO THE RADIO

When the unit is ON, press the **FM/** button repeatedly to select FM or band. The corresponding indicator lights up.

Manual search


IMPORTANT SAFETY INSTRUCTIONS

1. **READ INSTRUCTIONS** - All the safety and operating instructions should be read before the product is operated.
2. **RETAIN INSTRUCTIONS** - The safety and operating instructions should be retained for future reference.
3. **HEED WARNINGS** - All warnings on the product and in the operating instructions should be adhered to.
4. **FOLLOW INSTRUCTIONS** - All operating and use instructions should be followed.
5. **CLEANING** - Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
6. **ATTACHMENTS** - Do not use attachments not recommended by the product manufacturer as they may cause hazards.
7. **WATER AND MOISTURE** - Do not use this product near water - for example, near a bath tub, wash bowl, kitchen sink , or laundry tub; in a wet basement, or near a swimming pool, and the like.
8. **ACCESSORIES** - Do not place this product on an unstable cart, stand tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.
9. A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.



10. **VENTILATION** - Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.
11. **POWER SOURCES** - This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to operating instruction.

13. **GROUNDING OR POLARIZATION** - This product may be equipped with a polarized alternating current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.
 - ALTERNATE WARNINGS** - This product is equipped with a three-wire grounding-type plug, a plug having a third (grounding) pin. This plug will only fit into a grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding-type plug.
 14. **POWER - CORD PROTECTION** - Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and point where they exit from the product.
 14. **PROTECTIVE ATTACHMENT PLUG** - The product is equipped with an attachment plug having overload protection. This is a safety feature. See Instruction Manual for replacement or resetting of protective device. If replacement of the plug is required, be sure the service technician has used a replacement plug specified by the manufacturer that has the same overload protection as the original plug.
 15. **OUTDOOR ANTENNA GROUNDING** - If an outside antenna is connected to the receiver, be sure the antenna system is grounded so as to provide some protection against voltage surges and built-up static charges. Article 810 of the National Electrical Code, ANSI/NFPA 70, provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna-discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.
- See figure:



1. Adjust the volume by Volume — or Volume + to the desired level.
 2. Choose your radio station with Tune—setting down or Tune + setting up.
- Automatic search
- Press and hold Tune—or Tune + for a few seconds. The automatic search locates strong stations. A station with a weak signal can be set manually by repeatedly pressing Tune—or Tune +.
- NOTE: During the search operation, the sound level is automatically muted.
- To enhance radio reception ability:
- FM: Extend the wire antenna.

BLUETOOTH FUNCTION

1. When the unit is On press **FM/⌂** button repeatedly to select the Bluetooth mode. The display will show the "b" for a few seconds and change to clock time. The Bluetooth indicator will start to bling indicating it is in pairing mode.
2. On the Bluetooth device, enable Bluetooth and select "HOTELO CLOCK" from the Device list.

DIMMER

Press DIMMER to select the brightness of the screen:high,low.

SETTING THE ALARM

1. Press Alarm button to activate the alarm mode, the alarm indicator lights up.
2. Press and hold Alarm set button, in the mean time, press HOUR or MINUTE to set the time of wake up.
3. To cancel the alarm before the preset alarm time, press Alarm button and the alarm indicator lights off.

SNOOZE FUNCTION

When the alarm rings, press SNOOZE button. The alarm stops and will sound again 9 minutes later.

SINGLE DAY ALARM (HOSPITALITY FUNCTION)

This machine provides SINGLE DAY ALARM function specially. Alarm will change to Alarm off/canceled mode automatically after around 14 minutes, if SNOOZE or ALARM OFF buttons is not hit previously. So that a new hotel guest is not subject to the preset alarm time of the previous guest.

SLEEP FUNCTION	
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10
11	11
12	12
13	13
14	14
15	15
16	16
17	17
18	18
19	19
20	20
21	21
22	22
23	23
24	24
25	25
26	26
27	27
28	28
29	29
30	30
31	31
32	32
33	33
34	34
35	35
36	36
37	37
38	38
39	39
40	40
41	41
42	42
43	43
44	44
45	45
46	46
47	47
48	48
49	49
50	50
51	51
52	52
53	53
54	54
55	55
56	56
57	57
58	58
59	59
60	60
61	61
62	62
63	63
64	64
65	65
66	66
67	67
68	68
69	69
70	70
71	71
72	72
73	73
74	74
75	75
76	76
77	77
78	78
79	79
80	80
81	81
82	82
83	83
84	84
85	85
86	86
87	87
88	88
89	89
90	90
91	91
92	92
93	93
94	94
95	95
96	96
97	97
98	98
99	99
100	100

To fall asleep with the radio, press **ON** button once to turn on the unit, then press **SLEEP** button to select 60-50-40-30-20-10 minutes of listening. The unit will automatically turn off after the specified time.

To cancel the sleep function, press the Sleep time to OFF.

TECHNICAL SPECIFICATIONS

POWER SUPPLY: AC 120V~60Hz, 5W consumption
DC 3V , 2x1.5V, battery type AAA size (not provided) for back up.
USB charger: DC 5V
RADIO: FM 87.5-108MHz

- 14. LIGHTNING** - For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.
- 17. POWER LINES** - An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.
- 18. OVERLOADING** - Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
- 19. OBJECT AND LIQUID ENTRY** - Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
- 20. SERVICING** - Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
- 21. DAMAGE REQUIRING SERVICE** - Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
 - a) When the power-supply cord or plug is damaged.
 - b) If liquid has been spilled, or objects have fallen into the product.
 - c) If the product has been exposed to rain or water.
 - d) If the product does not operate normally by following the operating instructions, adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
 - e) If the product has been dropped or damaged in any way, and.
 - f) When the product exhibits a distinct change in performance - this indicates a need for service.
- 22. REPLACEMENT PARTS** - When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.
- 23. SAFETY CHECK** - Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.
- 24. WALL OR CEILING MOUNTING** - The product should be mounted to a wall or ceiling only as recommended by the manufacturer.
- 25. HEAT** - The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the users' authority to operate the equipment.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.