

10.4 Setup Photographs:


X-axis, 30-1000 MHz



Y-axis, 30-1000 MHz




Z-axis, 30-1000 MHz




X-axis, 1-18 GHz





Y-axis, 1-18 GHz




Z-axis, 1-18 GHz



18-25 GHz, X-Axis



18-25 GHz, Y-Axis



18-25 GHz, Z-Axis

