


ANKER SOLIX

QUICK START GUIDE

Anker SOLIX C2000X Gen 2
Portable Power Station




For User Guide / App / Support


What's in the Box



Anker SOLIX C2000 Gen 2
Portable Power Station



AC Charging Cable




Car Charging Cable




Documents

Product Overview




- 1 LCD Screen
- 2 USB-C Port
- 3 Reset Hole
- 4 TT-30 Port
- 5 Overload Protection Switch
- 6 Expansion Battery Port
- 7 Car Socket
- 8 AC Port
- 9 USB-A Port
- 10 AC Input Port
- 11 Car Socket Button
- 12 Multi Power Button
- 13 AC Output Button
- 14 XT60 Input Port

LCD Screen Guide




- 1 High-Temperature / Low-Temperature Alert
- 2 Battery Level Ring
- 3 Current Input Power
- 4 USB-C Output Icon
- 5 DC Output Icon
- 6 Anker SOLIX Alternator Charger Charging
- 7 Anker SOLIX Generator Charging
- 8 Battery Level
- 9 Automatic Connection of Battery Level
- 10 Power Backup Plan
- 11 Charging / Discharging Limit
- 12 AC Charging Frequency
- 13 USB-A Output Icon
- 14 Expansion Battery Connected
- 15 Current Output Power
- 16 Estimated Time to Charge / Discharge
- 17 Wi-Fi / Bluetooth Connected

Powering On/Off



Recharging the Power Station

AC Recharging (1,800W Max)



Solar Panel Recharging (800W Max)

- The 100W/200W/400W solar panels, the PV connector to XT60 charging cable, and the solar panel extension cables need to be purchased separately.
- The figure below shows an example of connecting two solar panels.

[illegible]

(Not Included)

- Only one expansion battery can be connected with C200X Gen 2.
- You can purchase Anker SOLIX BP2000 Expansion Battery (Gen 2) or Anker SOLIX BP5000 Expansion Battery to increase the capacity to 4,096Wh or 5,120Wh.

