




QUICK
START
GUIDE




Nebula Cosmos Max

- Charge Your Projector
- Prepare Remote Control
- Power On / Off
- Adjust the Focus
- Control Buttons
- Download Nebula Connect App
- Chromecast™
- Play Video from HDMI / USB Devices


- 01
- 02
- 03
- 04
- 05
- 06
- 07
- 08




Charge Your Projector



- 1 Slide down to open the battery compartment.




- 2 Insert new batteries, matching the polarity (+ / -) as indicated.




Press **POWER** to power on.
Press and hold **POWER** . A menu pops up. Select Power Off to turn off the projector.

When the projector is in standby mode, press **POWER** to turn on / off the projector.




Press the **FOCUS** button on the remote control to adjust focus.



Adjust Focus

Navigation

Back



Power On / Off

Press to activate Google Assistant

Confirm the selected content

Home

System Settings

Volume Up / Down

Remote Control: Nebula RC
Model: D0413

- 1 Download the Nebula Connect app from the App Store (iOS devices) or Google Play (Android devices) to control your projector.
- 2 Enable Bluetooth on your smartphone.
- 3 Open the **Nebula Connect** app, and follow the on-screen instructions to complete the connection setup.

