



Permanent Outdoor Lights S4 Quick Start Guide




Installation Guide /
Video / Support

Step 1. Get Items Ready


What's in the Box

Contact support@eufy.com if anything is missing.

Light Strings & Accessories



Radar Motion Sensor & Accessories



Extension Cables* & Cable Clips *Only available in 150 ft / 200 ft kit.



Other




Tools You Will Need





Step 2. Download the eufy App

Make sure your app is updated to the latest version.




Step 3. Connect Parts & Test

Disconnect the power supply after testing.




Step 4. Install Lights




- a. The light strings can be cut to fit your house.
- b. Use cable clips to secure the strings/cable if necessary.

Step 5. Install Radar Motion Sensor



Step 6. Power on and Enjoy Your Light




Using Your Wire Splicers

You can trim your light string with a wire stripper (not provided) to better fit your house.

1. Take Apart Your Wire Splicer


 Do NOT peel the wire skin before you run the light string through the wire splicer.




2. Cut Your Light String

Use a wire stripper to cut the light string from the middle of two lights.

⚠ Power off the light strings before cutting!




3. Run the cut light string through the wire splicer Part C first, then Part B.




4. Reveal Insulated Wires


- Reveal at least 25 mm of insulated wires.
- Expose at least 15 mm of copper wiring.



5. Connect the wire splicer to the cut light string.





6. Connect to the next light string.



To Adjust the Radar Angle

Use the positioning card to adjust the radar motion sensor to the optimal angle.



PAP 22
Raccolta Carta