


POWER BANK USER'S MANUAL

Model No:82081

PRODUCT DESCRIPTION:




PRODUCT CHARACTERISTICS:

1. Battery: Li-ion polymer
2. Size: $\Phi 68.7\text{mm} \times 16.4\text{mm}$
3. Net weight: 128g
4. Capacity: 3000mAh, 3.7V/11.1Wh
5. Type-C Input: 5V/2.3A
6. Type-C Output: 5V/2A
7. Wireless Output: 5W
8. To charge full the power bank: 3 hours
9. Material: Plastic

HOW IT WORKS:


◆ How to charge the power bank:

1. Connect Type C USB input to the power bank and then connect the Type C USB plug to the laptop / computer or adapter.
2. Flashing LED display means power bank is charging.
3. When 4 indicator stop flashing, the power bank is full charged.



◆ How to charge your digital Device:

1. Use the original cable or the attached Type C USB cable.
2. Connect the power bank with your digital device.
3. The power indicator will light up for proper charging.
4. After fully charging detach the cable.



Indicator:

LED Indicators(ON OFF)	Battery Left
●	≤25%
● ●	25%~50%
● ● ●	50%~70%
● ● ● ●	75%~100%

Safety instructions:

1. Do not disassemble or attempt to repair or modify the power bank in any manner. Do not attempt to disassemble or modify the battery in order to avoid danger.
2. Avoid physical damage of the device. Misusing, beating, crushing or dropping may result in product damage.
3. Keep the device dry, do not leave the device to liquid or in the immediate vicinity of heater or flammable objects.
4. Discharge and charge the power bank at least one time in 1 months.
5. When fully charged, disconnect the device from the

electricity network.

6. Keep the device out of the reach of Children.
7. Dispose of properly or send to recycling center to save the environment.
8. Do not contact the power bank battery terminals with metal objects, it may cause fire.
9. Do not expose product to fire or extreme high temperatures, wet or corrosive environment.
10. Optimum working temperature for device is lower 60 degrees celcuys.
11. Charging time will vary depending on brand of adapters being used due to different specifications.
12. Battery performance will possibly decline after being used for certain period of time.
13. Please fully charge the power bank to activate it before first use.



FCC Statement

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
The device has evaluated to meet general RF exposure requirement. The device can be used be in portable exposure without restriction.

Thank you very much for your choosing out power bank.

四折 Size:350x90mm