

正面

140 mm

尺寸:525*140m

材质:70g书写纸

ionix[®]
AIH-78/6
AI BLUETOOTH
STEREO HEADPHONES



INSTRUCTION MANUAL
PLEASE READ ALL INSTRUCTIONS CAREFULLY
AND RETAIN FOR FUTURE USE

1

Getting started

- Remove the product from the box.
- Please retain all packaging after you have checked and counted all the parts and the contents against the list.

Package Contents

- Bluetooth Stereo Headphones
- Type-C Charging Cable
- 3.5mm Auxiliary Cable
- Instruction Manual

Key Features


- Bluetooth stereo headphones with built-in Microphone
- Connect seamlessly to your devices
- Offers stable connection, crystal clear sound quality for music and phone-calls
- AI Voice Assistant Operation - Optimized for Google Assistant and Siri
- Padded earcups and headband for comfort
- Adjustable headband for customized fit
- Rechargeable battery 200mAh
- Recharge cable & aux cable included

Safety Instructions

- Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.
- Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent electric shock, explosion and/or injury to yourself and damage to the unit.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs of electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Do not use the unit with wet hands.
- Do not put objects into any of the openings.
- Keep the unit free from dust, lint etc.
- Do not use this unit for anything other than its intended use.
- Keep the unit out of reach of children.
- This product is not a toy.
- Do not use the headset at excessive volume levels, as damage to hearing may occur.

2

Description of Parts:



1	EQ Button
2	Volume Increase (+) / Next Track Button
3	Volume Decrease (-) / Previous Track Button
4	ON/OFF / Play/Pause/Phone Button
5	LED Light Indicator
6	Aux-in Port
7	Charging Port
8	Built-In Microphone

INSTRUCTIONS FOR USE

Charging Instructions

The Bluetooth Headphones come with a built-in rechargeable battery. Before using it for the first time, we recommend charging the battery fully. It takes about 2-2.5 hours to fully charge the battery. Only use the supplied USB Cord to charge the Bluetooth Headphones. Connect the USB charging cord to USB power source, and the Type-C plug to the Charging port of the device. The Red LED light turns on while the device is charging. It takes about 2-2.5 hours for the headphones to fully charge. When the battery is fully charged, the LED light will turn blue.

Switching on/off the device

Long press the ON/OFF button to turn on/off the device.

Pairing the device with Bluetooth devices (phone or music device)

- Ensure the device is turned off and then long-press the ON/OFF button to turn on the device, you will hear an indication tone, and the LED will flash red and blue. Place the Bluetooth Headphones and Bluetooth device (phone or music device) so that they are no further than 3 feet apart.
- Activate the Bluetooth function on your Bluetooth device (phone or music device). Please refer to the manufacturer's instructions on how to enable Bluetooth on your device.

3

- Once you have activated Bluetooth on your device, select the "ionix Headphones" from the list of available Bluetooth devices.
- You might be prompted with "Pair with ionix Headphones?" message on your source device, with "Cancel" and "OK" options. Please click "OK".
- If required, enter the password "0000" to confirm & finalize pairing.
- Once paired successfully, you will hear another indication tone, and the LED will flash blue slowly.
- You can now start to use the device.

If pairing is unsuccessful, turn off the device first and then re-pair following the above steps.

- Once you have paired the Bluetooth Headphones with a device, the Headphones will remember this device and will pair automatically when the device's Bluetooth is activated and in range. You do not need to re-pair any previously connected devices.
- Bluetooth Headphones will attempt to automatically connect to the last device it was paired with when switched on. If you want to pair it with a new device, please follow the steps outlined above.
- Once the Bluetooth Headphones are paired with your device, the music will be transmitted through the Bluetooth Headphones. Please refer to your device's user manual for further information.

Function Summary

Listening to Music

Once the Headphones are paired with your device you can stream music wirelessly through the Bluetooth Headphones. Should you encounter any problems while streaming please refer to your device's user manual for further information.

Control Function

Function	Operation	Button
Increase Volume	Playing music	A short press each time on the + button will increase the volume
Decrease Volume	Playing music	A short press each time on the - button will decrease the volume
Pause	Playing music	Short press on the Play/Pause button will pause the music
Play	Pausing	Short press on the Play/Pause button will restart the music
Previous track	Playing music	Long press the Previous Track button will return you to the previous track
Next track	Playing music	Long press the Next Track button will take you to the next track

4

An indication tone will alert you when the volume is adjusted to maximum level.

EQ Mode

Short press the EQ button each time to different EQ mode operation, the modes are Bass mode -> Vocal mode -> Pop mode.

Making a call with Bluetooth Headphones in Bluetooth mode

Basic operation

Function	Operation	Button
Answer a call	Incoming Call	Press the Phone button once to answer an incoming call
Reject a call	Incoming Call	Long press the Phone button
End a call	During a call	After your phone conversation, short press the Phone button.
Increase Volume	During a call	A short press each time on the + button will increase the volume
Decrease Volume	During a call	A short press each time on the - button will decrease the volume
Redial last number	Standby mode and connected to a device	Short press the Phone button twice

Please Note

- Not all mobile phones support all the functions listed above. Please refer to your cell phone's user manual for further information.
- Certain functions and indication tone may vary depending on your mobile phone.

AI Voice Assistant Operation

Voice Assistant is a built-in, interactive feature that allows you to start a conversation with Siri or Google Assist, short press a button twice on your device.

This feature enables you to ask questions and seek assistance on several things from your Voice Assistant, even when you're several feet away from your phone. Below are some examples.

Note: Google Assist is available on eligible Android 5.0 devices or later. Works on Lollipop, Marshmallow and Nougat Android Phones with Google Play Services, >1.5GB of memory and 720P or higher screen resolution. Please ensure Google Assist App is downloaded and is listed as the default Voice Assistant on your mobile device.

While the headphones are paired using Bluetooth, short press the EQ button twice to start a conversation with Siri or Google Assist. An indication tone will sound before you speak into the headphones.

5

105 mm

- Example 1: Short press the EQ button twice and then speak into the headphones, how's the weather today?
Voice Assistant will reply with something like "Mainly cloudy with a few showers"
- Example 2: Short press the EQ button twice and then speak into the headphones, what's the current time?
Voice Assistant will reply with something like "It is 8pm"
- More examples:
Set an alarm for 7am tomorrow.
Play some music.
What's in the news?

Listening to Music using AUX-in Mode

Insert the 3.5mm auxiliary cable (included) to the Aux input of the Headphones. The other end of the cable connects to the audio device (such as a computer, tablet, etc.).
Select your favorite song at the source device and play.

(Note: Using this Aux-in mode, you do not need to turn on the Headphones, and you need to control the volume increase/decrease, play/pause, next/previous track through your source device only.)

Tips!!

- When the headphones is not in use, turn OFF the device to save battery power.
- Do not overcharge the headphones.

Troubleshooting

Symptom	Solution
No Sound	- Power On the headphones and charge the battery - Increase the volume on your headphones, your mobile device and music source - Move your mobile device closer to the headphones and away from any interference or obstructions - User a different music source - Connect another mobile device
Poor Sound Quality	- Use a different music source - Connect another mobile device - Move your mobile device closer to the headphones and away from any interference or obstructions
Battery Won't Charge	- Secure the ends of the USB charging cable - Try another charging source
Your Google Assist not responding	- This is only available for Android Mobile Devices - Make sure Google Assistant is downloaded on

6

	your mobile device and set to default voice assistant - Make sure your Android Mobile Device is Bluetooth paired with Headphones - Make sure you are in a country where Google Assistant is available - For additional support, visit www.support.google.com/assistant
Load Dial Tone Noise When Activating Google Assist	- Make sure you have the latest version of the Google Assistant App - On your Android mobile device, go to Settings > Apps > Google App > Disable. After that, tap Enable (If you have uninstalled the Google App, please reinstall the app).

Care and Maintenance

Read the following recommendations before using Bluetooth Headphones. By following these maintenance tips, you will be able to enjoy the product for many years.

- Do not expose the Bluetooth Headphones to liquid, moisture or humidity to avoid the product's internal circuit being affected.
- Do not use abrasive cleaning solvents to clean the device.
- Do not expose the device to extremely high or low temperatures as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Do not dispose of the device in a fire, as it will result in an explosion.
- Do not expose the device to contact with sharp objects, as this will cause scratches and damage.
- Do not let the device fall on the floor. The internal circuit might get damaged.
- Do not attempt to disassemble the device as it may get damaged if you are not a professional.

Specifications

Bluetooth specification	Bluetooth 5.3
Operating distance	30 feet
Working time	Up to 6 hours
Charging input	DC 5V
Charging time	About 2-2.5 hours
Built-In Battery	200mAh

(Note: Battery life & charging time may vary based on usage & types of devices used.)

FCC Instructions

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection

7

against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Limited Warranty

This manufacturer's product warranty extends to the original consumer purchaser of the product. Neither the retailer nor any other company involved in the sale or promotion of this product is a co-warrantor of this manufacturer's warranty.

WARRANTY DURATION: All materials and workmanship are warranted to the original consumer purchaser for a period of ninety (90) days from the original purchase date.

WARRANTY COVERAGE: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty doesn't cover the following which may be supplied with this product, including but not limited to LCD Screens, glass parts, lenses, bulbs etc. This warranty is effective only if the product is purchased and operated in USA and Canada and does not extend to any units which have been used in violation of written instructions furnished by manufacturer or to units which have been altered or modified or, to damaged products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

WARRANTY DISCLAIMERS: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for manufacturer any other liability in connection with the sale of our products. There shall be no claims for defects or failure under any theory of tort, contractor commercial law including but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract. Under no circumstances will Manufacturer's / Distributor's maximum liability exceed the retail value of the product.

WARRANTY PERFORMANCE: During the above 90-day warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at manufacturer's option). The repaired or replacement product will be in warranty for the balance of the 90-day warranty period and an

8

additional one-month period. No charge will be applicable for such repairs or replacement.

SERVICE AND REPAIR: If service is required for this product, you should first contact Inspired Brands Customer Service at Support@inspired-brands.com or by calling 1 (800) 246-0972, Monday to Friday 10am to 6pm EST.

NOTE: Manufacturer cannot assume responsibility for loss or damage during incoming shipment. As a precautionary measure, carefully package the product for shipment, and insure it with the carrier. Be sure to enclose the following details with the product: your full name, return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

Distributed by (Responsible party): Inspired Brands, LLC

Address: 2311 W Howard Street, Chicago, IL 60645

Telephone No.: 1 (800) 246-0972

9

反面