272*88mm 风琴3折4页

封面

2AOMX-132639

QFX

WHERE THE PARTY BEGINS™



INSTRUCTION MANUAL

QFX 2AOMX-132639 GUIDE / GUÍA / GUIDE

IMPORTANT SAFETY GUIDELINES

1. Read all instructions before using this product.
2. Do not leave this product unattended while connected to the power supply.
3. Avoid exposing the product to water or any liquid substances.
4. Do not use if unit has been dropped or damaged in any way.
5. Improper and unauthorized repairs may place user at serious risk.
6. Electrical equipment repairs should be exclusively handled by certified professional. Ensure the unit is placed on a stable, flat surface, away from heat sources and vibrations.
7. Do not insert any objects into the unit's openings.
8. Use the product only for its intended purpose.
9. Keep this product out of reach of children.
10. Remember, this product is not a toy.
11. Avoid playing music at high volumes, especially around children, to prevent potential hearing damage.

PAUTAS DE SEGURIDAD IMPORTANTES

1. Lea todas las instrucciones antes de utilizar este producto.
2. No deje este producto desatendido mientras este conectado a la fuente de alimentación.
3. Evite exponer el producto al agua o a cualquier sustancia líquida.
4. No utilice la unidad si se ha caído o ha sufrido algún daño.
5. Las reparaciones inadecuadas o no autorizadas pueden poner al usuario en grave riesgo.
6. Las reparaciones de equipos eléctricos deben ser realizadas exclusivamente por profesionales certificados. Asegúrese de que la unidad esté colocada sobre una superficie estable y plana, alejada de fuentes de calor y vibraciones.
7. No introduzca ningún objeto en las aberturas de la unidad.
8. Utilice el producto únicamente para el fin previsto.
9. Mantenga este producto fuera del alcance de los niños.
10. Recuerde que este producto no es un juguete.
11. Evite reproducir música a un volumen alto, especialmente cerca de niños, para evitar posibles daños auditivos.

CONSIGNES DE SÉCURITÉ IMPORTANTES

1. Lisez toutes les instructions avant d'utiliser ce produit.
2. Ne laissez pas ce produit sans surveillance lorsqu'il est connecté à l'alimentation électrique.
3. Evitez d'exposer le produit à l'eau ou à toute substance liquide.
4. N'utilisez pas l'appareil si celui-ci est tombé ou a été endommagé de quelque façon que ce soit.
5. Les réparations incorrectes et non autorisées peuvent mettre l'utilisateur en danger.
6. Les réparations d'équipements électriques doivent être exclusivement confiées à un professionnel certifié. Assurez-vous que l'appareil est placé sur une surface stable et plane, à l'écart des sources de chaleur et des vibrations.
7. N'insérez aucun objet dans les ouvertures de l'appareil.
8. Utilisez le produit uniquement pour l'usage auquel il est destiné.
9. Gardez ce produit hors de portée des enfants.
10. N'oubliez pas que ce produit n'est pas un jouet.
11. Evitez d'écouter de la musique à volume élevé, en particulier à proximité des enfants, pour éviter d'éventuels dommages auditifs.

PRODUCT DIAGRAM


1. PREVIOUS SONG
2. PLAY BUTTON / ON / OFF BUTTON / HANDS FREE
3. NEXT SONG
4. DECREASE VOLUME / INCREASE VOLUME
5. TF CARD PORT
6. DC 5V CHARGING PORT
7. USB PORT
8. AUX PORT

DIAGRAMA DEL PRODUCTO

1. CANCIÓN ANTERIOR
2. BOTÓN DE REPRODUCCIÓN / BOTÓN DE ENCENDIDO / APAGADO / MANOS LIBRES
3. SIGUIENTE CANCIÓN
4. BAJAR VOLUMEN / AUMENTAR VOLUMEN
5. PUERTO PARA TARJETA TF
6. PUERTO DE CARGA DC 5V
7. PUERTO USB
8. PUERTO AUXILIAR

DIAGRAMME DU PRODUIT

1. CHANSON PRECEDENTE
2. BOUTON DE LECTURE / BOUTON MARCHE / ARRÊT / MAINS LIBRES
3. CHANSON SUIVANTE
4. DIMINUER LE VOLUME / AUGMENTER LE VOLUME
5. PORT DE CARTE TF
6. PORT DE CHARGE CC 5 V
7. PORT USB
8. PORT AUXILLAIRE



QFX 2AOMX-132639 GUIDE / GUÍA / GUIDE

CONNECTING THE UNIT

1, Initial Pairing:
- Turn on both the speaker and your mobile or other device.
- Search for and select the speaker's model name, "QFX BT-26" to pair the devices.
- After the initial pairing, the devices will automatically reconnect when the speaker is turned on.

2, Wireless Mode:
- Turn on the speaker to enter wireless mode.
- Pair your device to start playing music.
- Use the "⏯" button to play or pause music.
- Tap the "⏮ or ⏭" button to skip to the previous or next track.
- Rotate the nob to adjust the volume.

3, USB/TF Card Mode:
- Insert a USB flash drive or TF card into the corresponding slot.
- The speaker will automatically start playing MP3 files.
- Use the "⏯" button to play or pause music.
- Tap the "⏮ or ⏭" button to skip tracks.
- Rotate the knob to adjust the volume.

Note: In order to use the radio please connect the USB cordas antenna.

4, FM Radio Mode:
- Double-click "⏯" until you hear FM mode.
- The speaker will scan and save all available FM stations, which may take a few minutes.
- Tap the "⏮ or ⏭" button to navigate through the stations.
- Rotate the knob to adjust the volume.

5, TWS (True Wireless Stereo) Mode:
- To connect two speakers of the same model to one device, first turn on both speakers.
- Triple-click "⏯" until you hear a "Voice Note" sound, indicating successful pairing of the two units.
- Ensure neither speaker is connected to another device before pairing.

6, Charging:
- Connect the USB cable to the speaker's charging port and plug it into a power source.
- The red LED indicator will light up, showing that the speaker is charging.

CONECTANDO LA UNIDAD

1. Emparejamiento Inicial:
- Encienda el altavoz y tu dispositivo.
- Busca y selecciona "QFX BT-26" para emparejar.
- Se reconectará automáticamente después del primer emparejamiento.

2. Modo Inalámbrico:
- Encienda el altavoz y empareja tu dispositivo.
- Usa el botón "⏯" para reproducir o pausar.
- Toca "⏮ o ⏭" para cambiar de pista.
- Gire el noble para ajustar el volumen.

3. Modo USB/Tarjeta TF:
- Inserta una unidad USB o tarjeta TF; la reproducción comienza automáticamente.
- Usa "⏯" para pausar/reproducir y "⏮ o ⏭" para cambiar pistas.
- Gire el noble para ajustar el volumen.

Nota: Conecta el cable USB como antena para usar la radio.

4. Modo FM:
- Haz doble clic en "⏯" para activar el modo FM.
- Escaneará estaciones automáticamente.
- Usa "⏮ o ⏭" para cambiar estaciones
- Gire la perilla para ajustar el volumen.

5. Modo TWS:
- Enciende dos altavoces iguales.
- Haz Tripa clic en "⏯" para emparejarlos.
- Asegúrate de que no estén conectados a otro dispositivo.

6. Carga:
- Conecta el cable USB al puerto de carga y a una fuente de energía.
- El LED rojo indica que se está cargando.

CONNEXION DE L'UNITÉ

1. **Appairage Initial :**
- Allumez l'enceinte et votre appareil.
- Recherchez et sélectionnez "QFX BT-26" pour l'appairage.
- La reconnexion se fera automatiquement après le premier appairage.

2. **Mode Sans Fil :**
- Allumez l'enceinte et appairez votre appareil.
- Utilisez le bouton "⏯" pour lire ou mettre en pause.
- Appuyez sur "⏮ ou ⏭ " pour changer de piste
- Tournez le bouton pour régler le volume

3. **Mode USB/Carte TF :**
- Insérez une clé USB ou une carte TF ; la lecture démarre automatiquement.
- Utilisez "⏯" pour lire/mettre en pause et "⏮ ou ⏭ " pour changer de piste ou.
- Tournez le bouton pour régler le volume

Note : Connectez le câble USB comme antenne pour utiliser la radio.*

4. **Mode Radio FM :**
- Double-cliquez sur "⏯" pour activer le mode FM.
- Les stations seront scannées et enregistrées automatique ment.
- Utilisez "⏮ ou ⏭" pour changer de station
- Tournez le bouton pour régler le volume.

5, **Mode TWS (True Wireless Stereo) :**
- Allumez deux enceintes identiques.
- Triple-cliquez sur " ⏯ " pour les appairer.
- Assurez-vous qu'aucune enceinte n'est connectée à un autre appareil.

6, **Charge :**
- Connectez le câble USB au port de charge de l'enceinte et à une source d'alimentation.
- Le voyant LED rouge indique que l'enceinte est en charge.

QFX 2AOMX-132639 GUIDE / GUÍA / GUID

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.
This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.
The device can be used in portable exposure conditions without restriction.

THANK YOU.

QFX Where the Party Begins!

We would love to hear about your BT-26 Journey!
Tag us **@QFXUSA** to share your stories.

FOLLOW US @QFXUSA

QFX

1 YEAR WARRANTY

LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.
Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the data stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling, if in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card, No returned Product will be shipped back to a PO BOX, If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.

QFX USA®, Inc.
RMA Processing
Customer Support Department
2957 E. 46th Street | Vernon, CA 90058

support@qfxusa.com
(800) 864-CLUB (2582) or (323) 457-9900
qfxusa.com
Hours of Operation: Monday – Friday, 9am – 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your prouuct or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth Speakers	$5.00	1 Year	1 Year
Personal Stereos	$10.00	1 Year	1 Year
Portable Radio/Cassette	$15.00	1 Year	1 Year
Large Portable Radio Cassette	$20.00	1 Year	1 Year
Mobile Audio	$10.00	1 Year	1 Year
Pro Audio SBX Systems	$75.00	1 Year	1 Year
Pro Audio PBX Systems	$75.00	1 Year	1 Year
Televisions	$25.00	1 Year	1 Year
Telephones	$10.00	1 Year	1 Year
Stand Fans	$20.00	1 Year	1 Year
Portable Rechargeable Fans	$15.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.
Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you specil legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2025 ©

1-800-864-2582
Mon-Fri 9AM - 5PM (PST)

support@qfxusa.com
Mon-Fri 9AM – 5PM (PST)

www.qfxusa.com