



USER GUIDE Bluetooth 5.0 BC

EXPERIENCE THE POWER OF AI

Designed for comfort, these earbuds feature advanced noise cancellation and rich bass, enabling precise translations in 165 languages. Customize your personal listening experience with our intuitive app, which offers simultaneous interpretation and a dual-headphone mode. Soundplay Verse AI enables you to connect and explore without limits for business, academics, or travel.


FEATURES:

- Impressive Sound Quality
- Convenient LED display
- Active Noise Cancellation (ANC)
- AI-Driven Translation

WHAT'S INCLUDED:

- Soundplay Verse AI
- 2 Earbud Tip Sets
- USB Type-C Cable
- User Guide

PRODUCT OVERVIEW



CHARGING THE SOUNDPLAY VERSE AI

1. Plug one end of the included charging cable to the USB-C port on the Charging Case, and plug the other end into a USB power source.
2. It takes up to 2 hours to fully charge the Charging Case and Earbuds from a completely depleted battery level.
3. While the Charging Case is in use, the screen will display the current battery level of the case as well as the battery levels of the earbuds.


NOTE: To maintain the battery capacity of the Soundplay Verse AI, ensure that you fully charge and discharge the unit at least once every 3 months, even if it is not being used regularly.

DOWNLOADING THE VERSE AI APP

- Scan the QR code below to download the app via Google Play or the Apple App Store.
- Once downloaded, you can follow the instructions to connect your device to Bluetooth.
- You will be prompted to create an account. Follow the instructions to finalize your account information.
- A one-time activation code will be sent to your email to bind the earbuds to your account.

BINDING YOUR EARBUDS

Scan the QR code below to bind the earbuds to your account.



CONNECTING TO BLUETOOTH

1. Take the earphones out of the Charging Case, and then the earphones will automatically turn on and enter pairing mode.
2. Activate your mobile device's Bluetooth function and search and select "VERSE BUDS" from your mobile device's Bluetooth list and follow the prompts to complete the pairing process.
3. The earbuds will announce "Connected" once your devices have been successfully paired.

NOTE: After successfully pairing once, your devices will remember each other. No pairing will be needed next time.

USING THE EARBUDS

ANSWER/END CALL: Tap the RIGHT or LEFT earbud 1 time.

REJECT CALL: Double-tap the RIGHT or LEFT earbud to reject a call.

PLAY/PAUSE: Tap the RIGHT or LEFT earbud 1 time.

NEXT SONG: Double-tap the RIGHT earbud to play the next song.

REWIND/PREVIOUS SONG: Double-tap the LEFT earbud to play the previous song.

TRANSPARENT MODE/ ACTIVE NOISE CANCELLATION (ANC):

1. Touch and hold the RIGHT earbud for 3 seconds to turn Transparent Mode.
2. Then, touch and hold the RIGHT earbud for 3 seconds to turn ANC mode ON/OFF.

VOLUME CONTROL:

- Tap three times on the RIGHT earbud to increase volume.
- Tap three times on the LEFT earbud to decrease volume.

VOICE ASSISTANT: Touch and hold the LEFT earbud for 2 seconds to activate the voice assistant.

USING THE CHARGING CASE

POWER ON LED SCREEN: Press the power button to turn the screen ON/OFF.

UNLOCK LED SCREEN: Slide the screen to unlock.

CHANGE WALLPAPER:

1. Touch and hold the Home Screen for 3 seconds.
2. Tap the LEFT or RIGHT buttons to view options.
3. Tap to select the image you want to use as your lock screen wallpaper.

NOISE CANCELLATION MODES:

Cycle between Noise Cancellation modes such as ANC, Transparent, and Normal.

MUSIC CONTROL: Play, pause, fast-forward, and rewind music; adjust the volume with the speaker button; and view lyrics displayed in sync with the music when enabled on your device.

SPATIAL AUDIO: Enjoy immersive sound modes while watching movies, listening to music, or playing games on your mobile.

STYLE OPTIONS: Choose from Default, Kaleidoscope, or Gear to customize the settings display appearance.

USING THE CHARGING CASE (CONTINUED)

FIND EARBUDS: Tap the L or R button to find your Left or Right earphone if it's lost. Once tapped, the earphone will begin beeping to help you locate it.


EQUALIZER: Adjust your audio settings to match your favorite genres like Rock, Jazz, Pop, and more.

SETTINGS: Choose your screen language, disable tap-to-wake, select a new theme, or explore more settings.

FLASHLIGHT: Tap the flashlight icon on the LED Screen to cycle through white, red, yellow, and green colors. Swipe left to right to exit the loop.

PHOTOGRAPH: Tap the camera icon on the LED Screen to take a picture with your phone.

APP HOMEPAGE



USING THE APP

Select from the following to use the Verse AI features:

HEADSET TRANSLATE: Select the language you wish to translate, and then the language you wish for it to be translated to.

BINAURAL TRANSLATE: Wear one earbud and give the other earbud to the person you'd like to translate with. You can select which languages the earbuds translate within the app.

LISTEN & TRANSLATE: Speak into the phone, and the earbuds will translate in the selected language.

FACE TO FACE: Speak into the phone for translated text output.

RECORDS: Shows previous recordings.

FIND EARPHONES: Press 'play' to find earbuds.

DUST CLEANER TOOL: Remove the earbuds from the ears and press 'start' to clean the earbuds of extra debris.

MOISTURE REMOVAL TOOL: Remove the earbuds from the ears and press 'start' to remove moisture from earbuds.

TRANSCRIBE AUDIO: Convert an audio file into text.

PRODUCT SPECIFICATIONS:

EAR BUDS	
USAGE TIME:	Up to 6 hours
CHARGING TIME:	2 hours
BATTERY CAPACITY:	40mAh
SIZE:	0.83" x 1.27" x 0.93"
WEIGHT:	0.27oz

CHARGING CASE	
SIZE:	2.49" x 2.16" x 1.20"
CHARGING TIME:	2 hours
INPUT:	5V/1A
POWER:	5W
BATTERY CAPACITY:	470mAh
WEIGHT:	1.7oz

CARE & MAINTENANCE

Use a dry cloth to clean the earbuds and the LED Charging case.

WARNINGS & SAFETY INFORMATION

1. Do not use this unit for anything other than its intended purpose.
2. Keep the unit away from heat sources, direct sunlight, humidity, and liquids.
3. Do not expose the device to extremely high or low temperatures, as doing so may damage the battery.
4. To prevent electric shocks, injuries to yourself, and/or damage to the unit, do not operate this device if it has been exposed to liquids.
5. Do not use the unit if it has been dropped or damaged in any way.
6. Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
7. Keep the unit out of the reach of children. This unit is not a toy.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV

technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

RF warning for portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

CUSTOMER SUPPORT

If you have any questions regarding this product, we are here to help. Call or email us, and an experienced customer support representative will be happy to assist you: **1-855-G0-TZUMI** or **support@tzumi.com**.

SCAN THE QR CODE FOR THE ONLINE MANUAL

It's quick, easy, and always up to date.



FCC ID: 2AON7-30466
SoundPlay® Verse AI. Distributed by tzumi® Inc. NY, NY 10016. ©Copyright 2026. All Rights Reserved. Made in China. Apple is a trademark of Apple Inc., registered in the U.S. and other countries. Google Play and the Google Play logo are trademarks of Google LLC. All other trademarks and trade names are the property of their respective owners. Subject to change without prior notice.



AURICULARES CON TRADUCCIÓN POR IA



GUÍA DEL USUARIO



EXPERIMENTA EL PODER DE LA IA

Diseñados para ofrecer comodidad, estos auriculares cuentan con una cancelación de ruido avanzada y graves potentes, lo que permite traducciones precisas en 165 idiomas. Personaliza tu experiencia auditiva con nuestra intuitiva aplicación, que ofrece interpretación simultánea y modo de auriculares duales. Soundplay Verse AI te permite conectarte y explorar sin límites para negocios, estudios o viajes.


CARACTERÍSTICAS:

- Impresionante calidad de sonido
- Práctica pantalla LED
- Cancelación activa de ruido (ANC)
- Traducción basada en IA

LO QUE INCLUYE:

- Soundplay Verse AI
- 2 tamaños de punta de auriculares
- Cable USB Tipo-C
- Guía del usuario

DESCRIPCIÓN DEL PRODUCTO



CARGA EL SOUNDPLAY VERSE AI

1. Conecta un extremo del cable de carga incluido al puerto USB-C del estuche de carga y enchufa el otro extremo a una fuente de alimentación USB.
2. Se tarda hasta 2 horas en cargar completamente el estuche de carga y los auriculares de un nivel de batería completamente agotado.
3. Mientras el estuche de carga está en uso, la pantalla mostrará el nivel de batería actual del estuche, así como los niveles de batería de los auriculares.

NOTA: Para mantener la capacidad de la batería del Soundplay Verse AI, asegúrate de cargar y descargar completamente la unidad al menos una vez cada 3 meses, incluso si no se utiliza con regularidad.

DESCARGAR LA APLICACIÓN VERSE AI

- Escanea el código QR que aparece a continuación para descargar la aplicación desde Google Play o el App Store de Apple.
- Una vez descargada, sigue las instrucciones para conectar tu dispositivo a Bluetooth.
- Recibirás una indicación para crear una cuenta. Sigue las instrucciones para completar la información de tu cuenta.
- Un código de activación único te será enviado por correo electrónico para vincular los auriculares a tu cuenta.

VINCULAR TUS AURICULARES

Escanea el código QR a continuación para vincular los auriculares a tu cuenta.



Descargar en Google Play



Descargar en el App Store



CONEXIÓN A BLUETOOTH

1. Saca los auriculares del estuche de carga, y luego se encenderán automáticamente y entrarán en modo de emparejamiento.
2. Activa la función Bluetooth de tu dispositivo móvil, busca y selecciona "VERSE BUDS" en la lista Bluetooth de tu dispositivo móvil y sigue las instrucciones para completar el proceso de emparejamiento.
3. Los auriculares anunciarán "Connected" ("Conectado" en inglés) una vez que tus dispositivos se hayan emparejado correctamente.

NOTA: Después de emparejar correctamente tus dispositivos una vez, se recordarán el uno al otro. No será necesario volver a emparejarlos la próxima vez.

USO DE LOS AURICULARES

CONTESTAR/FINALIZAR LLAMADA: toca una vez el auricular DERECHO o IZQUIERDO.

RECHAZAR LLAMADA: toca dos veces el auricular DERECHO o IZQUIERDO para rechazar una llamada.

REPRODUCIR/PAUSAR: toca una vez el auricular DERECHO o IZQUIERDO.

SIGUIENTE CANCIÓN: toca dos veces el auricular DERECHO para reproducir la siguiente canción.

REBOBINAR/CANCIÓN ANTERIOR: toca dos veces el auricular IZQUIERDO para reproducir la canción anterior.

MODO TRANSPARENTE/CANCELACIÓN ACTIVA DEL RUIDO (ANC):

1. Mantén pulsado el auricular DERECHO durante 3 segundos para activar/desactivar el modo transparente.
2. A continuación, mantén pulsado el auricular DERECHO durante 3 segundos para activar/desactivar el modo ANC.

CONTROL DE VOLUMEN:

- Toca tres veces el auricular DERECHO para subir el volumen.
- Toca tres veces el auricular IZQUIERDO para bajar el volumen.

ASISTENTE DE VOZ: mantén pulsado el auricular IZQUIERDO durante 2 segundos para activar el asistente de voz.

USO DEL ESTUCHE DE CARGA

ENCENDER LA PANTALLA LED: pulsa el botón de encendido para activar/desactivar la pantalla.

DESBLOQUEAR LA PANTALLA LED: desliza la pantalla para desbloquearla.

CAMBIAR EL FONDO DE PANTALLA:

1. Mantén pulsada la pantalla de inicio durante 3 segundos.
2. Toca los botones IZQUIERDO o DERECHO para ver las opciones.
3. Toca para seleccionar la imagen que deseas utilizar como fondo de pantalla de bloqueo.

MODOS DE CANCELACIÓN DE RUIDO:

cambia entre los modos de cancelación de ruido, como "ANC", "Transparente" y "Normal".

CONTROL DE MÚSICA: reproduce, pausa, avanza y rebobina la música; ajusta el volumen con el botón del altavoz; y mira las letras de las canciones sincronizadas con la música.

AUDIO ESPACIAL: disfruta de modos de sonido envolventes mientras ves películas, escuchas música o juegas en tu celular.

USO DEL ESTUCHE DE CARGA (CONTINUACIÓN)

OPCIONES DE ESTILO: elige entre "Predeterminado", "Caleidoscopio" o "Engranaje" para personalizar el aspecto de la pantalla de configuración.

ENCONTRAR LOS AURICULARES: toca el botón L o R para encontrar el auricular izquierdo o derecho si lo has perdido. Una vez tocado, el auricular comenzará a emitir un pitido para ayudarte a localizarlo.


ECUALIZADOR: ajusta la configuración de audio para adaptarla a tus géneros favoritos, como rock, jazz, pop y muchos más.

CONFIGURACIÓN: elige el idioma de la pantalla, desactiva la función "tocar para activar", selecciona un nuevo tema o explora más opciones de configuración.

LINTERNA: toca el icono de la linterna en la pantalla LED para alternar entre los colores blanco, rojo, amarillo y verde. Desliza el dedo de la izquierda a la derecha para salir del bucle.

FOTOGRAFÍA: toca el icono de la cámara en la pantalla LED para hacer una foto con tu teléfono.

PÁGINA DE INICIO DE LA APLICACIÓN



USO DE LA APLICACIÓN

Selecciona una de las siguientes opciones para utilizar las funciones de Verse AI:

TRADUCCIÓN CON AURICULARES: selecciona el idioma que deseas traducir y, a continuación, el idioma al que deseas traducirlo.

TRADUCCIÓN BINAURAL: colócate un auricular y pasa el otro a la persona con la que deseas traducir. Puedes seleccionar los idiomas que traducen los auriculares dentro de la aplicación.

ESCUCHAR Y TRADUCIR: habla al teléfono y los auriculares traducirán al idioma seleccionado.

CARA A CARA: habla al teléfono para obtener el texto traducido.

GRABACIONES: muestra las grabaciones anteriores.

BUSCAR AURICULARES: pulsa "Reproducir" para buscar los auriculares.

HERRAMIENTA DE LIMPIEZA DE POLVO: retira los auriculares de los oídos y pulsa "Inicio" para eliminar residuos adicionales de los auriculares.

HERRAMIENTA DE ELIMINACIÓN DE HUMEDAD: quítate los auriculares de los oídos y pulsa "Inicio" para eliminar la humedad de los auriculares.

TRANSCRIBIR AUDIO: convierte un archivo de audio en texto.

ESPECIFICACIONES DEL PRODUCTO:

AURICULARES	
TIEMPO DE USO:	hasta 6 horas
TIEMPO DE CARGA:	2 horas
CAPACIDAD DE LA BATERÍA:	40 mAh
TAMAÑO:	2,1 cm x 3,2 cm x 2,3 cm
PESO:	7,6 g

ESTUCHE DE CARGA	
TAMAÑO:	6,3 cm x 5,4 cm x 3 cm
TIEMPO DE CARGA:	2 horas
ENTRADA:	5 V/1 A
POTENCIA:	5 W
CAPACIDAD DE LA BATERÍA:	470 mAh
PESO:	48,1 g

CUIDADO Y MANTENIMIENTO

Utiliza un paño seco para limpiar los auriculares y el estuche de carga LED.

ADVERTENCIAS E INFORMACIÓN DE SEGURIDAD

1. No utilices esta unidad para fines distintos a los previstos.
2. Mantén la unidad alejada de fuentes de calor, luz solar directa, humedad y líquidos.
3. No expongas el dispositivo a temperaturas extremadamente altas o bajas, ya que esto podría dañar la batería.
4. Para evitar descargas eléctricas, lesiones personales y/o daños en la unidad, no utilices este dispositivo si ha estado expuesto a líquidos.
5. No utilices la unidad si se ha caído o se ha dañado de alguna manera.
6. Las reparaciones de equipos eléctricos solo deben ser realizadas por un electricista cualificado. Las reparaciones inadecuadas pueden suponer un grave riesgo para el usuario.
7. Mantén la unidad fuera del alcance de los niños. Esta unidad no es un juguete.

ATENCIÓN AL CLIENTE

Si tienes preguntas sobre este producto, estamos aquí para ayudarte. Llámanos o envíanos un correo electrónico, y un representante de atención al cliente con experiencia estará encantado de ayudarte: **1-855-GO-TZUMI** o **support@tzumi.com**.

ESCANEA EL CÓDIGO QR PARA ACCEDER AL MANUAL EN LÍNEA

Es rápido, fácil y siempre está actualizado.



tzumi
live awesome™

SoundPlay® Verse AI. Distribuido por tzumi® Inc. NY, NY 10016. ©Copyright 2026. Todos los derechos reservados. Hecho en China. Apple es una marca comercial de Apple Inc., registrada en EE. UU. y en otros países. Google Play y el logotipo de Google Play son marcas comerciales de Google LLC. Todas las demás marcas comerciales y nombres comerciales son propiedad de sus respectivos propietarios. Sujeto a cambios sin previo aviso.