



INTRODUCTION

Introducing the Probuds OpenEar earbuds, where cutting-edge design meets exceptional sound quality. Engineered for those who demand both comfort and performance, these earbuds offer a unique open-ear design that ensures situational awareness without compromising on audio clarity. Perfect for active lifestyles, the Probuds OpenEar earbuds seamlessly blend innovation with convenience, setting a new standard in personal audio technology.

TURNING THE EARBUDS ON/OFF

Remove the earbuds from the charging case. The earbuds will automatically turn ON. Place the earbuds back in the case to turn them OFF.

BLUETOOTH PAIRING INSTRUCTIONS

FIRST: Remove both earbuds from the charging case. They will auto pair to each other.

SECOND: Keep the earbuds within 3 feet of your smart device. Enable your device's Bluetooth function from its Settings menu. Select "Probuds OpenEar" from the Bluetooth devices list to pair the earbuds to your device. Once paired, you will hear "Connected."

Your Probuds OpenEar are now ready to use!

SINGLE EARBUD USAGE

Each earbud can be used independently.

CONTROLS

PLAY/PAUSE

Touch the RIGHT or LEFT earbud 2 times.

NEXT SONG

Touch the RIGHT earbud 3 times.

REWIND/PREVIOUS SONG

Touch the LEFT earbud 3 times.

ANSWER/END CALL

Touch the RIGHT or LEFT earbud 2 times during an incoming call.

REJECTING A CALL

Touch and hold the RIGHT or LEFT earbud for 2 seconds during an incoming call.

VOICE ASSISTANT

Touch and hold the RIGHT or LEFT earbud for 2 seconds, or until you hear a prompt sound to activate the Voice Assistant/Siri function. This function may not work with all devices.

CHARGING THE EARBUDS

Make sure to fully charge the earbuds prior to their first use. **NOTE: If you are only using one earbud and the other one is fully charged in the case, be sure to remove the one in the case prior to inserting the first one.**

CHARGING THE CASE

Plug the included Type-C charging cable into the port on the case and connect the USB end to a power source, such as an AC wall adapter or a computer. The LED on the case will flash orange while charging. Once the case is fully charged, the LED will turn solid orange.

CHARGING THE EARBUDS

When the earbuds are low on power, you will hear "Low Battery." Place the earbuds in their respective slots inside of the charging case. They will automatically begin charging. The LED indicator on the side of the case will glow green. Once the charging process is complete, the LED on the case will turn off.

IMPORTANT SAFEGUARDS

- Do not use this unit for anything other than its intended purpose.
- Keep the unit away from heat sources, direct sunlight, humidity, water or any other liquid.
- Do not expose the device to extremely high or low temperatures, as doing so may damage the battery.
- Do not operate the unit if it is wet or damp to prevent against electric shocks, injuries to yourself and/or damage to the unit.
- Do not use this unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Keep this unit out of the reach of children. This unit is not a toy.
- Do not listen to loud music at a high volume for long periods of time.

SPECIFICATIONS

Bluetooth Technology: Version 5.4
Battery (Earbuds): 50mAh; 3.7V
Battery (Charging Case): 400mAh; 3.7V
Input Power Supply: 5V/0.4A
Earbuds Charging Time: approx. 2 hr.
Case Charging Time: approx. 2 hrs.
Music Playback Time: approx. 7 hrs.

BATTERY DISPOSAL:
This product contains a lithium polymer battery. Lithium polymer batteries are environmentally safe when fully discharged. Please refer to your local and state laws for battery disposal procedures.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. **Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. **NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and the receiver.
-Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

CUSTOMER SERVICE

If you have any other questions or issues with product use and/or care, please contact tzumi Technical Support at: support@tzumi.com or 1-855-GO-TZUMI.



Probuds OpenEar Earbuds. All Rights Reserved. ©Copyright 2025. Made in China. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. All other trademarks and trade names are the property of their respective owners. Actual product may vary due to product enhancement. Subject to change without prior notice.

