

MAG21210 Power Bank

User Manual

30W


Congratulations on your purchase! We recognize the stress and annoyance of running out of battery power when you are on the go, so we created the power bank, a quick and easy way to stay connected and powered up no matter where you are. Featuring dual USB outputs, you can use powerbank to charge your tablet, most smartphones, MP3 players, mini speakers and other digital devices.

With the user's own Apple cable or connector, it can also charge iPhone and iPad devices.

Charging the power bank

Please note: Before using your power bank for the first time, please charge it to full. This unit requires 3-4 full charges and drain cycles before the battery is optimized to its full potential. The unit should be recharged every 3 months when not in use.

- Insert the regular USB end into the output USB jack of computer or wall outlet adaptor.
- Insert the Micro-USB end into the input port on the power bank.
- The display will turn and breath showing.
- The display will light continuously when power bank is charged fully.



Power indication:

Short press power key, the display shows capacity in digital.

Specifications:

- USB-C1/2 Input : 5V-3A/9V-3A
- USB-C1/2 Output: 5V-3A/9V-3A/10V-2.25A (SCP)/12V-2.5A/20V-1.5A
- Wireless Output: 5W/7.5W/10W/15W (Qi2 MPP)
- Total Output: 5V-3A Max
- Capacity: 10000mAh/38.5Wh
- Size: 63*102*22.3mm
- Weight: 213g
- Operating temperature: 10°C - 40°C (50°F-104°F)

Charging your Devices

Please note: Always check the voltage compatibility of your device before connecting to the power bank.

- Insert your device's regular USB charging cable into the output port of power bank
- Insert the other end into your electronic device
- Your device should indicate that charging has started.
- When you are finished with charging please remove the USB cable from the power bank.

Safety Precautions

Please note: Improper use may result in product damage, decreased battery life and loss of charging capacity not covered by the manufactures warranty.

- Check device voltage for compatibility before use
- Only charge the unit from your computer or a certified approved power adaptor (certification depends on your region)
- Do not store powerbank in high or low temperature environments, small enclosed areas without ventilation or place in fire
- Do not drop, bump, throw or shake the unit, this may damage internal components
- Do not disassemble or try to repair or modify
- Do not allow the unit to come in contact with water or moisture
- If battery becomes excessively hot, emits odour, gets dented or experiences any abnormal deformity you should stop using it immediately.
- Only dispose of battery at authorized recycling centre
- Do not use harsh chemicals or cleaning agents on the exterior of this unit

FCC Warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.