



真无线双耳耳机不带无线充电 BT5.0 说明书	 ① earphone ② indicator light ③ multifunctional button ④ earbud ⑤ LED lights ⑥ charging box	产品规格： 蓝牙版本：BT5.0 通话时间：约4.5小时 音乐播放时间：约5小时 充电时间：约2.5小时 电池：耳机60mAh 充电仓 400mAh 1、开机配对与连接： A.将耳机从充电盒中取出后，耳机自动开机。此时，2只耳机的指示灯闪烁蓝灯，待一只耳机出现红蓝交替闪烁时，则两只耳机自动配对。 B.打开手机的蓝牙功能，搜索耳机的配对名称TWS03，点击即可完成连接。 C.配对成功后蓝灯闪烁。 注意：如果配对失败，请将耳机放回充电仓，再重复上述步骤重新配对。	2、关机：把耳机放回充电盒即可。 3、音乐播放/暂停：按“多功能按键”暂停/播放音乐。 4、接听电话：当所连接手机有电话打进时，耳机会语音提示，按任一“多功能按键”，接通电话。通话完毕时，按任一“多功能按键”，挂断电话。 5、拒绝接听：当所连接手机有电话打进时，按任一“多功能按键”约2秒，可拒绝接听。 6、下一曲：播放音乐时，长按副机上的“多功能按键”2秒。 7、上一曲：播放音乐时，长按主机上的“多功能按键”2秒。 8、音量加：播放音乐时，快速双击副机上的“多功能按键”	9、音量减：播放音乐时，快速双击副机上的“多功能按键” 10、充电： A、给充电盒充电：使用充电线，插入充电盒的输入口。充电过程中LED灯闪烁，充满电后LED灯示灯熄灭。 B、给耳机充电：将耳机放入充电盒内，耳机指示灯亮红灯则在充电；当两只耳机充满电后，耳机指示灯熄灭。 11、语音助手 快速按三下“多功能按键”即可启动。 12、设备组成：蓝牙耳机一对、充电仓一台、一本说明书、充电线一条、耳帽中、小号各一对。
--	--	---	--	--

True Wireless Stereo Earphone without Wireless Charging BT5.0 user manual	 ① earphone ② Indicator light ③ multifunctional button ④ earbud ⑤ LED lights ⑥ charging box	Specificafion Bluetooth Version: BT5.0 Call time: about 4.5 hours Music play time: about 5 hours Charging time: about 2.5 hours Battery: Earphone: 60mAh Charging box: 400mAh 1. Power on, Pairing and Connection: A. Take the earphones out of the charging box, they will automatically power on and at the same time, indicator lights flash in blue. When one of indicator light flashes in red and blue alternately, two earphones automatically pair. B. Open "Bluetooth" on your mobile phone and search "TWS03" to click it to connect. C. When successfully pairing, the lights flash blue. Note: If cannot pairing successfully, pls take the earphones back to the charging box, and repeat the above steps to re-pairing. 2.Power off : Put the earphones into the charging box for turning off automatically.	3. Music play/pause: Click the "Multifunctional button" to play or pause music playing. 4. Answer Calls: When a phone call in , you can hear a voice prompt, click any one of the "Multifunctional button" to answer the call (only one earphones can hear the voice). When finish talking, click any one of the "Multifunctional button" to end the call. 5.Reject Calls: When a phone call in, you can hear a voice prompt, long press any one of the "Multifunctional button" for about 2 seconds to reject the call. 6.Next song: When playing music, long press the "Multifunctional button" of the vice earphone for 2 seconds. 7. Last song: When playing music, long press the "Multifunctional button" of the main earphone for 2 seconds. 8. Volume up: When playing music, quickly double-click the "Multifunctional button" of the vice earphone.	9. Volume down: When playing music, quickly double-click the "Multifunctional button" of the main earphone. 10. Charging: A. Charge the charging box: Use the charging cable and plug it to the input port of the charging box. When charging, LED lights flash; when fully charged, LED lights turn off. B. Charge the earphones: Put the earphones into the charging box. When charging, the indicator light is red; when fully charged, the indicator light is off. 11. Voice Assistant Quickly press 3 times of any "Multifunctional button". 12.Components A pair of earphones, Charging box(1pc) Instruction manual(1pc), Charging cable(1pc) A pair of earbuds in middle size, A pair of earbuds in small size
---	---	---	--	---

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.