



ANC Bluetooth Headset



CE ROHS



Specification

BN601


Driver: 40mm Neodymium
Frequency range: 20Hz-20KHz
Battery: 3.7v500 mAH replaceable
Functional Specs: Bluetooth, Hands-free, ANC, Microphone

Battery Precautions

The BN601 can be powered by a built-in rechargeable lithium-ion battery. Please charge the battery for at least 3 hours before first use. If the device has not been used for an extended period of time, the battery may be drained of power and require recharging. Only use the supplied micro-USB cable to recharge the battery. Improper charging may damage the battery and the device. Avoid storing the battery in extremely hot or cold environments. A device with a hot or cold battery may not work temporarily, even when the battery is fully charged. Do not dispose of the batteries in a fire as they may explode. Batteries may also explode if damaged. Please dispose of them according to local regulation. Do not dispose of batteries as household waste.


-1-

Getting Started



-2-

5. Cable Connection



-3-

Bluetooth Connection

Pairing headphone to your Smart device (Smart device should be within 10 meters of this headphone).
1. Activate pairing mode on headphone by press the POWER button 5 seconds. The LED will flash in blue and red.
2. Turn on Bluetooth function of your device. (refer to the device owner's manual to locate Bluetooth function).
3. Select "Search" or "Discover" devices.
4. Select "BN601".
5. Press the Enter key.
After completing the steps above, a message in your Smart device will appear confirming that your device is now paired/connected.
In case of unsuccessful pairing, turn off it and restart, then do as steps above. If the Bluetooth on your smart device remains open, when you restart the headphone, the Bluetooth will be connected automatically.

Active Noise Cancelling

BN601 has ANC function. Switch the NC button to turn on the noise cancelling function. It can reduce about 18db-25db noise on the background, make you more enjoy your music.

-4-

Functional Guide

Playing music

Button	Operation	Function
	Long press	Volume up
	Short press	Next song
	Long press	Volume down
	Short press	Previous song
	Short press	Play/Pause, Answer/End a call
	Long press	Ready for pairing / Power on/off
	Switch	Turn on/off noise cancelling

8. LED Display Status

	LED Display	Light indication
Right LED	Flash in Blue	Power ON
	Stay Solid	Paired
	Flash in Blue and Red	Ready to pair
Left LED	Blue	Active noise cancelling ON
	OFF	Active noise cancelling Off

-5-

Battery Charging

This BN601 has a built-in rechargeable lithium-ion battery that can be charged by connecting the supplied cable to a USB port of your computer or into an AC adapter with USB port. When charging is completed, the red light will go off.

Product care

This device is designed to be light, compact and durable. As an electronic device it must be treated carefully. Putting unnecessary pressure in it or striking the device against other objects may cause damage. To avoid damage to your device, please:

Do not drop, crush, bend or apply excessive force to the device. Do not expose your device to moisture, extreme or prolonged heat, cold, humidity, or other adverse conditions. Avoid storing it in damp, humid or wet places, as it is not waterproof. Clean the unit with a soft cloth or damp chamois leather. Never use solvents. The unit can only be opened by qualified personnel. This unit contains magnets. Keep magnetic field sensitive products such as credit cards and video screen away from this device to avoid damage or malfunction.

-6-

NO HAPPY?


We encourage our customer to give us feedback through your ORDER ID before you get upset and leave a bad review or feedback.

We will try our best to help you resolve your problem.

Or,

More detail installs and help please contact us directly:

Email: fans@willnorn.com



-7-

Warranty

Willnorn 1 Year Defect Warranty

All products listed below come with a life time general warranty, which are considered defects. Defect is defined as an imperfection or flaw in the product produced by a manufacturing error. Accidental drop, installation failures, etc. caused by the owner are covered under this warranty.
- Headsets/headphones

*All terms and conditions for any and all warranties are subject to change under the sole discretion of Willnorn.

*Find more warranty help on:



-8-

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

Willnorn™



Follow us to discover more

WWW.Willnorn.com

Contact: fans@willnorn.com

Designed by Shenzhen Weihuo Technology Co., Ltd