OTium

User Manual

True wireless earbuds TWS-A3

Thank you for purchasing our product. Please review this manual throughly before operating your device.

Packing List

Charging case*1 piece

TWS earbud*1 pair

Ear cap*3 pairs

Manual*1 piece

Type-C charging cable*1 piece

Product picture



① Earcap
② Earbuds charging contact
③ Earbud indicator/Microphone
④ Tap area
⑤ Charging case charging pin
⑥ Charging case electricity indicator
⑦ Type-C charging input port

Wearing

Wearing earbuds and adjust the right angle as the picture shows. It is OK when we feel comfortable and stable.

Closer microphone makes a crystal clear phone calls.

How To Use

Power on

Auto power on:

• Just open the case cover and the earbuds will be power on automatically.

Manual power on:

• blue lights

• Top the touch area of earbuds for 3s at the same time.

Pairing

The first step: Earbuds is the pairing mode

For first use, open the charging case, the earbuds will power on automatically and enter the pairing mode.

The second step: Phone searching and connecting

Turn on Bluetooth function of phone to search P3 and then connect. It will show connected successfully.

Tips:
1. When the red & blue lights of the master earbud flash alternately, and the indicator of the slave earbud flashes fast blue slowly, the earbuds are ready to pair with your Bluetooth device.
2. When the earbuds indicators flash blue slowly, they have connected with cellphone.

Connection lost

Reason 1: When earbuds are connected with mobile phones, when you open charging case, earbuds will connect to the last connected mobile phone automatically. If the last connected mobile phone is out of connection range or Bluetooth function is not on, earbuds will get into searching status.

Reason 2: The pairing mode lasts 5 minutes at most. Earbuds will power off automatically if they are not connected with any bluetooth-enabled device. If you want to connect P3 and to be connected again, please operate as "Power on"and "Pairing"steps.

Reason 3: If out of the bluetooth range, earbuds will disconnect with Bluetooth-enabled device and will re-connect if back to the right distance within 5 minutes.



Incoming call

Answer a call/End a call

Double click either earbud at touching area

Double click

Reject a call

Long press either earbud for 2S

Press 2S

Music

Pause/ Play

Double click either earbud at touching area (Some phones may require you to start a media player first).

Double click

Voice Assistant / Siri

Triple click will activate Siri function and last with same operation. (this function is only available to IOS system).

Triple click

Previous /Next song

Press the left earbud 2S for previous song; press the right earbud 2S for next song.

Notice:
1. If a phone call comes during music play, the earbuds will play music automatically after the call ends.
2. Music will pause if using Siri., and will re-play music automatically after exit Siri.
3. If using only one earbud, the earbud can go next song only, cannot go previous song by this operation.

Single Mode

Either earbud can connect with Bluetooth-enabled device and used as a wireless earbud independently.
When one earbud run out of the power, or turn off one earbud, the other one will keep working.

Turn Off

Method 1:
Put the earbuds into the charging case , they will enter into charging mode and power off automatically.

Method 2:
If the charging case is not available, just disconnect the Bluetooth connection between your cell phone and the earbuds, the earbuds will power off automatically after 5 minutes.

disconnect the Bluetooth connection

Method 3 :
Press the left/right earbud for about 6 seconds, and the left / right earbud will turn off automatically.

press 6 s

Charging

Earbuds Charging Status

When earbuds is low battery, put earbuds into charging case and it will charge automatically. The charging case indicator will be white. When fully charged, the charging case indicator will be off, the charging case will power off automatically.

Note: It takes about 1.5 hours to fully charge the earbuds.

• Charging (With in light of the charging case keep lighting.)

• Full charged(the indicators keep white light)

Tips: When the charging contact point of the earbuds or the charging case is found to be dirty, please use a cotton swab or a fine cloth to gently wipe it off.

Charging Case Charging Status

Plug in suitable power supply for charging case, the indicator flashes white light. And it will keep white light when fully charged, please disconnect the charging device from the charging case.

• Charging (the indicator flashes white light)

• Full charged(the indicators keep white light)

Note:
1. It takes about 1.5 hours to fully charge the charging case.
2. Please use the 5V 1A charger to charge the charging case.

Charging Case Battery And Indicator Light Status

The indicator will show charging case battery status when opening upper cover. (See below picture.)

How To Reset

If the earbuds cannot be connected to the mobile device, or the left and right earbud cannot be connected normally, please use the following reset method to solve the problem.

Turn on the earbuds, when the earbuds flash blue light, triple-click the left and right earbud touch area at the same time. The earbuds lights up red and blue light once at the same time, and then wait for automatically entering pairing mode.

Note: Please touch when the earbud is flashed blue light(within 10 seconds), but the touch is invalid when flashes red and blue light.

Specification

Bluetooth version	V5.0
Support profile	A2DP/AVRCP/HFP/HSP
Transmission distance	10M
Frequency range	2402MHz-2480MHz
Driver	φ6MM*2 Hi-Fi Speaker
Voltage	3.7V
Standby time	About 40H
Talking time	About 3.5H
Playing time	About 4H
earbud battery capacity	25mAh
earbud charging time	About 1.5H
Support system	IOS/Android/Windows
Certification	CE/FCC/Rohs

Safety Instruction

Using earbuds at high to moderate volumes for extended periods of time will result in permanent hearing damage. It suggests that you keep volume levels moderate to low at all times for your ear protection.
Do not use earbuds while driving, cycling, operating machinery or performing other activities that require hearing surrounding sounds.
Do not use earbuds in thunderstorm weather, the earbuds may not work properly in the bad weather condition, and may increased risk of electric shock.
Earbuds may not work properly under high temperature or high humidity conditions.
Do not use any corrosive cleaners/oil to clean the earbuds. If the earbuds come in contact with liquids, quickly wipe away. If submersed in this water, do not turn the earbuds on until it is completely dried.

Tips: Warranty void if the earbuds submersion in the water. Keep the earbuds and the packaging out of reach of children.

Trouble Shooting

If the earbuds cannot be connected with your phone, please try the following steps:
1. Please make sure the earbuds are fully charged.
2. Please make sure the earbuds are powered on.
3. Please make sure the earbuds are not paired with other devices.
4. Please make sure the Bluetooth-enabled devices' BT function is on and in pairing mode.
5. Please make sure that the distance between the earphone and Bluetooth-enabled device is within available connection range.
6. Please try to turn on the earbuds again.

Questions&Answers of P3 Wireless Earbuds

Q: Why my Earbuds Can't be Charged ?
A: Put the earbuds into the charging case and close the case, it will charge automatically. The LED lights of the case light on when the earbuds are in charging and the lights will go out when fully charge.
If the led light is none, please check following steps:
Firstly, try to wipe the charging contact point with alcohol cloth.
Secondly, try to use the USB Cable to charge the charging case and earbuds together. Or check whether the LED light on the charging case.
If still not make it, please make the problem video to our official email after sale, we will help you solve it.

Q: The earbuds has no any action or shut down ?
A: Put earbuds into charging case and close charging case for 10 seconds. Re-open charging case and earbuds can work properly.

Q: Why my Charging case can not be Charged ?
A: Ensure that the charging cable is properly connected to the charging port or replace charging cable.

Q: Why is Bluetooth Earbuds signal direct distance better than the curve ?
A: Because this is a kind of radio wave, it has low transmission power. However, if there is an obstruction , the signal is not good.

Q: Signal is not stable or left earbud is out of voice?
A: Try to wear the earbuds well, and put the mobile on front pocket when used in outdoor

Q: Why is my phone volume and sound clarity different from my friends phone when calling?
A: This issue is on each people's individual phone, we have done our best to ensure the sound clarity and volume on many different phones.

Q: Why do the Earbuds become a little warm after using them for a while?
A: Because these Earbuds are completely the in-ear type, the ear space is not large enough for quick heat dissipation, so the earbuds may get a little warm, but you don't need to worry about it, the heat is definitely a human body acceptable temperature.

Q: How far is the distance between the left earbud and the right one?
A: 0M in the normal environment without any barrier.

Attention

The Earbuds are excellent in quality. In order to extent the life of the Earbuds, please make sure of the following instructions :

1. Please don't dismantle the Earbuds or Charging Case.
2. Do not touch the earbuds in corrosive liquid, otherwise it will cause damage to them.
3. Do not put the equipment under too high or too low temperature (Below 0 °C or above 45°C).
4. Please prevent the device from being shock or dropping, warping, soaking, etc.
5. Please don't overcharge the device for a long time, as that will decrease the battery life.
6. Please stop using the device immediately if it causes discomfort or pain.
7. Use DC-5V 1A chargers/adapters certified by a regulated manufacturer.Recharging and discharging the headphones repeatedly will lead to decrease in battery performance over time,which is normal for all rechargeable batteries.
8. This product contains a built-in lithium battery. Please do not expose the product to strong sunlight, roasting or throwing it into the fire, as they may explode.

For better sound quality experience, suggest use IOS 8.0/ Android 4.3 or above operation system.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:(1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.