




Wireless Watchdog Personal Security Monitor **Instructions**



For additional assistance or trouble-shooting help,
please email info@jobar.com

© 2017 Jobar International, Inc.
Carson, CA 90745

JB8066 [112817]

Battery Precautions

- All batteries must be of the same type.
- Do not mix old and new batteries.
- If battery contents are leaking, discontinue use and discard.
- Remove dead batteries.
- Remove batteries if not in use.

Portable Alert Battery Installation

- Slide battery cover (F) to open and insert 3 AA type batteries according to the polarity (+/-) marked in the battery compartment. Replace battery cover.

Motion Monitor Battery Installation

- Remove screws (J) from back side of motion sensor with a Philips screwdriver (not included). Pull battery cover and insert a 9V battery according to the polarity (+/-) marks. Replace battery cover and screws.

Use Instructions

Press on/off button (B) to turn on the Portable Alert. The red LED lights will flash and make a short sound. Press the on/off button again to turn off.

Press button (C) (+) to increase the volume level or (-) to decrease.


Place the Portable Alert upright on any flat surface, or clip it to your belt buckle or alike using clip (E) located on the backside.

Place Motion Monitor upright on a horizontal surface or wall mount on a flat surface using included hardware.

Note: the Motion Monitor will detect motion at a maximum distance of 15' feet / 4.5 meters away, and at angles of 30 degrees horizontal and 15 degrees vertical. Once it has detected any motion, it will automatically activate the Portable Alert at a maximum distance range of 400' ft / 122 meters in an open area.

Disclaimer

Obstructions, walls, and barriers may limit the signal range.



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.